

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China

MIMXRT1050 EVK Board Hardware User's Guide

1. Introduction

This document is a Hardware User's Guide for the MIMXRT1050 Evaluation Kit (EVK) based on the NXP Semiconductor i.MX RT1050 Processor. This board is fully supported by NXP Semiconductor. This manual includes system setup and debugging, and provides detailed information on the overall design and usage of the EVK board from a hardware systems perspective.

1.1. Board overview

This EVK board is a platform designed to showcase the most commonly used features of the i.MX RT1050 Processor in a small, low cost package. The MIMXRT1050 EVK board is an entry level development board, which gives the developer the option of becoming familiar with the processor before investing a large amount of resources in more specific designs.

Contents

1.	Introduction.....	1
1.1.	Board overview.....	1
1.2.	MIMXRT1050 EVK Contents.....	3
1.3.	MIMXRT1050 EVK Board revision history.....	3
2.	Specifications.....	4
2.1.	i.MX RT1050 Processor	6
2.2.	Boot Mode Configurations.....	7
2.3.	Power Tree.....	7
2.4.	SDRAM memory	10
2.5.	SD Card Slot	10
2.6.	Hyper Flash.....	11
2.7.	QSPI Flash.....	11
2.8.	Ethernet Connector	11
2.9.	USB PHY Connector	11
2.10.	Audio input / output Connector.....	12
2.11.	OpenSDA circuit (DAP-Link)	12
2.12.	JTAG Connector	12
2.13.	Arduino Expansion Port.....	13
2.14.	Camera Module Connector	14
2.15.	User Interface Switch.....	14
2.16.	Sensor	15
2.17.	User Interface LED Indicator.....	15
2.18.	LCD Interface	15
3.	PCB Information	16
4.	EVK Design Files	16
5.	Contents of the Evaluation Kit	16
6.	Revision history	17

Features of the MIMXRT1050 EVK board are shown in *Table 1*

Table 1. Board features

Processor	NXP Processor	MIMXRT1052DVL6A(A0 silicon) MIMXRT1052DVL6B(A1 silicon)
DRAM Memory	SDRAM 256 Mb, 166MHz	MT48LC16M16A2B4-6AIT: G
DCDC	MPS	MP2144GJ
LDO	UNION	UM1550S-18 UM1750S-00
Mass Storage	TF Card Slot	
	64 Mbit Quad SPI Flash	
	512 Mbit Hyper Flash	
Display Interface	LCD Connector	
Ethernet	10/100 Mbit/s Ethernet Connector. PHY Chip: KSZ8081RNB	
USB	USB 2.0 OTG Connector	
	USB 2.0 Host Connector	
Audio Connector	3.5 mm Audio Stereo Headphone Jack	
	Board-Mounted Microphone	
	Left & Right Speaker Out Connectors	
	SPDIF Interface(unpopulated)	
Power Connector	5V DC-Jack	
Debug Connector	JTAG 20-pin Connector (SWD by default)	
	OpenSDA with DAP-Link	
Sensor	FXOS8700CQ: 6-Axis Ecompass (3-Axis Mag, 3-Axis Accel)	
Camera	CMOS Sensor Interface	
CAN	CAN Bus Connector	
User Interface Button	ON/OFF, POR Reset, Reset, USER Button	
Led Indicator	Power Status, Reset, OpenSDA, USER LED	
Expansion Port	Arduino Interface	
PCB	3.937-inch x 5.9055-inch (10cm x 15cm), 4-layer board	

1.2. MIMXRT1050 EVK Contents

The MIMXRT1050 EVK contains the following items:

- MIMXRT1050 EVK Board
- USB Cable (Micro B)

1.3. MIMXRT1050 EVK Board revision history

- EVK Rev A: Prototype.
- EVK Rev A1/2: Pilot Board.
- EVK Rev A3/4/5:Mass Product.

NOTE

EVK Rev A, Rev A1/2/3/4/5 Boards are based on A0 silicon.

- EVKB: Mass Product.

NOTE

EVKB Boards are based on A1 silicon.

2. Specifications

This chapter provides detailed information about the electrical design and practical considerations of the EVK Board, and is organized to discuss each block in the following block diagram of the EVK board.




Figure 1. Block diagram

The overview of the MIMXRT1050 EVK Board is shown in [Figure 1](#) & [Figure 2](#).




Figure 2. Overview of the MIMXRT1050 EVK Board (Front side)




Figure 3. Overview of the MIMXRT1050 EVK Board (Back side)

2.1. i.MX RT1050 Processor

The i.MX RT1050 is a new processor family featuring NXP's advanced implementation of the ARM Cortex-M7 Core. It provides high CPU performance and best real-time response. The i.MX RT1050 provides various memory interfaces, including SDRAM, Raw NAND FLASH, NOR FLASH, SD/eMMC, Quad SPI, HyperBus and a wide range of other interfaces for connecting peripherals, such as WLAN, Bluetooth™, GPS, displays, and camera sensors. Same as other i.MX processors, i.MX RT1050 also has rich audio and video features, including LCD display, basic 2D graphics, camera interface, SPDIF and I2S audio interface.

The i.MX RT1050 applications processor can be used in areas such as industrial HMI, IoT, motor control and home appliances. The architecture's flexibility enables it to be used in a wide variety of other general embedded applications too. The i.MX processor provides all interfaces necessary to connect peripherals such as WLAN, Bluetooth™, GPS, camera sensors, and multiple displays.

The more detail information about i.MX RT1050 can be found in the [Datasheet and Reference manual](#).

2.2. Boot Mode Configurations

The device has four boot modes (one is reserved for NXP use). The boot mode is selected based on the binary value stored in the internal BOOT_MODE register. Switch (SW7-3 & SW7-4) is used to select the boot mode on the MIMXRT1050 EVK Board.

Table 2. Boot Mode pin settings

BOOT_MODE[1:0] (SW7-3 SW7-4)	BOOT Type
00	Boot From Fuses
01	Serial Downloader
10	Internal Boot
11	Reserved

Typically, the internal boot is selected for normal boot, which is configured by external BOOT_CFG GPIOs. The following [Table 3](#) shows the typical Boot Mode and Boot Device settings.

Table 3. Typical Boot Mode and Boot Device settings

SW7-1	SW7-2	SW7-3	SW7-4	Boot Device
OFF	ON	ON	OFF	Hyper Flash
OFF	OFF	ON	OFF	QSPI Flash
ON	OFF	ON	OFF	SD Card

NOTE

For more information about boot mode configuration, see the System Boot chapter of the [MIMXRT1050 Reference Manual](#).

For more information about MIMXRT1050 EVK boot device selection and configuration, see the [main board schematic](#).

2.3. Power Tree

A DC 5V external power supply is used to supply the MIMXRT1050 EVK Board at J2, and a slide switch SW1 is used to turn the Power ON/OFF. J28 and J9 also can be used to supply the EVK Board. Different power supply need to configure different Jumper setting of J1. [Table 4](#) shows the details:

Table 4. Jumper settings of Power Supply

Power Supply	J1 Setting
J2	1-2
J9	3-4

NOTE

For some computers' USB, it cannot support 500ma before establishing communication. In this case, it is recommended to replace the computer or use the power adapter(J2) to power the EVK Board.

The power tree is shown in the following figure.




Figure 4. Power Tree

The power control logic of the MIMXRT1050 EVK board is shown in the following figure:

For A0 silicon:

- It will power up SNVS and DCDC_IN together firstly, then PMIC_REQ_ON will be switched on to enable external DC/DC to power up other power domains.
- ON/OFF button is used to switch ON/OFF PMIC_REQ_ON to control power modes.
- RESET button and WDOG output are used to reset the system power.

For A1 silicon:

- It will power up SNVS firstly, then PMIC_REQ_ON will be switched on to enable external DC/DC to power up other power domains.
- ON/OFF button is used to switch ON/OFF PMIC_REQ_ON to control power modes.
- RESET button and WDOG output are used to reset the system power.




Figure 5. Power Control Diagram

NOTE

Power Control Diagram described in MIMXRT1050 EVK Board is true for A0 silicon. For A1 silicon, DCDC_IN is expected to be powered with other domains together.

In the other word, for A0 silicon the DCDC_IN is powered with LDO (Path 1). And for A1 silicon, it is expected to be powered with DC/DC (Path 2).

For A0 silicon, please follow the above power logic as if not power the SNVS together with DCDC_IN, the on chip DCDC module will not power up correctly.

The power rails on the board are shown in [Table 5](#).

Table 5. Power Rails

Power Rail	MIN (V)	TYP (V)	MAX (V)	Description
VDD_SOC_IN	0.925	--	1.26	Core supplies input voltage
VDD_HIGH_IN	3	3.3	3.6	VDD_HIGH_IN supply voltage
DCDC_IN	3 ¹	3.3 ¹	3.6 ¹	Power for DCDC

VDD_SNVS_IN	2.4	3	3.6	Power for SNVS and RTC
USB_OTG1_VBUS USB_OTG2_VBUS	4.4	5	5.5	Power for USB VBUS
VDDA_ADC	3	3.3	3.6	Power for 12-bit ADC
NVCC_SD0	3	3.3	3.6	Power for GPIO in SDIO1 bank (3.3V mode)
	1.65	1.8	1.95	Power for GPIO in SDIO1 bank (1.8V mode)
NVCC_SD1	3	3.3	3.6	Power for GPIO in SDIO2 bank (3.3V mode)
	1.65	1.8	1.95	Power for GPIO in SDIO2 bank (1.8V mode)
NVCC_EMC	3	3.3	3.6	IO supply for GPIO in EMC bank (3.3 V mode)
	1.65	1.8	1.95	IO supply for GPIO in EMC bank (1.8 V mode)
NVCC_GPIO	3	3.3	3.6	IO power for GPIO

¹ For silicon A0, DCDC_IN voltage domain is 2.9V~3.1V

2.4. SDRAM memory

One 256 Mb, 166MHz SDRAM (MT48LC16M16A2B4-6AIT: G) is used on the EVK Board.

2.5. SD Card Slot

There is a SD card slot(J20) on the MIMXRT1050 EVK Board.J20 is the Micro SD slot for USDHC1 interface. If the developer wants to boot from the SD Card, the boot device switch (SW7) settings should be: ON, OFF, ON, OFF, as shown in Table 3.

2.6. Hyper Flash

On the MIMXRT1050 EVK Board, there is one 512Mbit Hyper Flash device. If the developer wants to boot from the Hyper Flash, the boot device switch (SW7) settings should be: OFF, ON, ON, OFF, as shown in Table3.

2.7. QSPI Flash

A 64Mbit QSPI Flash is used on the MIMXRT1050 EVK Board. If the developer wants to boot from the QSPI Flash, the boot device switch(SW7) settings should be: OFF, OFF, ON, OFF, as shown in Table3.

By default, this QSPI Flash is disabled on the EVK. To enable the onboard QSPI Flash, the settings need to be changed.

2.7.1. EVKA Settings

Step1:

The onboard HyperFlash should be removed, otherwise it will impact the QSPI Flash read and write timing.

Step2:

Weld 0 Ω resistor to the pad from R153 to R158.

2.7.2. EVKB Settings

For EVKB board, the onboard HyperFlash doesn't need to remove.

Step1:

Removed resistors: R356, R361 - R366.

Step2:

Weld 0 Ω resistors: R153 - R158.

2.8. Ethernet Connector

There is one Ethernet Mac controller in the MIMXRT1050 processor. The Ethernet subsystem of the MIMXRT1050 EVK Board is provided by the KSZ8081RNB 10/100M Ethernet Transceiver (U16) and a RJ45 (J19) with integrated Magnetic.

2.9. USB PHY Connector

The MIMXRT1050 contains 2 integrated USB 2.0 PHYs capable of connecting to USB host/device systems at the USB low-speed (LS) rate of 1.5 Mbits/s, full-speed (FS) rate of 12 Mbits/s or at the USB 2.0 high-speed (HS) rate of 480 Mbits/s.

2.10. Audio input / output Connector

The Audio CODEC used on the MIMXRT1050 EVK Board is Wolfson's Low Power, high quality Stereo Codec, WM8960. The MIMXRT1050 EVK Board include one headphone interface (J12), one onboard MIC (P1), two speaker interfaces (J16, J17), and the SPDIF interface (J14 & J18, DNP). J12 is a 3.5mm audio stereo headphone jack, which supports jack detect.

2.11. OpenSDA circuit (DAP-Link)

The OpenSDA circuit (CMSIS-DAP) is an open-standard serial and debug adapter. It bridges serial and debug communications between a USB host and an embedded target processor.

CMSIS-DAP features a mass storage device (MSD) bootloader, which provides a quick and easy mechanism for loading different CMSIS-DAP Applications such as flash programmers, run-control debug interfaces, serial-to-USB converters, and more. Two or more CMSIS-DAP applications can run simultaneously. For example, run-control debug application and serial-to-USB converter runs in parallel to provide a virtual COM communication interface while allowing code debugging via CMSIS-DAP with just single USB connection.

For the MIMXRT1050 EVK Board, J28 is the connector between the USB host and the target processor. Jumper to serial downloader mode to use stable DAP-Link debugger function. If developer wants to make OpenSDA going to the bootloader mode, J27 should jumper to 1-2, and press SW4 when power on. Meanwhile, the OpenSDA supports drag/drop feature for U-Disk. First, use the serial downloader mode and drag/drop the image file to U-Disk. Then select Hyper Flash as boot device and reset the Board, the image will run.

2.12. JTAG Connector

J21 is a standard 20-pin/2.54mm Box Header Connector for JTAG. The pin definitions are shown in the following figure. Support SWD by default.




Figure 6. JTAG pin definitions

2.13. Arduino Expansion Port

J22 – J25 (unpopulated) is defined as Arduino Interface. The pin definitions of Arduino Interface are shown in [Table 6](#).

Table 6. Arduino Interface pin definitions

J22	J23
UART_RX/D0	A0/ADC0
UART_TX/D1	A1/ADC1
D2/INT0	A2/ADC2
D3/INT1/PWM/OC2B	A3/ADC3
D4/T0/XCK	A4/ADC4/SDA
D5/TI/PWM	A5/ADC5/SCL
D6/AIN0/PWM/OC0A	
D7/AIN1/PWM	

J24	J25
D8/CLK0/ICP1	NC
D9/OC1A/PWM	IOREF
D10/SPI_CS	RESET
D11/OC2A/PWM/SPI_MOSI	3.3V
D12/SPI_MISO	5V
D13/SPI_CLK	GND
GND	GND
AREF	VIN
D14/I2C_SDA	
D15/I2C_SCL	

2.14. Camera Module Connector

One parallel CSI (Camera Sensor Interface) is supported by the i.MX RT1050. There is a Camera Module Connector (J35) on the MIMXRT1050 EVK Board. The CA031C based on OV7725 can be used directly.

2.15. User Interface Switch

There are four user interface switches on the MIMXRT1050 EVK Board. Their functionality is as below.

2.15.1. Power Switch

SW1 is a slide switch to control the power of the MIMXRT1050 EVK Board when the power supply is from J2. The function of this switch is listed below:

- Sliding the switch to the ON position connects the 5V power supply to the Evaluation board main power system.
- Sliding the switch to OFF position immediately removes all power from the board.

2.15.2. ON/OFF Button

SW2 is the ON/OFF button for MIMXRT1050 EVK Board. A short pressing in OFF mode causes the internal power management state machine to change state to ON. In ON mode, a short pressing

generates an interrupt (intended to be a software-controllable(power-down)). An approximate 5 seconds or more pressing causes a forced OFF. Both boot mode inputs can be disconnected.

2.15.3. Reset Button

There are two Reset Button on the EVK Board. SW3 is the Power Reset Button. Pressing the SW3 in the Power On state will force to reset the system power except SNVS domain. The Processor will be immediately turn off and reinitiate a boot cycle from the Processor Power Off state. SW4 is Reset Button.

2.15.4. USER Button

SW8 is the USER Button(GPIO5-00) for developers using. Pressing can produce changes in high and low levels.

2.16. Sensor

U32 on the EVK Board is a 6-Axis Ecompass (3-Axis Mag, 3-Axis Accel) sensor FXOS8700CQ. The Ecompass is connected to i.MX RT1050 I2C1 port.

2.17. User Interface LED Indicator

There are four LED status indicators located on the EVK Board. The functions of these LEDs include:

- Main Power Supply(D3)
Green: DC 5V main supply is normal.
Red: J2 input voltage is over 5.6V.
Off: the board is not powered.
- Reset RED LED(D15)
- OpenSDA LED(D16)
- USER LED(D18)

2.18. LCD Interface

The enhanced Liquid Crystal Display Interface (eLCDIF) is a general purpose display controller.

The eLCDIF block supports the following:

- Displays that support moving pictures and require the RGB interface mode (DOTCLK interface).

The eLCDIF provides fully programmable functionality to supported interfaces:

- Bus master interface to source frame buffer data for display refresh.
- 8/16/24/32 bit LCD data bus support available depending on I/O mux options.
- Programmable timing and parameters for DOTCLK LCD interfaces.

If developers want to use LCD, NXP provides an optional LCD module RK043FN02H-CT which has a 4.3 inches touch-screen and supports a resolution of up to 480*3(RGB)*272. This module contains two FPC cables. The LCD interface can be connected to J8(A1-A40) and the CPT interface can be connected to J8(B1-B6). LCD modules can be purchased from the NXP website.

3. PCB Information

The MIMXRT1050 EVK Board is made using standard 4-layer technology. The material used was FR-4. The PCB stack-up information is shown in [Table 7](#).

Table 7. Board stack-up information

Layer	Description	Copper(Oz)	Dielectric Thickness(mil)
1	Signal	1	—
	Dielectric	—	3
2	GND	1	—
	Dielectric	—	52
3	Power	1	—
	Dielectric	—	3
4	Signal	1	—

4. EVK Design Files

The schematics, layout files, and gerber files (including Silkscreen) can be downloaded from nxp.com/MIMXRT1050-EVK

5. Contents of the Evaluation Kit

Table 8. EVK contents

Item	Description
EVK Board	EVK Board with processor, memory, interfaces, etc
USB Cable	USB cable (Micro-B to Standard-A)

NOTE

Power adaptor, Micro SD Card, LCD Module and Camera Module are not standard parts of the Evaluation Kit.

6. Revision history

Table 9 summarizes the changes made to this document since the initial release.

Table 9. Revision history

Revision number	Date	Substantive changes
0	08/2017	Initial release
1	11/2017	References/links have been completed
2	03/2018	Add(Update) information for RT1050 silicon A1

How to Reach Us:

Home Page:
nxp.com

Web Support:
nxp.com/support

Information in this document is provided solely to enable system and software implementers to use NXP products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits based on the information in this document. NXP reserves the right to make changes without further notice to any products herein.

NXP makes no warranty, representation, or guarantee regarding the suitability of its products for any particular purpose, nor does NXP assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in NXP data sheets and/or specifications can and do vary in different applications, and actual performance may vary over time. All operating parameters, including "typicals," must be validated for each customer application by customer's technical experts. NXP does not convey any license under its patent rights nor the rights of others. NXP sells products pursuant to standard terms and conditions of sale, which can be found at the following address: nxp.com/SalesTermsandConditions.

NXP, the NXP logo, NXP SECURE CONNECTIONS FOR A SMARTER WORLD, Freescale, the Freescale logo are the trademarks of NXP B.V. All other product or service names are the property of their respective owners.

Arm, the Arm logo, and Cortex are registered trademarks of Arm Limited (or its subsidiaries) in the EU and/or elsewhere.. All rights reserved.

© 2018 NXP B.V.

Document Number: MIMXRT1050EVKHUG
Rev. 2
03/2018