# imall

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



# Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832 Email & Skype: info@chipsmall.com Web: www.chipsmall.com Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China





# MCP6XXX Amplifier Evaluation Board 4 User's Guide

#### Note the following details of the code protection feature on Microchip devices:

- Microchip products meet the specification contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is one of the most secure families of its kind on the market today, when used in the intended manner and under normal conditions.
- There are dishonest and possibly illegal methods used to breach the code protection feature. All of these methods, to our knowledge, require using the Microchip products in a manner outside the operating specifications contained in Microchip's Data Sheets. Most likely, the person doing so is engaged in theft of intellectual property.
- Microchip is willing to work with the customer who is concerned about the integrity of their code.
- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of their code. Code protection does not mean that we are guaranteeing the product as "unbreakable."

Code protection is constantly evolving. We at Microchip are committed to continuously improving the code protection features of our products. Attempts to break Microchip's code protection feature may be a violation of the Digital Millennium Copyright Act. If such acts allow unauthorized access to your software or other copyrighted work, you may have a right to sue for relief under that Act.

Information contained in this publication regarding device applications and the like is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. MICROCHIP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION. INCLUDING BUT NOT LIMITED TO ITS CONDITION. QUALITY, PERFORMANCE, MERCHANTABILITY OR FITNESS FOR PURPOSE. Microchip disclaims all liability arising from this information and its use. Use of Microchip devices in life support and/or safety applications is entirely at the buyer's risk, and the buyer agrees to defend, indemnify and hold harmless Microchip from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights.

#### Trademarks

The Microchip name and logo, the Microchip logo, Accuron, dsPIC, KEELOQ, KEELOQ logo, microID, MPLAB, PIC, PICmicro, PICSTART, PRO MATE, rfPIC and SmartShunt are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.


AmpLab, FilterLab, Linear Active Thermistor, Migratable Memory, MXDEV, MXLAB, SEEVAL, SmartSensor and The Embedded Control Solutions Company are registered trademarks of Microchip Technology Incorporated in the U.S.A.

Analog-for-the-Digital Age, Application Maestro, CodeGuard, dsPICDEM, dsPICDEM.net, dsPICworks, dsSPEAK, ECAN, ECONOMONITOR, FanSense, FlexROM, fuzzyLAB, In-Circuit Serial Programming, ICSP, ICEPIC, Mindi, MiWi, MPASM, MPLAB Certified logo, MPLIB, MPLINK, PICkit, PICDEM, PICDEM.net, PICLAB, PICtail, PowerCal, PowerInfo, Power-Mate, PowerTool, REAL ICE, rfLAB, Select Mode, Smart Serial, SmartTel, Total Endurance, UNI/O, WiperLock and ZENA are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

SQTP is a service mark of Microchip Technology Incorporated in the U.S.A.

All other trademarks mentioned herein are property of their respective companies.

© 2007, Microchip Technology Incorporated, Printed in the U.S.A., All Rights Reserved.



# QUALITY MANAGEMENT SYSTEM CERTIFIED BY DNV ISO/TS 16949:2002

Microchip received ISO/TS-16949:2002 certification for its worldwide headquarters, design and wafer fabrication facilities in Chandler and Tempe, Arizona; Gresham, Oregon and design centers in California and India. The Company's quality system processes and procedures are for its PIC® MCUs and dsPIC® DSCs, KEELOQ® code hopping devices, Serial EEPROMs, microperipherals, nonvolatile memory and analog products. In addition, Microchip's quality system for the design and mulfacture of development systems is ISO 9001:2000 certified.



# **Table of Contents**

Preface	1
Introduction	1
Document Layout	1
Conventions Used in this Guide	2
Recommended Reading	3
The Microchip Web Site	3
Customer Support	3
Document Revision History	3
Chapter 1. Product Overview	5
1.1 Introduction	5
1.2 MCP6XXX Amplifier Evaluation Board 4 Kit Contents	5
1.3 MCP6XXX Amplifier Evaluation Board 4 Description	6
Chapter 2. Installation and Operation	7
2.1 Introduction	7
2.2 Required Tools	7
2.3 MCP6XXX Amplifier Evaluation Board 4 Set-up	7
2.4 MCP6XXX Amplifier Evaluation Board 4 Operation	1
Appendix A. Schematic and Layouts1	7
A.1 Introduction1	7
A.2 Board - Schematic1	8
A.3 Board - Top Silk and Metal Layers	9
A.4 Board - Top Metal Layer2	
A.5 Board - Bottom Metal Layer2	1
Appendix B. Bill of Materials (BOM)23	3
B.1 MCP6XXX Amplifier Evaluation Board 4 BOM	3
Worldwide Sales and Service2	7

NOTES:



# Preface

# NOTICE TO CUSTOMERS

All documentation becomes dated, and this manual is no exception. Microchip tools and documentation are constantly evolving to meet customer needs, so some actual dialogs and/or tool descriptions may differ from those in this document. Please refer to our web site (www.microchip.com) to obtain the latest documentation available.

Documents are identified with a "DS" number. This number is located on the bottom of each page, in front of the page number. The numbering convention for the DS number is "DSXXXXA", where "XXXXX" is the document number and "A" is the revision level of the document.

For the most up-to-date information on development tools, see the MPLAB<sup>®</sup> IDE on-line help. Select the Help menu, and then Topics to open a list of available on-line help files.

### INTRODUCTION

This chapter contains general information that will be useful to know before using the MCP6XXX Amplifier Evaluation Board 4. Items discussed in this chapter include:

- Document Layout
- Conventions Used in this Guide
- Recommended Reading
- The Microchip Web Site
- Customer Support
- Document Revision History

### **DOCUMENT LAYOUT**

This document describes how to use the MCP6XXX Amplifier Evaluation Board 4. The manual layout is as follows:

- **Chapter 1. "Product Overview"** Provides the important information about the MCP6XXX Amplifier Evaluation Board 4.
- Chapter 2. "Installation and Operation" Covers the installation and operation of the MCP6XXX Amplifier Evaluation Board 4. It lists the required tools, shows how to set up the board, and demonstrates how to verify the amplifier operation.
- **Appendix A. "Schematic and Layouts"** Shows the schematic and board layouts for the MCP6XXX Amplifier Evaluation Board 4.
- Appendix B. "Bill of Materials (BOM)" Lists the parts used to build the MCP6XXX Amplifier Evaluation Board 4.

### **CONVENTIONS USED IN THIS GUIDE**

This manual uses the following documentation conventions:

#### **DOCUMENTATION CONVENTIONS**

Description	Represents	Examples		
Arial font:	·	·		
Italic characters	Referenced books	MPLAB <sup>®</sup> IDE User's Guide		
	Emphasized text	is the only compiler		
Initial caps	A window	the Output window		
	A dialog	the Settings dialog		
	A menu selection	select Enable Programmer		
Quotes	A field name in a window or "Save project before build" dialog			
Underlined, italic text with right angle bracket	A menu path	<u>File&gt;Save</u>		
Bold characters	A dialog button	Click OK		
	A tab	Click the <b>Power</b> tab		
N'Rnnnn	A number in verilog format, where N is the total number of digits, R is the radix and n is a digit.	4'b0010, 2'hF1		
Text in angle brackets < >	A key on the keyboard	Press <enter>, <f1></f1></enter>		
Courier New font:				
Plain Courier New	Sample source code	#define START		
	Filenames	autoexec.bat		
	File paths	c:\mcc18\h		
	Keywords	_asm, _endasm, static		
	Command-line options	-Opa+, -Opa-		
	Bit values	0, 1		
	Constants	OxFF, `A'		
Italic Courier New	A variable argument	file.o, where file can be any valid filename		
Square brackets [ ]	Optional arguments	mcc18 [options] file [options]		
Curly brackets and pipe character: {   }	Choice of mutually exclusive arguments; an OR selection	errorlevel {0 1}		
Ellipses	Replaces repeated text	<pre>var_name [, var_name]</pre>		
	Represents code supplied by user	<pre>void main (void) { }</pre>		

### **RECOMMENDED READING**

This user's guide describes how to use MCP6XXX Amplifier Evaluation Board 4. Other useful documents are listed below. The following Microchip documents are available and recommended as supplemental reference resources.

# MCP6021/2/3/4 Data Sheet, *"Rail-to-Rail Input/Output, 10 MHz Op Amps"* (DS21685)

This data sheet provides detailed information regarding the MCP602X product family.

#### THE MICROCHIP WEB SITE

Microchip provides online support via our web site at www.microchip.com. This web site is used as a means to make files and information easily available to customers. Accessible by using your favorite Internet browser, the web site contains the following information:

- **Product Support** Data sheets and errata, application notes and sample programs, design resources, user's guides and hardware support documents, latest software releases and archived software
- General Technical Support Frequently Asked Questions (FAQs), technical support requests, online discussion groups, Microchip consultant program member listing
- Business of Microchip Product selector and ordering guides, latest Microchip press releases, listing of seminars and events, listings of Microchip sales offices, distributors and factory representatives

#### **CUSTOMER SUPPORT**

Users of Microchip products can receive assistance through several channels:

- · Distributor or Representative
- · Local Sales Office
- Field Application Engineer (FAE)
- Technical Support
- Development Systems Information Line

Customers should contact their distributor, representative or field application engineer for support. Local sales offices are also available to help customers. A listing of sales offices and locations is included in the back of this document.

Technical support is available through the web site at: http://support.microchip.com

### **DOCUMENT REVISION HISTORY**

#### **Revision A (August 2007)**

• Initial Release of this Document.

NOTES:



# **Chapter 1. Product Overview**

### 1.1 INTRODUCTION

The MCP6XXX Amplifier Evaluation Board 4 is described by the following:

- Assembly #: 114-00154
- Order # : MCP6XXXEV-AMP4
- Name: MCP6XXX Amplifier Evaluation Board 4

Items discussed in this chapter include:

- Section 1.2 "MCP6XXX Amplifier Evaluation Board 4 Kit Contents"
- Section 1.3 "MCP6XXX Amplifier Evaluation Board 4 Description"

## 1.2 MCP6XXX AMPLIFIER EVALUATION BOARD 4 KIT CONTENTS

- MCP6XXX Amplifier Evaluation Board 4 One partially assembled board
- · Important Information "Read First"
- Accessory Bag Contains loose parts for populating sockets on board
- Analog and Interface Products Demonstration Boards CD-ROM (DS21912)
  - MCP6XXX Amplifier Evaluation Board 4 User's Guide (DS51681)



FIGURE 1-1:

MCP6XXX Amplifier Evaluation Board 4 Kit.

### 1.3 MCP6XXX AMPLIFIER EVALUATION BOARD 4 DESCRIPTION

MCP6XXX Amplifier Evaluation Board 4 is intended to support the inverting integrator circuit.

The MCP6XXX Amplifier Evaluation Board 4 has the following features:

- · All amplifier resistors and capacitors are socketed
- Supports all Microchip single op amps
  - PDIP-8 package (e.g., MCP6021) are socketed
  - SOIC-8 package can be accomodated; see Section 2.4.3 "Amplifier Modifications Using 8-Pin SOIC Op Amps"
- · Test points for connecting lab equipment
- Single supply configuration

Figure 1-2 shows the block diagram of the MCP6XXX Amplifier Evaluation Board 4. Lab equipment can be attached (via test points) to measure the amplifier response.




FIGURE 1-2: MCP6XXX Amplifier Evaluation Board 4 Block Diagram.



# **Chapter 2. Installation and Operation**

### 2.1 INTRODUCTION

This chapter shows how to set up the MCP6XXX Amplifier Evaluation Board 4 and verify its operation. This chapter includes the following topics:

- Required Tools
- MCP6XXX Amplifier Evaluation Board 4 Set-Up
- MCP6XXX Amplifier Evaluation Board 4 Operation

### 2.2 REQUIRED TOOLS

- · Lab power supply
- · Lab signal source (e.g., function generator)
- Lab measurement equipment (e.g., oscilloscope)

### 2.3 MCP6XXX AMPLIFIER EVALUATION BOARD 4 SET-UP

The MCP6XXX Amplifier Evaluation Board 4 is designed to demonstrate an inverting integrator using one op amp and supporting circuitry. This section details the conversion of the topology to the MCP6XXX Amplifier Evaluation Board 4. Figure 2-1 shows the circuit diagram for the board.




FIGURE 2-1:

MCP6XXX Amplifier Evaluation Board 4 Circuit Diagram.

# MCP6XXX Amplifier Evaluation Board 4 User's Guide

The power supply voltage needs to be in the allowed range for the installed operational amplifiers. Any of Microchip's op amps that operate below 5.5V can be used. Moreover, the power supply is protected by a zener diode with nominal voltage 6.2V and bypassed by a 1.0  $\mu$ F capacitor. (See **Figure 2-3: "Power Supply Block."**)

The output load consists of a capacitor (C<sub>L</sub>) and two resistors (R<sub>L</sub>, R<sub>ISO</sub>). R<sub>ISO</sub> is used to stabilize the amplifier when it drives a large capacitive load. R<sub>ISO</sub> is a short circuit (0 $\Omega$ ) when C<sub>L</sub> is small.

The non-inverting comparator provides two trip points which are at  $0.8V_{DD}$  and  $0.2V_{DD}$ . (See Section Figure 2-4: "Non-Inverting Comparator Block.")

The resistors that are part of an amplifier are placed in pin sockets which are labeled. The op amps are bypassed by 0.1  $\mu$ F capacitors and the single op amp U1 can have either a PDIP-8 or SOIC-8 package.

- PDIP-8 packages are inserted into the DIP-8 socket to the right of the U1 label.
- SOIC-8 packages can be accommodated; see Section 2.4.3 "Amplifier Modifications Using 8-Pin SOIC Op Amps".

The (surface mount) test points for power supply, ground, input signal and output signal allow lab equipment to be connected to the board. The MCP6XXX Amplifier Evaluation Board 4 top view is shown in Figure 2-2.





FIGURE 2-2:

MCP6XXX Amplifier Evaluation Board 4 Top View.

### 2.3.1 Top Level Amplifier Circuit Diagrams

#### 2.3.1.1 POWER SUPPLY BLOCK

The power supply is protected by a zener diode and bypassed by a capacitor. Figure 2-3 shows the circuit diagram for the power supply.  $C_{P1}$  = 1.0 µF.





#### 2.3.1.2 NON-INVERTING COMPARATOR

Figure 2-4 shows the circuit diagram for the non-inverting comparator block. The non-inverting comprator's trip points are  $0.8V_{DD}$  and  $0.2V_{DD}$ . R<sub>C1</sub> = R<sub>C2</sub> = 10.0 k $\Omega$ , R<sub>C3</sub> = 30.0 k $\Omega$ , R<sub>C4</sub> = 50.0 k $\Omega$ , C<sub>C1</sub> = C<sub>C2</sub> = 0.1 uF.





FIGURE 2-4: Non-Inverting Comparator Block.

#### 2.3.2 Inverting Integrator

- It integrates and inverts a voltage with an integrating frequency  $\omega = 1/R_1C_1$  (rad/s). Additional components control output clipping (wind-up) and initialization of the integrating capacitor (C<sub>1</sub>). Refer to Figure 2-1.
- Figure 2-5 shows the circuit diagram for the inverting integrator block.  $C_{U1} = 0.1 \text{ uF}, R_4 = R_5 = 100.0\Omega, M_1 \text{ is N-MOSFET}, R_3 = R_1//R_2$

**Note 1:** Adding R<sub>2</sub> to avoid the integrator output clipping at DC.

2: Adding R<sub>3</sub> to minimize the output error due to the input bias current






Table 2-1 shows the jumper positions and the corresponding effects

TABLE 2-1: JUMPER POSITIONS AND EFFECTS

Jumper	Position	Effect
JP <sub>1</sub>	1	Set the Input Reference (V <sub>REF</sub> ) to 0.5V <sub>DD</sub>
	2	Set the Input Reference (V <sub>REF</sub> )) to 0.1V <sub>DD</sub>
JP2	1	Drive Integrator with Comparator
	2	Ground Integrator's Resistor (contstant input current)
	3	Drive Integrator with External Source
JP <sub>3</sub> , JP <sub>4</sub>	1	Ground (de-activate) Integrator's Reset Switch (M1)
	2	Drive Integrator's Reset Switch (M1) with Comparator

Table 2-2 shows the integrator control strategies

TABLE 2-2:INTEGRATOR CONTROL STRATEGY

Integrator Control	Jumper Positions			ns	Integrator's Input	P2 (Integrator)
Strategy	JP1	JP2	JP3	JP4	Voltage	R2 (Integrator)
Feedback Loop <sup>(1)</sup>	1	1	1	1	VCMP (internal)	open
	2	1	1	1		
Reset Switch <sup>(2)</sup>	2	2	2	2	GND (internal)	open
Stand Alone	1	3	1	1	VINX	>> R1
	2	3	1	1	]	

Note 1: The circuit shown uses a non-inverting comparator to close the feedback loop.

**2:** The reset switch (MOSFET) in the circuit is controlled by a non-inverting comparator.

### 2.4 MCP6XXX AMPLIFIER EVALUATION BOARD 4 OPERATION


Items discussed in this section include:


- Building the Amplifier
- · Testing the Amplifier
- Amplifier Modification: Using 8-Pin SOIC Op Amps


#### 2.4.1 Building the Amplifier

This inverting integrator is described as follows:

- Power Supply  $V_{DD}$  is 5.0V
- Load Capacitance CL is 56 pF
- Load Resistance  $R_L$  is 1.6 k $\Omega$
- $R_1$ = 8.06 k $\Omega$ ,  $R_2$  is open,  $R_3$  = 8.06 k $\Omega$ ,  $C_1$  = 1  $\mu$ F,  $R_{ISO}$  = 0 $\Omega$
- Input Reference V<sub>REF</sub> = 0.5V<sub>DD</sub>
- Integrator Control Strategy: Feedback Loop (JP1: Position 1, JP2: Position 1, JP3: Position 1, JP4: Position 1)
- The fully assembled inverting integrator is shown in Figure 2-6.







The fully assembled MCP6XXX Amplifier Evaluation Board 4 top view is shown in Figure 2-7 (without any user selected components).

**FIGURE 2-7:** Picture of the Inverting Integrator Supported by the MCP6XXX Amplifier Evaluation Board 4.

### 2.4.2 Testing the Amplifier

#### 2.4.2.1 CHECKING THE TEST POINTS

The (surface mount) test points for power supply, ground, input signal and output signal allow lab equipment to be connected to the board. Figure 2-8 shows the test points to check.




FIGURE 2-8: Checking the Test Points.

#### 2.4.2.2 INVERTING INTEGRATOR RESPONSE

The MCP6021 op amp, 1% resistors, and 5% capacitors were used to build an inverting integrator circuit. The measured response with feedback control strategy is shown in Figure 2-9.




FIGURE 2-9:

Measured Output Response.


### 2.4.3 Amplifier Modifications Using 8-Pin SOIC Op Amps

There are two options available when using single op amps in SOIC-8 packages (150 mil wide):

- · Soldering onto the MCP6XXX Amplifier Evaluation Board 4, or
- · Soldering it onto a separate board which is connected to the DIP-8 socket

```
Note: The DIP-8 socket must be empty; only one op amp can be used at a time.
```

Figure 2-10 shows a SOIC-8 op amp soldered onto the MCP6XXX Amplifier Evaluation Board 4.



**FIGURE 2-10:** Op Amp in SOIC-8 package soldered onto MCP6XXX Amplifier Evaluation Board 4.

Figure 2-11 shows a SOIC-8 op amp and a DIP-8 socket, soldered onto the 8-Pin SOIC/MSOP/TSSOP/DIP Evaluation Board available from Microchip Technology Inc. (order # SOIC8EV). The two interconnect strips on the bottom are Samtec part # BBS-14-T-B or equivalent and are soldered into the through holes for the DIP-8 socket. Figure 2-12 shows this board plugged into the MCP6XXX Amplifier Evaluation Board 4.

**Note:** Insert the interconnect strips into the DIP-8 socket on the MCP6XXX Amplifier Evaluation Board 4. Place the SOIC8EV board on the top of the interconnect strips with the same pin orientation. Now solder the strips to the top board; this procedure ensures correct alignment of the strips. Clip the pins flush with the top surface of the SOIC8EV board, then solder the SOIC-8 op amp on the top.





FIGURE 2-11: Op Amp in SOIC-8 package soldered to a separate board.



**FIGURE 2-12:** Connecting Adaptor Board onto MCP6XXX Amplifier Evaluation Board 4.

NOTES:




# **Appendix A. Schematic and Layouts**


### A.1 INTRODUCTION

This appendix contains the following schematics and layouts for the MCP6XXX Amplifier Evaluation Board 4:


- Board Schematic
- Board Top Silk and Metal Layers
- Board Top Metal Layer
- Board Bottom Metal Layer

# A.2 BOARD - SCHEMATIC





# A.4 BOARD - TOP METAL LAYER



A.5 BOARD - BOTTOM METAL LAYER

