

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China







mikromedia+

for TIVA® ARM®

Amazingly compact, all-on-single-pcb development board carring 4.3" TFT Touch Screen and lots of multimedia peripherals, all driven by powerful TM4C123GH6PGEI microcontroller from ARM® Cortex $^{\text{M}}$ -M4 family





To our valued customers

I want to express my thanks to you for being interested in our products and for having confidence in MikroElektronika.

The primary aim of our company is to design and produce high quality electronic products and to constantly improve the performance thereof in order to better suit your needs.

Nebojsa Matic General Manager



Table of Contents

Introduction to mikromedia+ for TIVA® ARM®	6
System Specification	6
Package Contains	7
1. Power supply	8
2. TM4C123GH6PGEI microcontroller	10
Key microcontroller features	10
3. Programming the microcontroller	11
Programming with mikroBootloader	12
step 1 - Connecting mikromedia	12
step 2 - Browsing for .HEX file	13
step 3 - Selecting .HEX file	13
step 4 - Uploading .HEX file	14
step 5 - Finish upload	15
Programming with mikroProg™ programmer	16
mikroProg™ suite™ for ARM® software	18
Software installation wizard	19

4. RTC Battery and Reset Button	20
5. Crystal oscillator and 2.048V reference	22
6. MicroSD Card Slot	24
7. Touch Screen	26
8. Audio Module	28
9. USB DEVICE connection	30
10. USB HOST connection	32
11. Accelerometer	34
12. Flash Memory	36
13. RF transceiver	38
14. Buzzer	40
15. Other modules	42
16. Pads	44

Introduction to mikromedia+ for TIVA®

The central part of the system is a 32-bit ARM® Cortex™-M4 TM4C123GH6PGEI microcontroller. The mikromedia+ for TIVA® ARM® features integrated modules such as stereo MP3 codec, 4.3" TFT 480x272 touch screen display, accelerometer, microSD card slot, buzzer, IR receiver, RGB LED diode, PIN photodiode, temperature sensor, 2.4GHz RF transceiver, 8 Mbit flash memory, RTC battery, Li-Polimer battery charger etc. The board also contains MINI-B USB connector, power screw terminals, 2x5 JTAG connector, two 1x26 connection pads, ON/OFF switch and other. It comes pre-programmed with USB HID bootloader, but can also be programmed with external programmers, such as mikroProg™ for TIVA® or other JTAG programmers. Mikromedia is compact and slim, and perfectly fits in the palm of your hand, which makes it a convenient platform for mobile and other multimedia devices.

System Specification



power supply

Via USB cable (5V DC) or via screw terminals (2.5-12V DC)



ower consumption

26 mA with erased MCU [when on-board modules are inactive]



hoard dimensions

119.54 x 78 mm [4.71 x 3.07 inch]




weight

~270g (0.595 lbs)

Package Contains







02

mikromedia+ for TIVA®






USB cable and microSD card with adapter






04 mikromedia+ for TIVA® ARM® user's guide

1. Power supply



The mikromedia+ for TIVA® ARM® board can be powered in three different ways: via USB connector using MINI-B USB cable provided with the board (CN4), via battery connector using Li-Polymer battery (CN5) or via screw terminals using laboratory power supply (CN3). After you plug in the appropriate power supply turn the power switch ON (SW1). The USB connection can provide up to 500mA of current which is more than enough for the operation of all on-board modules and the microcontroller as well. If you decide to use external power supply via screw terminals, voltage values must be within 2.5-12V DC range. Power LED ON (GREEN) indicates the presence of power supply. On-board battery charger circuit MCP73832 enables you to charge the battery over USB connection or via screw terminals. LED diode (RED)




2. TM4C123GH6PGEI MCU features


All members of the Tiva™ C Series, including the TM4C123GH6PGE microcontroller, are designed around an ARM Cortex-M processor core. It has a 32-bit ARM® Cortex™-M4F 80-MHz processor core with System Timer (SysTick), integrated Nested Vectored Interrupt Controller (NVIC), Wake-Up Interrupt Controller (WIC) with clock

Key microcontroller features

- ARM Cortex-M4F CPU, 80-MHz operation;
- 256KB of Flash memory;
- 32KB of SRAM memory;
- 2KB of EEPROM memory;
- up to 105 I/O pins;
- 16/32-bit timers
- 16MHz internal oscillator, 32kHz RTCC;
- 8xUART, 4xSPI, 6xI2C, 2xCAN, 2xADC, USB etc.



3. Programming the microcontroller




Programming with mikroBootloader

You can program the microcontroller with bootloader which is pre programmed into the device by default. To transfer .HEX file from a PC to MCU you need bootloader software [mikroBootloader USB HID] which can be downloaded from:

http://download.mikroe.com/examples/smart-displays/mikromedia/4/tiva/mikromedia-4-tiva-mikrobootloader-usb-hid-v130.zip

After software is downloaded unzip it to desired location and start mikroBootloader USB HID software.



step 1 - Connecting mikromedia



To start connect the USB cable or (if already connected) press the Reset button on your mikromedia+ board. Click the Connect button within 5s to enter the bootloader mode, otherwise existing microcontroller program will execute.

step 2 – Browsing for .HEX file



Figure 3-3: Browse for HEX

Olick the Browse for HEX button and from a pop-up window (Figure 3.4) choose the .HEX file that will be uploaded to MCU memory.

step 3 - Selecting .HEX file



Figure 3-4: Selecting HEX

- O1 Select .HEX file using open dialog window.
- OZ Click the Open button.

step 4 - Uploading .HEX file



Figure 3-5: Begin uploading

O1 To start .HEX file uploading click the Begin uploading button.



Figure 3-6: Progress bar

01 You can monitor .HEX file uploading via progress bar

step 5 - Finish upload



Figure 3-7: Restarting MCU

Olick the OK button after uploading is finished. Board will automatically reset and after 5 seconds your new program will execute.



Figure 3-8: mikroBootloader ready for next job

Programming with mikroProg[™] programmer



The microcontroller can be programmed with external mikroProg[™] for TIVA[®] programmer and mikroProg Suite[™] for ARM[®] software. The external programmer is connected to the development system via JTAG connector, Figure 3-9. mikroProg[™] is a fast USB 2.0 programmer with hardware Debugger support. It supports ARM[®] Cortex[™]-M3 and Cortex[™]-M4 microcontrollers from TIVA[®]. Outstanding performance, easy operation and elegant design are it's key features.




Figure 3-10: mikroProg[™] JTAG connector connection schematic

mikroProg Suite[™] for ARM® software



mikroProg™ for TIVA® programmer requires special programming software called mikroProg Suite™ for ARM®. This software is used for programming ALL of TIVA® ARM® Cortex-M3™ and Cortex-M4™ microcontroller families. It features intuitive interface and SingleClick™ programming technology. Software installation is available on a Product DVD:

After downloading, extract the package and double click the executable setup file, to start installation.


Quick Guide

- Olick the Detect MCU button in order to recognize the device ID.
- O2 Click the Read button to read the entire microcontroller memory. You can click the Save button to save it to target HEX file.
- If you want to write the HEX file to the microcontroller, first make sure to load the target HEX file using the Load button. Then click the Write button to begin programming.
- O4 Click the Erase button to wipe out the microcontroller memory.

Software installation wizard



Start Installation




Ohoose destination folder



Accept EULA and continue




105 Installation in progress



1 Install for all users



Finish installation






Figure 4-1: Reset circuit and RTC battery schematic

5. Crystal oscillator and 2

The board is equipped with (1) 16MHz crystal oscillator (X4) circuit that provides external clock waveform to the microcontroller OSCO and OSC1 pins.

This base frequency is suitable for further clock multipliers and ideal for generation of necessary USB clock, which ensures proper operation of bootloader and your custom USB-based applications.

The board also contains (1) 32.768 kHz crystal oscillator (X5) which provides external clock for internal RTCC module.

Microcontroller ADC requires an accurate source of reference voltage signal. That is why we provide the external (1) voltage reference to the microcontroller VREF pin which is 2.048V.







Figure 5-1: Crystal oscillator and 2.048V reference

rence




Figure 5-2: Crystal oscillator and 2.048V reference schematic




Figure 6-1: microSD card slot




Figure 6-2: microSD Card Slot module connection schematic