



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of “Quality Parts,Customers Priority,Honest Operation,and Considerate Service”,our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China



Serial RAM™

Manual

All Mikroelektronika's development systems feature a large number of peripheral modules expanding microcontroller's range of application and making the process of program testing easier. In addition to these modules, it is also possible to use numerous additional modules linked to the development system through the I/O port connectors. Some of these additional modules can operate as stand-alone devices without being connected to the microcontroller.

Additional board

 **MikroElektronika**

SOFTWARE AND HARDWARE SOLUTIONS FOR EMBEDDED WORLD ...making it simple

Serial RAM

The Serial RAM additional board enables the microcontroller to use additional 64Kbit of RAM memory.

Key features:

- Serial SPI communication;
- 64Kbit of RAM;
- 3.3V or 5V power supply voltage.




Figure 1: Serial RAM additional board

How to connect the board?

The Serial RAM can be easily connected to a development system's port via a 2x5 connector CN1. The additional board may be connected to 3.3V and 5V development systems. If it is connected to a 3.3V development system, it is necessary to place jumper J1 in the 3.3V position. Otherwise, this jumper should be left in the 5V position. The position of switches on the DIP switch SW1 depends on the development system in use, Table 1.

	MISO	MOSI	SCK
PIC	1 (P4)	4 (P5)	6 (P3)
dsPIC	3 (P2)	5 (P3)	8 (P6)
AVR-8051	2 (P6)	4 (P5)	7 (P7)
	Position of switches on DIP switch SW1 for appropriate development system		

Table 1

How to use the board?

The Serial RAM additional board communicates with the microcontroller supplied on the development system via the Serial Peripheral Interface (SPI). A LED marked POWER indicates that the additional board is turned on.

Here you can find examples for the Serial RAM additional board:
<http://www.mikroe.com/eng/products/view/365/serialram-board/>

If you want to learn more about our products, please visit our website at www.mikroe.com

If you are experiencing some problems with any of our products or just need additional information, please place your ticket at www.mikroe.com/en/support

If you have any questions, comments or business proposals, do not hesitate to contact us at office@mikroe.com