



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of “Quality Parts,Customers Priority,Honest Operation,and Considerate Service”,our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



## Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China



# Skywire™ LTE CAT-M1 Embedded Cellular Modem Datasheet

NimbeLink Corp

Updated: March 2017



© NimbeLink Corp. 2017. All rights reserved.

NimbeLink Corp. provides this documentation in support of its products for the internal use of its current and prospective customers. The publication of this document does not create any other right or license in any party to use any content contained in or referred to in this document and any modification or redistribution of this document is not permitted.

While efforts are made to ensure accuracy, typographical and other errors may exist in this document. NimbeLink reserves the right to modify or discontinue its products and to modify this and any other product documentation at any time.

All NimbeLink products are sold subject to its published Terms and Conditions, subject to any separate terms agreed with its customers. No warranty of any type is extended by publication of this documentation, including, but not limited to, implied warranties of merchantability, fitness for a particular purpose and non-infringement.

Skywire and NimbeLink are trademarks of NimbeLink Corp. All other trademarks appearing in the document are the property of their respective owners.

# Table of Contents

## [Table of Contents](#)

### [Introduction](#)

[Orderable Part Numbers](#)

[Product Overview](#)

[Block Diagram](#)

### [Technical Specifications](#)

[Electrical Specifications](#)

[Absolute Maximum Ratings](#)

[Recommended Ratings & Module Pin out](#)

[Connectors J1 and J2](#)

[Connectors J3, X1, X2](#)

[Mechanical Specifications](#)

[Mechanical Characteristics](#)

[Mating Connectors](#)

[Device Placement](#)

[Environmental Specifications](#)

### [Important Design Considerations](#)

[PWR\\_ON Signal](#)

[Power Supply Requirements](#)

[Serial Communications](#)

[LED](#)

[GPIO Control](#)

### [Mounting Guidelines](#)

[Board to Board connectors approach](#)

[Solder to Board connection approach](#)

### [Antenna Considerations](#)

[Primary Antenna Requirements](#)

[Recommended Antennas](#)

### [Certifications](#)

[Carrier Specific](#)

[Geography Specific](#)  
[Federal Regulatory Licensing](#)  
[End Product Labeling Requirements](#)

# 1. Introduction


## 1.1 Orderable Part Numbers

| Orderable Device | Firmware Revision | Operating Temp | Bands   | GPS/GNSS | Network Type |
|------------------|-------------------|----------------|---------|----------|--------------|
| NL-SW-LTE-SVZM20 | TBD               | -40 to +85°C   | B4, B13 | No       | Verizon      |
| NL-SW-LTE-SVZM21 | TBD               | -40 to +85°C   | B4, B13 | Yes      | Verizon      |

## 1.2 Product Overview

Add robust cellular connectivity to your M2M devices with scalable radio technology with Skywire line of modems including CAT-M1 based LTE solutions. Extensive experience in designing and building embedded product solutions makes the NimbeLink Skywire™ embedded cellular modem the smallest on the market. It complies with the popular XBEE interface standard and supports multiple LTE bands minimizing costs of hardware and network access. The module is designed for volume production and is intended for OEMs to embed into end equipment designs.

## 1.3 Block Diagram



## 2. Technical Specifications

### 2.1 Electrical Specifications

#### 2.1.1 Absolute Maximum Ratings

| Parameter             | Signal | Maximum Rating |
|-----------------------|--------|----------------|
| Main Power Supply     | VCC    | 5.1V           |
| I/O Voltage Reference | VREF   | 5.5V           |

#### 2.1.2 Recommended Ratings & Module Pin out

##### 2.1.2.1 Connectors J1 and J2

| Pin | Name    | Direction | Description   | Min                     | Typical | Max                               | If not used         |
|-----|---------|-----------|---|-------------------------|---------|-----------------------------------|---------------------|
| 1   | VCC     | Input     | Main Power supply   | 3.1V                    | 3.8V    | 4.5V                              | Must be implemented |
| 2   | DOUT    | Output    | UART data out, I/O level tied to VREF   | VOL:<br>GND to<br>0.55V |         | VOH:<br>VREF x<br>0.67 to<br>VREF | Must be implemented |
| 3   | DIN     | Input     | UART data in, I/O level tied to VREF  | VIL:<br>GND to<br>0.15V |         | VIH:<br>VREF-0.4V<br>to VREF      | Must be implemented |
| 4   | GND     | Input     | Ground Pin  |                         | 0       |                                   | Must be implemented |
| 5   | RESET_N | Input     | Controls RESET_N input on modem, tie low for a minimum of 1uS and released to activate. Internally pulled up to VCC. Drive with open collector output. Assert only in an emergency as the module will not gracefully exit the cellular network when asserted. |                         | VREF    |                                   | No connection       |
| 6   | VUSB    | Input     | Supply for USB interface  | 4.5V                    | 5V      | 5.5V                              | No connection       |
| 7   | USB_D+  | I/O       | USB differential Data + signal  |                         |         |                                   | No connection       |
| 8   | USB_D-  | I/O       | USB differential Data - signal  |                         |         |                                   | No connection       |
| 9   | WAKE    | Input     | Wakes up the modem from low power modes. Default configuration for wakeup is a low to high transition on this line  | VIL:<br>GND to<br>0.15V |         | VIH:<br>VREF-0.4V<br>to VREF      | Tie to GND          |
| 10  | GND     | Input     | Ground Pin  |                         | 0       |                                   | Must be implemented |
| 11  | GND     | Input     | Ground Pin  |                         | 0       |                                   | Must be implemented |
| 12  | CTS     | Output    | Modem Clear to Send hardware flow control output  | VOL:<br>GND to<br>0.55V |         | VOH:<br>VREF x<br>0.67 to<br>VREF | No connection       |

|    |               |        |  |                         |                 |                                   |                      |
|----|---------------|--------|--|-------------------------|-----------------|-----------------------------------|----------------------|
| 13 | ON_STAT<br>US | Output | Signal drives high indicating the modem is on and ready for commands. (It can be idle, or in sleep mode)   | 0                       |                 | 1.8V                              | No connection        |
| 14 | VREF          | Input  | Voltage reference for off board I/O signals. This signal drives the input voltage side of an onboard buffer which converts all external I/O voltage from VREF range to 1.8V range to drive the onboard modem module.                     | 1.65V                   | 1.8V or<br>3.3V | 5.5V                              | Must be implemented  |
| 15 | GND           | Input  | Ground Pin   |                         | 0               |                                   | Must be implemented  |
| 16 | RTS           | Input  | Modem Request to Send hardware flow control input  | VIL:<br>GND to<br>0.15V |                 | VIH:<br>VREF-0.4V<br>to VREF      | Tie to GND           |
| 17 | GPS_RX        | Input  | UART GPS data in, I/O level tied to VREF   | VIL:<br>GND to<br>0.15V |                 | VIH:<br>VREF-0.4V<br>to VREF      | Must be implemented  |
| 18 | GPS_TX        | Output | UART GPS data out, I/O level tied to VREF  | VOL:<br>GND to<br>0.55V |                 | VOH:<br>VREF x<br>0.67 to<br>VREF | Must be implemented  |
| 19 | RING          | Output | Signal wakes up a host processor when there is incoming traffic on the network   | VOL:<br>GND to<br>0.55V |                 | VOH:<br>VREF x<br>0.67 to<br>VREF | Must be implemented  |
| 20 | ON_OFF        | Input  | Modem PWR_ON is active low Internally pulled up to internal I/O rail with resistor. Do not use any external pull ups. <b>Note:</b> If you want modem to turn on automatically when power is applied, permanently tie this signal to GND. | 0                       |                 | 1.8V                              | Must be implemented. |

### 2.1.2.2 Connectors J3, X1, X2

| Connector Designator | Description                 | Connector Location    |
|----------------------|-----------------------------|-----------------------|
| J3                   | Micro SIM Connector         | Bottom Side of Module |
| X1                   | Primary Antenna Connection  | Topside of Module     |
| X2                   | GPS/GNSS Antenna Connection | Topside of Module     |



## 2.2 Mechanical Specifications

### 2.2.1 Mechanical Characteristics

| Parameter  | Typical              | Unit   |
|--|----------------------|--------|
| Dimensions (excluding pin height, for solder to board applications)          | 29.0 x 33.60 x 6.63  | mm     |
| Dimensions (including pin height, for board to board connector applications) | 29.0 x 33.60 x 10.73 | mm     |
| Weight   | 0.3                  | oz     |
| Connector Insertion/Removal  | hundreds             | Cycles |

### 2.2.2 Mating Connectors

| Connector Designator | Manufacture | Populated on Module | Recommended Mate                        | Mate Manufacture            |
|----------------------|-------------|---------------------|---|-----------------------------|
| J1, J2               | 3M          | 951110-2530-AR-PR   | 950510-6102-AR                          | 3M                          |
|                      |             |                     | Acceptable alternate:<br>NPPN101BFCN-RC | Sullins Connector Solutions |
| J3                   | Molex       | 786463001           | Micro SIM Card                          | Micro SIM Card              |
| X1, X2               | Hirose      | U.FL-R-SMT(10)      | CAB.011                                 | Taoglas                     |

### 2.2.3 Device Placement

⚠ Make sure the Skywire™ is installed in the correct orientation; failure to do so will damage the device and void the warranty.

## 2.3 Environmental Specifications

| Parameter             | Min | Typical | Max | Unit | Note           |
|-----------------------|-----|---------|-----|------|----------------|
| Operating Temperature | -30 | 25      | +60 | °C   |                |
| Extended Temperature* | -40 | 25      | +85 | °C   |                |
| Operating Humidity    | 20  |         | 90  | %    | Non-condensing |

\* Transmit power limited during Extended Temperature operation

## 3. Important Design Considerations

### 3.1 PWR\_ON Signal

To conserve power, the Skywire modem does not automatically start up when power is applied. The baseboard design must supply a means to assert the PWR\_ON signal low. The signal is level sensitive. After asserting the PWR\_ON signal, software must wait for device to boot up before attempting to communicate with the Skywire Modem. To make module automatically start when power is applied, tie PWR\_ON signal to GND permanently.

### 3.2 Power Supply Requirements

The module will regularly consume high amounts of current on the Main Power Supply (VCC), up to 500mA during active transmits and receives. The baseboard power supply should be designed to support peak currents up to 1 Amp. A 100uF capacitor should be placed near the VCC pin on the module to ensure ample energy is available, with a low inductance path to the VCC pin. For example power supply designs, there are multiple references available. See the NimbeLink Skywire™ Development Kit schematic for a switching regulator example.

### 3.3 Serial Communications

The Skywire Modem can communicate over UART for AT commands and PPP interface. The USB interface is only provided as a path for firmware update and is not available for issuing AT commands. There is a second UART available for communication with GPS/GNSS.

### 3.4 LED

TBD

### 3.5 GPIO Control

TBD

## 4. Mounting Guidelines

The Skywire™ embedded cellular modem supports multiple connection methods, the two primary methods are board to board connectors and soldering directly to the baseboard.

## 4.1 Board to Board connectors approach

The XBEE form factor calls for two, 10 pin, 2mm pitch female receptacles.

There are many connector manufacturers that can be used; below is one readily available product:




Manufacturer: 3M

Alternate: Sullins Connector Solutions


Part Number: 950510-6102-AR

Alternate P/N: NPPN101BFCN-RC

Typical part drawing and footprint information:




PCB Layout



## 4.2 Solder to Board connection approach

The module can be soldered directly to a PCB. The PCB should be designed with two rows of ten, 0.8mm plated thru holes spaced 2mm apart. The two rows should be 22mm apart. See drawing for recommended footprint. Measurements are in millimeters. U.FL locations are marked with circles, X1 and X2 on top side of board, J3 is Micro SIM card slot on bottom side of board.



## 5. Antenna Considerations

### 5.1 Primary Antenna Requirements

Designers should review latest VZM20Q Hardware User Guide to ensure the information is up to date.

| PRIMARY ANTENNA REQUIREMENTS |   |
|------------------------------|---|
| Frequency Range              | Depending on the frequency bands provided by the network operator, the customer shall use the most suitable antenna for those bands |
| Bandwidth                    | LTE B4(1700): 445MHz<br>LTE B13(700c): 41MHz  |
| Impedance                    | 50 ohm  |
| Input Power                  | >24dB   |

## 5.2 Recommended Antennas

| Type             | Manufacturer         | Part Number                |
|------------------|----------------------|----------------------------|
| Primary Cellular | Taoglas <sup>1</sup> | <a href="#">TG.30.8113</a> |
|                  |                      |                            |

**Note 1:** U.FL to SMA adapter required.

For applications not using the recommended antennas developers will need to ensure that the selected antenna(s) must meet the following gain requirements:

| Frequency     | Max Gain (dBi) |
|---------------|----------------|
| 700 MHz Band  | TBD            |
| 1700 MHz Band | TBD            |

## 6. Certifications

### 6.1 Carrier Specific

NL-SW-LTE-SVZM

Verizon OD Certified

### 6.2 Geography Specific

Federal Communications Commission (FCC47) part 22, 24

Complies with FCC47 Part 15 Class B Radiated and Conducted Emissions

## 7. Federal Regulatory Licensing

### 7.1 Export Control Classification Number (ECCN)

ECCNs are five character alpha-numeric designations used on the Commerce Control List (CCL) to identify dual-use items for export control purposes. An ECCN categorizes items based on the nature of the product, i.e. type of commodity, software, or technology and its respective technical parameters.

NL-SW-LTE-SVZM (and all Skywire Modems): 5A992.c

## 7.2 Harmonized Tariff Schedule Code

HTS Code: 8517.62.0010

# 8. End Product Labeling Requirements

Device Uses Approved Radio: NL-SW-LTE-SVZM

Contains FCC ID:TBD and IC ID: TBD

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interferences, and (2) this device must accept any interference received, including interference that may cause undesired operation.