# mail

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



# Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832 Email & Skype: info@chipsmall.com Web: www.chipsmall.com Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China





# **Document Wiki**

## WizFi310 Shield



#### Overview

This document describes the contents of WizFi310 Shield. WizFi310 Shield is a Shield with built-in WizFi310 WiFi module of WIZnet.

Because WizFi310 Shield is Pin Compatible with Arduino, it can be used in Arduino, and it can be used in Arduino Pin Compatible development platform. It is also used on the WIZWiki Platform.

In addition, an temprature/humidity sensor and an CDS sensor are built in.

#### Features

#### WizFi310

- Single band 2.4GHz IEEE 802.11b/g/n
- 72.2Mbps receive PHY rate and 72.2Mbps transmit PHY rate using 20MHz bandwidth
- 150Mbps receive PHY rate and 150Mbps transmit PHY rate using 40MHz bandwidth
- Low power consumption & excellent power management performance extend battery life.
- Easy for integration into mobile and handheld device with flexible system configuration.
- Serial Interface : UART
- UART Max Baud : 921600 bps

- Soft AP
  - Enough memory retention
  - Wi-Fi Security (WEP, WPA/WPA2PSK)
  - L2 Switching
- OTA(Over The Air F/W Upgrading)

#### ETC

- Built-in UART to USB chip
  - CP2104-GM
  - Micro USB B Type Connector
- UART Selector
  - J1, J2, J3
  - 2.54mm Pin Header
- Built-in Sensors
  - Temprature/Humidity sensor : DHT11
  - CDS Sensor : GL5537
- Built-in Tact Switchs
  - System Reset Switch: SW4
  - WiFi Reset Switch: SW3
  - WiFi Function Switch: SW2
- Built-in LED Indicators
  - D13 LED
  - WizFi310 MODE/WiFi LED
  - WizFi310 RXD/TXD LED
- Built-in Level Shifters
  - The voltage of the RXD/TXD signal changes according to the main board platform voltage.
- Built-in DIP Switchs
  - UART RXD/TXD Selector : SW1
  - Digital/Analog PIN Selector : SW5
  - UART RTS/CTS Selector : SW6

#### WizFi310 Shield Callout & Pinmap



http://wizwiki.net/wiki/doku.php?id=osh:wizfi310\_shield:start



### **H/W** Configurations

#### **DIP** Switch Configurations

#### SW1 - RXD/TXD Selector DIP Switch

- **ON** : RXD/TXD of WizFi310 connect to USB
  - It is possible to communicate with WizFi310 using USB.
- **OFF** : RXD/TXD of WizFi310 connect to J1 and J3
  - UART Pin Header, Arduino PIN
  - If the jumper cap is not attached to the UART pin header, it will not be connected to the arduino pin.

Pin 1 : RXD Pin 2 : TXD

#### SW6 - RTS/CTS Selector DIP Switch

- **ON** : RTS/CTS of WizFi310 connect to D6 and D7
- **OFF** : RTS/CTS of WizFi310 not connect to anywhere
- If the state of SW5 is ON, D6 and D7 of UART jumper can not be used.

Pin 1 : RTS - D6 Pin 2 : CTS - D7

#### SW5 - Aruduino Pin Selector DIP Switch

- **ON** : Connect to Arduino Pin
- **OFF** : Not connect to anywhere

Pin 1 : A0 - CDS
Pin 2 : D14 - DHT11
Pin 3 : D9 - WizFi310 Reset Pin

#### **UART Selector Jumper**

- It can be used when SW2 is OFF.
- You have to specify the desired Arduino pin, use Jumper Cap to connect J1 to J2, and J3 to J2.
  Default : J1(RXD) D1, J3(TXD) D0
- If the state of SW5 is ON, D6 and D7 of UART jumper can not be used.

J1 : RXD J2 : D0 ~ D8 J3 : TXD

#### **Getting Started**

#### **Technical Refernce**

#### Datasheet

• WizFi310 Datasheet

#### Schematic

- WizFi310 Shield Schematic(Altium)
- WizFi310 Shield Schematic(PDF)

#### Partlist

• WizFi310 Shield Partlist

#### ETC

#### Serial Port Driver

<u>CP210x USB to UART Bridge VCP Drivers [http://www.silabs.com/products/development-tools/software/usb-to-uart-bridge-vcp-drivers]</u>

#### Sensor Datasheets

٠

• DHT11 Humidity & Temperature Sensor Datasheet [http://www.micropik.com/PDF/dht11.pdf]

.

• GL5537 Datasheet [https://www.kth.se/social/files/54ef17dbf27654753f437c56/GL5537.pdf]