



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of “Quality Parts,Customers Priority,Honest Operation,and Considerate Service”,our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



## Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China





# Z8611600ZEM

## ICEBOX™ FAMILY Z8®

### IN-CIRCUIT EMULATOR -116

#### HARDWARE FEATURES

- Supported Devices:

Package	Emulation	Programming	Notes
18-Pin DIP	Z86116	N/A	
18-Pin SOIC	Z86116*	N/A	[1]*

- Real-Time Emulation
- ICEBOX Emulator Provides In-Circuit Program Debug Emulation
- Z8 Graphical User Interface (GUI) Emulator Software

- Windows-Based User Interface
- RS-232C Connector
- ICE Pod Connector for Emulation
- HP-16500 Logic Analysis System Interface Connector

**\*Notes:**

[1] With optional, separately purchased adapter available from:

Emulation Technology, Inc.  
Telephone (408) 982-0660  
FAX (408) 982-0664  
Part # AS-DIP.3-020-S003-1

#### GENERAL DESCRIPTION

The 116 Emulator (Z8611600ZEM) is a member of Zilog's ICEBOX product family of in-circuit emulators providing support for those Z8 microcontroller devices listed in the preceding section.

Zilog's in-circuit emulators are interactive, Windows-based development tools, providing a real-time environment for emulation and debugging.

The emulator provides essential timing and I/O circuitry to simplify user emulation of the prototype hardware and software product.

Data entering and program debugging are performed by the monitor ROM and the host package, which communicates through RS-232C serial interface. The user program can be downloaded directly from the host computer through the RS-232C connector. User code may be executed through debugging commands in the monitor.

The Z8611600ZEM emulator can be connected to a serial port (COM1, COM2, COM3, and COM4) of the host computer and uses Graphical User Interface (GUI) software.

#### SPECIFICATIONS

##### Operating Conditions

- Operating Temperature: 20°C, ±10°C
- Supply Voltage: +5.0 VDC, ± 5%
- Minimum Emulation Speed: 200 kHz
- Maximum Emulation Speed: 12 MHz

##### Power Requirements

- +5.0 VDC @ 1.0A

##### Dimensions

- Width: 6.25 in. (15.8 cm)
- Length: 9.5 in. (24.1 cm)
- Height: 2.5 in. (6.35 cm)

##### Serial Interface

- RS-232C @ 9600, 19200 (default), 28800, or 57600 Baud

## HOST COMPUTER

### Minimum Requirements

IBM PC (or 100-percent compatible) 386-based machine  
33 MHz  
4 MB RAM  
VGA Video Adapter  
Hard Disk Drive (1 MB free space)  
3.5-inch, High-Density (HD) Floppy Disk Drive  
RS-232C COM port  
Mouse or Pointing Device  
Microsoft Windows 3.1

The following changes to the Minimum Requirements are recommended for increased performance:

486- or Pentium-based machine  
66 MHz (or faster)  
8 MB of RAM (or more)  
SVGA Video Adapter  
Color Monitor  
Printer

## KIT CONTENTS

### Z86116 Emulator

- Emulation Base Board includes:
  - CMOS
  - 8K x 8 EPROM (Programmed with Debug Monitor)
  - 32K x 8 Static RAM
  - Three 64K x 4 Static RAM
  - RS-232C Interface
  - Reset Switch
- Z86116 Emulation Daughterboard
  - 20 MHz CMOS Z86C5020GSE ICE Chip
  - 28-Pin DIP Zero Insertion Force (ZIF)
    - PN Data EPROM Socket
  - 40-Pin Target Connector
  - 100-Pin HP-16500 Logic Analyzer Interface
    - Connector
  - Reset Switch

### Cables/Pods

Power Cable with Banana Plugs  
DB25 RS-232C Cable  
18-Pin DIP Target Pod

### Host Software

Z8® GUI Emulator Software  
ZASM Cross-Assembler/MOBBJ Object File Utilities

## Documentation

Z86116 ICEBOX User's Manual  
Z8 Cross-Assembler User's Guide  
Universal Object File Utilities (MOBBJ) User's Guide  
Registration Card  
Product Information

## LIMITATIONS

1. Changing drives in file download and load symbol dialog boxes is not anticipated by the GUI. Typing in the filename in a directory other than shown in "Path:" will result in "File not found". Changing the drive using the mouse is the workaround.
2. The initial blue Zilog screen will be distorted by other active windows. This only affects the appearance, not functionality, of the GUI.
3. Switching ICEBOXes without quitting the GUI is not supported.
4. The maximum symbols that can be loaded is 32768, provided that there is enough system resource (memory).
5. The ICEBOX breakpoint hardware does not distinguish between instruction and data fetches. When a breakpoint in the GUI is set, the breakpoint hardware triggers when the addresses match for either code or data fetches.

Example:

```
000C      SRP      #%0
000E      LD       R4, #%0016
0010      LD       R5, @R4
0012      NOP
0013      JP       %000C
0016      NOP
```

Setting the breakpoint at %0016 and click GO.

**Result:** The code will break and stop at %0012.

**Note:** This will not happen when Animate Mode is on because the GUI is not using the hardware breakpoints when in Animate Mode.

## LIMITATIONS (Continued)

6. If the emulator is running a user code at full speed and the port window is opened: Switching to another application or minimizing the GUI (then restoring) will result in the following ICEBOX Communications Error message: "Emulator rejected command: target program is executing." This message may need to be cleared several times (as many as seven) before the GUI returns to normal operation.

**Workaround:** Always close the port window before leaving the GUI.

7. Clicking on the HALT button does not always halt the ICEBOX execution. If the application goes into Stop Mode or Halt Mode, the only way to halt the emulator execution is by doing a Stop-Mode or Halt-Mode Recovery (as defined by the user program). You may also reset the application using the RESET button; however, this will reset the whole ICEBOX.
8. Single-stepping into the Halt instruction will cause an ICEBOX "Fatal Error" message to be displayed on the screen. The Ice Chip must be reset, either by /Reset Pin on the target board or by resetting the whole ICEBOX by pressing the RESET button at back of emulator.
9. Do not put breakpoint at address after Stop instruction. This will cause program counter to continue at that location after a Stop-Mode Recovery.
10. The Emulator does not operate at 32 kHz frequency. The low-power 32 kHz oscillator cannot be selected in Emulation Mode; however, it can be selected in Stand-Alone Mode.
11. The ICEBOX does not support any OTP programming.
12. RC oscillator emulation is not supported.
13. The emulator uses the C50 ICE Chip; therefore, port 1 cannot be configured to Low EMI mode. (Bit 4 in PCON registers must be set to logic "1".)

**Note:** This condition is not present with the actual emulated device.

## PRECAUTION LIST

### All Devices

1. The GUI comes up as "C50" in the window caption and uses Z8EM\_C50.BSC as the firmware.
2. GUI software versions prior to 3.00 are incompatible with hardware containing BOOTROM 3.00. The GUI software may still boot, but will fail at some later point of the session.
3. When device serialization is enabled in the OTP dialog, the GUI copies the current serial number to code memory immediately before performing a VERIFY operation. If this behavior is undesirable, then device serialization must be disabled prior to invoking the VERIFY operation.
4. The status color bar in OTP dialog box will be cleared in the area where a new window opens on top of it.
5. For 386 PCs, set the baud rate to 19.2K or less because Windows' communication driver does not guarantee "reliable" operation at more than 9600 baud. Selecting a high baud rate on some slower 386 machines may crash the Windows environment.
6. Do not press hardware reset when the ICEBOX is in OTP programming. If reset is pressed while the GUI is doing OTP programming, close the OTP dialog window and reopen it to reload the information back to the hardware.

**Note:** Although the Command Status shows "Processing" after the GUI reestablishes the communication link when Retry was selected, the ICEBOX is actually sitting idle.)

**PRECAUTION LIST (Continued)**

7. All Z8® control registers are write only unless stated otherwise.
8. Power Supply ramp-up/rise time must be such that when minimum Power-On Reset (POR) time ( $T_{POR}$ ) expires, then the  $V_{CC}$  must be in the supported specified operating range of the device.
9. Check the  $T_{POR}$  and  $T_{WDT}$  specifications of the device that you wish to emulate. The actual specification may differ from the ICE chip specifications.
10. The PCON Register reserved bits for the 116 emulator must be set to "1".
11. The general-purpose registers after POR or at initial emulator use will be different than the actual device. The emulator self test will always leave the same values in the general-purpose registers, while the real device will have a random/undefined value in the general-purpose registers.
12. The register %F8 (PO1M register) bits D4 and D3 must be set to state "0" and bit D2 must be set to state "1".
13. Watch-Dog Timer (WDT) running in Stop Mode is not supported.
14. For emulation of the Z86116, select "Z86C06/E06" from the Z8 Microcontroller List Box in the Configuration Dialog Box.
15. The Emulator cannot be operated while performing ESD/EMI testing on the target board.

---

© 1995 by Zilog, Inc. All rights reserved. No part of this document may be copied or reproduced in any form or by any means without the prior written consent of Zilog, Inc. The information in this document is subject to change without notice. Devices sold by Zilog, Inc. are covered by warranty and patent indemnification provisions appearing in Zilog, Inc. Terms and Conditions of Sale only. Zilog, Inc. makes no warranty, express, statutory, implied or by description, regarding the information set forth herein or regarding the freedom of the described devices from intellectual property infringement. Zilog, Inc. makes no warranty of merchantability or fitness for any purpose. Zilog, Inc. shall not be responsible for any errors that may appear in this document. Zilog, Inc. makes no commitment to update or keep current the information contained in this document.

Zilog's products are not authorized for use as critical components in life support devices or systems unless a specific written agreement pertaining to such intended use is executed between the customer and Zilog prior to use. Life support devices or systems are those which are intended for surgical implantation into the body, or which sustains life whose failure to perform, when properly used in accordance with instructions for use provided in the labeling, can be reasonably expected to result in significant injury to the user.

Zilog, Inc. 210 East Hacienda Ave.  
Campbell, CA 95008-6600  
Telephone (408) 370-8000  
Telex 910-338-7621  
FAX 408 370-8056  
Internet: <http://www.zilog.com>