



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of “Quality Parts,Customers Priority,Honest Operation,and Considerate Service”,our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China





395 Handheld Refractometer

APPLICATIONS

HVACR:

- Radiant Heat Line Fluids For walkways, garages, closed loop systems, and in-floor systems

AUTOMOTIVE:

- Engine coolants
- Battery fluid condition
- Recreational vehicles

PLUMBING:

- Battery condition of sump pump battery back up systems

Turn over for technical information and accessory part numbers.

The Value Leader™

The 395 Handheld Refractometer

is designed to give an accurate reading regarding the freezing point of fluids used in hydronic heating systems. It is quick and easy to use. Place a drop of fluid on the prism, close the plastic lid, and look through the eye piece. Where the blue and white colors meet indicates the freezing point of the coolants or the state of charge for batteries.



FEATURES

- Use to test the following liquids:
 - Propylene glycol
 - Ethylene glycol
 - Battery fluid
- Does not degrade like litmus paper; Allows for more accurate readings
- Easy viewing: cushioned eye piece adjusts to most visual needs.
- Smooth focus adjustment for reliable repeat testing

The above information is provided to the best of TPI's knowledge and is not guaranteed. The above information is subject to change at any time.

visit us at www.tpi-thevalueleader.com



395 Handheld Refractometer

395 SPECIFICATIONS

TECHNICAL SPECIFICATIONS AND ACCESSORIES

- Digital Multimeters
- Clamp Meters
- Hand-held Oscilloscopes
- Refrigerant & Combustible Gas Leak Detectors
- Temperature Testers
- BNC Coax Cable Connectors
- Test Leads
- Accessories

Test Products International, Inc.
 Headquarters:
 9615 SW Allen Blvd.
 Beaverton, OR 97005
 USA
 503-520-9197
 Fax: 503-520-1225
 email:
 info@tpi-thevalueleader.com

Test Products International, Ltd.
 342 Bronte St. South
 Unit 9
 Milton, Ontario L9T
 5B7
 Canada
 905-693-8558
 Fax: 905-693-0888
 email:
 info@tpicanada.com

Test Products International UK Ltd.
 Longley House, East Park
 Crawley, West Sussex
 RH10 6AP England
 Tel: +44 (0)1293 561212
 Fax: +44 (0)1293813465
 contactus@tpieurope.com

Calibration	Field calibrateable using distilled water
Liquid and Range	Propylene Glycol: -60°F to 20°F (-50°C to -5°C) Ethylene Glycol: -60°F to 20°F (-50°C to -5°C) Battery Fluid: 1.10 to 1.4 pH with recharge, fair, and good ratings
Dimensions	6 3/8" x 1 1/4", 7/8" tube diameter
Weight	.6lbs (.286kg)
Standard Accessories	Refractometer Calibration screwdriver Eyedropper Distilled water Protective plastic case

TDS / Salt Meter 390



- Test condensate water in cooling tower and humidifier reservoir applications to prevent bacterial growth
- Test TDS levels in make-up water to prevent scale formation, corrosion, and embrittlement
- Reduce water and chemical consumption in boilers and cooling towers
- Determine when to perform blowdown and add make-up water
- Prevent contamination and corrosion of control valves, heat exchangers, and steam traps
- Verify automated TDS controllers are functioning properly
- Prevent low quality wet steam generation in boilers due to foaming caused by high TDS levels

Distributed By:



To learn about the entire line of TPI products visit:

www.tpi-thevalueleader.com

L 395-0107
 Copyright © 2007 Test Products International, Inc.