# imall

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



# Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832 Email & Skype: info@chipsmall.com Web: www.chipsmall.com Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China




### CONTROLS



## CONTROLS




- **LED Relay Indicator** •
- **Three Styles**
- **Pump Up Control**
- **4.7** k $\Omega$  to **100** k $\Omega$  Sensitivity
- **10 Amp SPDT Relay**



#### SPECIFICATIONS:

Input Power	:15% (50/60 Hz)
OutputSPDT Relay	
Contact materialAgCdO	
Maximum loading10A AC resistive	8A DC resistive
Maximum switching voltage250 VAC	250 VDC
Maximum power rating	80 W
Electrical life	
Mechanical life	
Probe isolationElectrodes: 2000 VAC	
Probe sensitivity	
Probe voltage	
Probe current	
<b>Operating temperature</b> +14°F to +140°F	-10°C to +60°C
Weight7 oz. (200g)	

Note: The cable for probes (max 300ft) should be run in separate conduit. A shielded cable is recommended.



Products and specifications subject to change without notice.




Control of conductive liquids (tap water, sea water, sewage, chemical solutions, coffee, ice cream, etc.)

The relay is energized when the level falls below the low level probe. It de-energizes when the high level probe is reached. The NRU will also control a single level. In this case, a single probe is used and the relay operates when the probe is not immersed. The Max terminal is connected to common with a jumper.

In either case, a common electrode is needed if the container is non-conductive.

#### WIRING DIAGRAM:




Consult factory for application assistance.

DIMENSIONS:

2.76" (70mm) 15 **-**-**-**-000 1.77" 2.72" (69mm) (45mm) Q ٠ī 12 A2 94 \* .08 " 94 1.10" .14" .43" (2mm)(24mm) (24mm) (28mm) (3.5mm) (11mm)2.95\* 1.89" (48mm) (75mm)

D - DIN-Rail

L & P - Sockets



Products and specifications subject to change without notice. Consult factory for application assistance.