

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



### Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China







## SEIZAIKEN SILVER OXIDE BATTERY


# SR731SW 329

**36mAh** Mercury Free

## **1. Specifications**


Model		SR731SW
Nominal Voltage		1.55V
Nominal Capacity		36mAh [cov:1.20V]
Standard Discharge Current		50μΑ
Operating Temperature Range		-10°C~+60°C
Weight		0.56g
Dimensions	Diameter	7.90mm
	Height	3.10mm

## 2. Dimensions




### 3. Characteristics

#### Discharge Characteristics




Measurement conditions: Temp: 23 deg C Load: 20kΩ

#### ◆ Shelf Life



Measurement conditions:Temp:23 deg C Storage conditions: 60 deg C Dry Load: $20k\Omega$ 


**♦** Low Temperature Characteristics



Measurement conditions:

Temp:-10 deg C Load:2kΩ 7.8msec pulse

#### ◆ Anti-leakage Performance



Storage conditions:

Temp:45 deg C Humidity:93% R.H.

Seiko Instruments Inc. Micro Energy Division 8, Nakase 1-chome, Mihama-ku, Chiba-shi, Chiba 261-8507 Japan Tel:(+81) 43-211-1735 FAX: (+81)43-211-8034 www.sii-me.com



<sup>\*</sup>Data is for reference only and is not guaranteed.

<sup>\*\*</sup>Changes may be made at any time to the information here without prior notice.

# Precautions for Your Safety



For using SII Silver Oxide batteries, please follow the following precautions.



- Do not heat, disassemble nor dispose of in fire
   Doing so damages the insulation materials and may cause fire,
   heat generation, leakage or bursting.
- · Do not short.

If the (+) and (-) come into contact with metal materials, shortcircuit occurs. As a result, fire, heat generation, leakage or bursting may occur.

Keep batteries out of children's reach.
 It is dangerous that children swallow the battery.
 When you design mechanical hardware around the battery, please

fix the battery firmly in order to prevent children from removing it. When you store the batteries, please keep the batteries out of children's reach.

If a battery is swallowed, consult a physician immediately.

- If leaked liquid, alkaline, get in the eyes, do not rub them, wash them with clean water and consult a physician immediately.
- If leaked liquid, alkaline, stick to clothing, for protecting from irritation, wash them with clean water immediately.



- Do not reverse placement of (+) and (-)
- . Do not solder directly to the battery
- Do not use new and used batteries together. Do not use different types of batteries together.
- Do not charge.
- Do not use nor leave the batteries in direct sunlight nor in high-temperature areas.
- Keep batteries away from direct sunlight, high temperature and humidity.
- Avoid letting battery contact water.

- Make sure to insert batteries without having (+) and (-) come in contact with metal parts of equipment.
- Read the equipment instruction manual and precautions carefully before using. Some usage or types of equipment do not suit the specifications or performance of these batteries.
- Remove batteries from the equipment, if finished using. Do not leave batteries connecting with equipment after using.
- In case of disposal, insulate between (+) and (-) of battery by an insulating material.