

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China










T2 Terminator Tooling Specification Sheet Part No. 63910-5300



FEATURES


- It is ideally suited for mid-volume bench operations
- This terminator can be installed in the TM42 and the TM40 press or Base Unit adapter for 3BF press
- Quick punch removal with the push of a button for fast and easy tooling change
- Track adjustment capabilities in the T2 Terminators for improved control of the bell mouth size and cutoff tablength
- T2 Terminator has standardized tooling with the Molex FineAdjust Applicator which will reduce your inventory requirements

SCOPE

Products: 3.96mm (.156") Pitch SPOX ™ Crimp Terminal, 18-24 AWG.

Terminal Series No.	Terminal Order No.		Wire Size		Insulation Diameter		Strip Length	
Terriniai Series No.			AWG	mm²	mm	ln.	mm	ln.
5194	08-70-1031	39-00-0416	18-24	0.80-0.20	1.30-3.00	.051118	3.00-3.50	.118138
	39-00-0409	39-00-0021						

DEFINITION OF TERMS



The above terminal drawing is a generic terminal representation. It is not an image of a terminal listed in the scope.

Doc No: ATS-639105300 Release Date: 08-17-07 **UNCONTROLLED COPY** Page 1 of 6 Revision: A Revision Date: 08-17-07

CRIMP SPECIFICATION

	Terminal Series No.	Bell r	nouth	Cut-off Tab	Maximum	n Conductor Brush	
	reminiai Senes No.	mm	ln.	mm	ln.	mm	ln.
	5194	0.20-0.70	.008028	0.40	.016	0.00-1.00	.000039

	Bend up Bend down		Twist Ro	Roll	Punch Width mm (Ref)			Seam	
Terminal Series No.			I WISL HOII		Conductor		Insulation		Seam shall not be open
	Deg	gree	Deg	gree	mm	In	mm	In	and no wire allowed out
5194	6	0	3	8	1.60	.063	2.80	.110	of the crimping area

After crimping, the conductor profile should measure the following.

Terminal Series No.	Wire Size			uctor Height	Pull Force Minimum		
	AWG	mm ²	mm .	Ĭn.	N	Lb.	
	18	0.80	1.10-1.20	.043047	88.1	19.80	
5194	20	0.50	1.07-1.17	.042046	58.7	13.20	
3184	22	0.35	0.96-1.06	.038042	39.1	8.80	
	24	0.20	0.90-1.00	.035039	29.4	6.60	

Pull Force should be measured with no influence from the insulation crimp.

The above specifications are guidelines to an optimum crimp.

Doc No: ATS-639105300 Release Date: 08-17-07 Revision: A Revision Date: 08-17-07


PARTS LIST

T2 Terminator 63910-5300									
Item	Order No	3 1 3 1							
Perishable Tooling									
	63910-5370	63910-5370	Tool Kit (All "Y" Items)	REF					
1	63444-1605	63444-1605	Conductor Punch	1 Y					
2	63445-1641	63445-1641	Conductor Anvil	1 Y					
3	63446-2827	63446-2827	Insulation Punch	1 Y					
4	63445-2835	63445-2835	Insulation Anvil	1 Y					
5	63443-0002	63443-0002	Front Cut-Off Plunger	1 Y					
6	63443-0012	63443-0012	Front Plunger Retainer	1 Y					
		Other Componen	ts (REF 105350)						
7	11-18-4083	60707-8	Feed Guide	1					
8	11-24-1067	4996-4	Cut-Off Plunger Spring	1					
9	11-40-4039	8302-5	Plunger Striker	1					
10	63443-0009	63443-0009	Front Scrap Chute	1					
11	63443-0024	63443-0024	Key	1					
12	63443-0085	63443-0085 Wire Stop L-Bracket		1					
13	63443-0090	63443-0090	Wire Stop	1					
14	63443-1716	63443-1716 18.60mm Height Spa		1					
15	63443-2216	63443-2216	16.00mm Coarse Spacer	1					
16	63443-2302	63443-2302	3.10mm Fine Spacer	1					
17	63443-6003 63443-6003		Rear Cover	1					
		Frai	me						
18	63800-8500	63800-8500	T2 Terminator	1					
		Hard	ware						
19	N/A	N/A	M3 by 6 Long SHCS	2**					
20	N/A	N/A	M3 by 6 Long FHCS	1**					
21	N/A	N/A	M4 by 6 Long SHCS	2**					
22	N/A	N/A	M4 by 12 Long BHCS	2**					
23	N/A	N/A	M4 by 14 Long SHCS	2**					
24	N/A	N/A	M4 by 50 Long SHCS	2**					
25	N/A	N/A	M5 by 12 Long SHCS	1**					
26	26 N/A N/A		#10-32 by 3/8"Long BHCS	1**					
** Available from an industrial supply company such as MSC (1-800-645-7270).									

Doc No: ATS-639105300 Release Date: 08-17-07

Revision: A

Release Date: 08-17-07 **UNCONTROLLED COPY**Revision Date: 08-17-07



Doc No: ATS-639105300 Revision: A Release Date: 08-17-07 Revision Date: 08-17-07

NOTES

Depending on the press vintage a feed finger assembly is supplied with the T2 Terminator.

- 1. To remove the existing feed finger assembly loosens the M4 x 10 mm set screw in the feed lever.
- 2. Select T2 Feed finger assembly from Terminator box.
- 3. Insert a screwdriver into the slot behind the feed lever and force the feed arm spring to the right.
- 4. Slide the T2 feed finger shaft for TM42 (11-40-5307) or (11-40-0123) for TM40 /Base Unit into the feed lever and to the left of the feed arm spring.
- 5. Release the feed arm spring.
- 6. Position feed finger for selected product. (Refer to Figure 5.1 in the T2 Manual).




Figure 2

UNCONTROLLED COPY Doc No: ATS-639105300 Release Date: 08-17-07 Page 5 of 6 Revision Date: 08-17-07

Revision: A

NOTES

- 1. Molex recommends an extra perishable tooling kit be maintained at your facility.
- 2. Verify tooling alignment by manually cycling the press before crimping under power. Check that all screws are tight.
- 3. Slugs, Terminals, Dirt and Oil should be kept clear of work area.
- 4. This Terminator should be only used in a Molex TM42, TM40, or 3BF Press with a Base Unit adaptor.
- 5. Wear safety glasses at all times.
- 6. For recommended maintenance refer to the TM40, TM42 Manual.

CAUTION: To prevent injury never operate this Terminator without the guards supplied with the press or in place. Reference the TM42 press manufacturer's instruction manual.

CAUTION: Molex crimp specifications are valid only when used with Molex terminals, applicators and tooling.

Americas Headquarters Lisle, Illinois 60532 U.S.A. 1-800-78MOLEX amerinfo@molex.com

Far East North Headquarters Yamato, Kanagawa, Japan 81-462-65-2324 feninfo@molex.com

Far East South Headquarters Jurong, Singapore 65-6-268-6868 fesinfo@molex.com

European Headquarters Munich, Germany 49-89-413092-0 eurinfo@molex.com

Corporate Headquarters 2222 Wellington Ct. Lisle, IL 60532 U.S.A. 630-969-4550 Fax: 630-969-1352

Visit our Web site at http://www.molex.com

UNCONTROLLED COPY Doc No: ATS-639105300 Release Date: 08-17-07 Page 6 of 6 Revision Date: 08-17-07

Revision: A