

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China







Temperature Tester 343 Instruction Manual



Test Products International, Inc.

9615 SW Allen Blvd., Ste. 104 Beaverton, OR USA 97005 503-520-9197 • Fax: 503-520-1225 info@testproductsintl.com

Test Products International, Ltd.

342 Bronte Road South, Unit 9 Milton, Ontario L9T5B7 Canada

905-693-8558 • Fax: 905-693-0888

Test Products International, Europe Ltd.

Longley House, International Drive, Southgate Crawley, West Sussex RH10 6AQ England

+44 (0) 1293 561212 • Fax: +44 (0) 1293 813465

L343 • 8/16/05 copyright © 2005 Test Products International, Inc.

EC DECLARATION OF CONFORMITY & GENERAL GUIDELINES

EC Declaration of Conformity

This is to certify that the 343 conforms to the protection requirements of the council directive 89/336/EEC, in the approximation of laws of the member states relating to Electromagnetic compatibility by application of the following standards:

EN 50081-1 1992 Emissions Standard EN 50082-1 1992 Immunity Standard

To ensure conformity with these standards, this instrument must be operated in accordance with the instructions and specifications given in this manual.

General Guidelines

<u>ALWAYS</u>

- Test the 343 before using it to make sure it is operating properly.
- Inspect temperature probes before using to make sure there are no breaks or shorts.
- Double check all connections before testing.

NEVER

- Insert the probe into an electrically charged medium.
- Touch the probe tip and shaft after it has been inserted in hot material

Features and Benefits

Water Resistant Operates in any environment.

Auto Power Off Instrument automatically shuts off after 20 minutes of inactivity.

Field Calibration Perform ice bath calibration via the front keypad.

Specifications

Innut Type: K-Type Thermocouple Probe

Range	Accuracy
-58° to 32°F (-50° to 0°C)	±3°F (1.6°C)
32° to 1100°F (0° to 600°C)	±(0.3% of reading, + 1.8°F (1°C))
1100° to 2462°F (600° to 1350°C)	±(0.4% of reading, + 1.8°F (1°C))

General Specificatio	ns	
Display	LCD. 4 Digits, 9999 counts	

Update Rate 2.5 times per second Operating Temperature 32° to 122°F (0° to 50°C)

Storage Temperature -13° to 158°F (-25° to 70°C)

Power Supply 9 Volt Alkaline Battery

Battery Life 200 hrs. Typical

Size (HxLxW) Weight

40mm x 190mm x 65mm (1.5" x 7.25" x 2.5")

315g (11.1 oz)



WARNING: Please follow manufacturers test procedures whenever possible. Make sure probe tip and shaft are thoroughly cleaned before inserting it into any food product.

1. Controls and Functions:

Push Buttons

Turns the 343 on and off.

°C/°F Selects Centigrade of Fahrenheit

Min/Max Selects Min or Max reading measured

 $T1/T2/\Delta T$ Selects probe and differential mode

HOLD Freezes the reading on the LCD

2. Step by Step Procedures

- a. Connect a temperature probe or probes to the 343.
- b. Turn the 343 on.
- Insert the tip of the probe into the substance being measured.
- d. Read the temperature on the LCD, allowing approximately 30 seconds for the reading to stabilize. Use the push buttons to switch between probes and access other funtions as described above.

The 343 has the ability to be field calibrated. Accuracy of +/-1°F within the 30°F to 120°F range can be achieved by performing an ice hath calibration.

The temperature of an ice bath is approximately 32°F (0°C). Fill a plastic or metal container with crushed ice and add clean water to a depth of at least 4 inches. Stir the ice and water for 2 to 3 minutes prior to performing calibration to ensure the water is completely chilled. Make certain there is plenty of ice in the mixture and always use clean water. Distilled water works well.

1. Step by Step Procedures

- a. Connect both temperature probes to the 343.
- Press and hold down the MIN/MAX and HOLD buttons and turn the 343 on. CALF will be displayed and the 343 will enter calibration mode and begin cycling between T1 and T2.
- Insert the probes into the ice bath and allow the readings to stabilize.
- d. Once the reading on both inputs has stabilized, press the **HOLD** button. SAVE will be displayed and calibration is complete.

FOR FULL FACTORY CALIBRATION PLEASE RETURN YOUR THERMOMETER TO: TPI / ATTN: SERVICE DEPT.

9615 SW ALLEN BLVD SUITE 104 BEAVERTON. OR 97005

Standard Accessories	Part No.
9V Battery	A009
Temperature Probe (2 each)	GK13M
Protective Boot	A303
Soft Pouch	A255
Instruction manual	

Optional Accessories	Part No.
Probes	See Catalog

MAINTENANCE

- Battery Replacement: The 343 will display battery symbol when the internal 9 Volt battery needs replacement. Replace battery as follows:
 - Disconnect and remove all temperature probes from 343.
 - b. Loosen the 4 screws from the back of the 343.
 - c. Remove the back cover.
 - Remove old battery and replace it with new battery.
 - f. Reassemble instrument in reverse order from above.

2. Cleaning your 343

Use a mild detergent and slightly damp cloth to clean the surfaces of 343.