imall

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832 Email & Skype: info@chipsmall.com Web: www.chipsmall.com Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China





381a Combo Non-Contact / Contact Thermometer

Measure hard-to-reach, sensitive, or large moving target areas.

Features

- Non-contact -4 to 572°F
- Contact -146 to 2,192°F depending upon optional temperature probe
- Temperature compensated
- Single button, last reading hold function, °F/°C switchable

Applications

HVACR

- Compressor heads
- Vents
- · Hot and cold areas in insulation
- Leaks around cooler or freezer doors
- Leaks around windows
- Steam traps
- Registers

Electrical

- Cables
- Circuit breakers
- Connections
- Machinery
- Motors
- Transformers

Food

- Grill & surface temperatures
- Holding cabinets
- Serving temperatures
- Storage temperatures



- Repeatable, 0.1° resolution readings ensure tests are consistently correct.
- Temperature compensated for accurate readings.
- · Don't have to hit a hold button holds last reading automatically.
- Easy-to-use one button operation you can't lock up chip by pressing multiple buttons at one time and therefore don't have to disconnect the battery to reboot the chip.
- °C and °F selectable
- 9 to 1 D:S

381a Technical Data

Jula Icullillai Dala	
Distance to Spot Ratio	9:1
Temperature	Non-contact: -4° to 572°F (-20° to 300°C)
Range	Contact:* -148° to 2192°F (-100° to 1200°C)
IR Accuracy @ 23°C	± 5°F (3°C) below 32°F (0°C)
and 0.95 emissivity	\pm 2% of rdg or \pm 3.5°F (2°C)
	whichever is greater at >32°F (0°C)
Contact Accuracy	+(0.5% of reading + 3.5°F (2°C)
Emissivity	0.95
Laser Sighting	Output <1mW, Wavelength 645-660nm, Class II Laser
°F or °C	Selectable (slide switch in handle)
Contact or Non-contact	Selectable (slide switch in handle)
Display Hold	Yes
Response Time	500 millisecond
Spectral Response	7 - 14 um
Operating Temperature	32° to 120°F (0° to 50°C)
Battery Type	9 Volt
*Overall K-Type range shown. Actual range is dependent on the temperature range of the probe selected.	

FREE GK11M K-type thermocouple with sub-mini input jack Included

GK11M: General purpose Fiberglass insulated beaded tip probe

Exposed junction for fast response in food and non-food liquid, air and surface applications

Diameter: 24 gauge Lead Length: 48" (1.2M) -40° to 950°F (-40° to 510°C) Temp Range:





381a Combo Non-Contact / Contact Thermometer

IR/K: The selector switch is located inside the battery compartment in the handle. Simply swing open the two piece handle and position the slide switch. Set to IR for non-contact measurements or set to K for contact measurements. When set to K, a K-type probe must be connected to the K-type connector located at the bottom right side of the handle. If a probe is not connected the thermometer will display "open" when the trigger is pulled.

Backlit display

TRIGGER: Press and hold the trigger button on the 381a. The thermometer will power up and the laser will be visible (unless in contact "K" mode). After releasing the trigger, the thermometer will hold the last reading then automati-cally turn off after 10 seconds. For extended measurement time simply hold the trigger on and the termometer will stay in scan mode.

>>>>>>

Laser sighting

°F/°C: The selector switch is located inside the battery compartment in the handle. Simply swing open the two piece handle and position the slide switch.

K-type thermocouple sub-mini input jack