Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of “Quality Parts,Customers Priority,Honest Operation,and Considerate Service”,our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!

Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832
Email & Skype: info@chipsmall.com Web: www.chipsmall.com
Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China

Americas

Atlanta - 678-957-9614
Boston - 774-760-0087
Chicago - 630-285-0071
Cleveland - 216-447-0464
Dallas - 972-818-7423
Detroit - 248-538-2250
Indianapolis - 317-773-8323
Los Angeles - 949-462-9523
Phoenix - 480-792-7200
Santa Clara - 408-961-6444
Toronto - 905-673-0699

Europe

Austria - Wels - 43-7242-2244-39
Denmark - Copenhagen - 45-4450-2828
France - Paris - 33-1-69-53-63-20
Germany - Munich - 49-89-627-144-0
Italy - Milan - 39-0331-742611
Netherlands - Drunen - 31-416-690399
Spain - Madrid - 34-91-708-08-90
UK - Wokingham - 44-118-921-5869

Asia/Pacific

Australia - Sydney - 61-2-9868-6733
China - Beijing - 86-10-8528-2100
China - Chengdu - 86-28-8665-5511
China - Chongqing - 86-23-8980-9588
China - Hong Kong SAR - 852-2401-1200
China - Nanjing- 86-25-8473-2460
China - Qingdao - 86-532-8502-7355
China - Shanghai - 86-21-5407-5533
China - Shenyang - 86-24-2334-2829
China - Shenzhen - 86-755-8203-2660
China - Wuhan - 86-27-5980-5300
China - Xiamen - 86-592-2388138
China - Xian - 86-29-8833-7252
China - Zhuhai - 86-756-3210040
India - Bangalore - 91-80-3090-4444
India - New Delhi - 91-11-4160-8631
India - Pune - 91-20-2566-1512
Japan - Yokohama - 81-45-471-6166
Korea - Daegu - 82-53-744-4301
Korea - Seoul - 82-2-554-7200
Malaysia - Kuala Lumpur - 60-3-6201-9857
Malaysia - Penang - 60-4-227-8870
Philippines - Manila - 63-2-634-9065
Singapore - 65-6334-8870
Taiwan - Hsin Chu - 886-3-6578-300
Taiwan - Kaohsiung - 886-7-213-7830
Taiwan - Taipei - 886-2-2500-6610
Thailand - Bangkok - 66-2-694-1351

02/18/11

Microchip Technology Inc. • 2355 West Chandler Blvd. • Chandler, AZ 85224-6199

www.microchip.com

DS51967A

Machine-to-Machine (M2M) PICtail™ Plus Daughter Board Information Sheet

Thank you for purchasing the Microchip M2M PICtail™ Plus Daughter Board. This information sheet highlights some important details that will help you successfully use the board as quickly as possible.

Getting Started

The M2M demonstration requires the use of the Multimedia Expansion Board (MEB) (P/N: DM320005) and a Microchip starter kit. A complete list of supported starter kits and information on software and documentation is available from the M2M webpage, which can be accessed by visiting www.microchip.com and browsing to *Development Tools > PIC32 Boards and Kits*.

Installing MPLAB® IDE and C Compilers

Before you use the M2M PICtail Plus Daughter Board, it is important that you have installed the Microchip MPLAB Integrated Development Environment (IDE). MPLAB IDE provides the assembler tools you will use for development. You will also need a C compiler for the TCP/IP demonstration code. The MPLAB C Compiler seamlessly integrates into MPLAB IDE. Both the MPLAB IDE and C Compiler are free (see the note below) and are available for download at http://www.microchip.com/MPLAB and http://www.microchip.com/compilers, respectively.

Note: Standard Evaluation (Free) – All optimization levels are enabled for 60 days, but then revert to optimization level 1 only.

Running the Demonstration:

1. Make sure MPLAB IDE and the C32 compiler are installed.
2. Download a M2M demonstration project file for the desired Microchip starter kit from the M2M webpage.
3. Connect the Multimedia Expansion Board (MEB) to a supported starter Kit.
4. Connect the daughter board to the MEB Board.
5. Connect the daughter board power cable to the MEB power input.
6. Connect the 9V power supply to the daughter board.
7. Connect starter kit to a USB port on the development computer using the USB cable provided.
8. Using MPLAB IDE, open the M2M demonstration project that was previously downloaded.
9. Choose the PIC32 Starter Kit debugger tool in MPLAB IDE by selecting *Debugger > Select Tool*, and then click **PIC32 Starter Kit**.
10. Build the project by selecting *Project > Build All*.
11. Download your code into the evaluation board microcontroller by selecting *Debugger > Programming > Program All Memories*.
12. Run the demonstration code previously downloaded by selecting *Debugger > Run*.
13. The Microchip M2M demonstration code previously programmed into the starter board starts with a button labeled “Next” displayed on the main screen, which must be touched to initialize the GSM, GPRS, and GPS features. Touch calibration is required if this is the first use of the code.

Your Multimedia Expansion Board and M2M PICtail Plus Daughter Board should now be up and running.

Note: For detailed instructions, please refer to the Microchip application note AN1373 *“Using PIC32 MCUs to Develop GSM/GPRS/GPS Solutions”*.