mail

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832 Email & Skype: info@chipsmall.com Web: www.chipsmall.com Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China





AC Current Transducer AT-B10

Split-core transducer for the electronic measurement of AC waveform currents, with galvanic separation between the primary circuit and the secondary circuit. 0-10 V DC switch voltage output proportional to the RMS value of the primary current.



Electrical data

Primary RMS cu	nominal rrent	Output voltage	T	Гуре		
I _{PN} (At R	MS)	V _{out} (V DC)				
5		0-10	AT	5 B10		
10		0-10	AT	AT 10 B10		
20		0-10	AT	AT 20 B10		
50		0-10	AT	AT 50 B10		
100		0-10	AT	100 B10		
150		0-10	AT	AT 150 B10		
R.	Load resista	nce		≥2		MΩ
U.			self-p	self-powered		
V V	Output clam	ning voltage		15		V
' SZ î	Overlead as	pilig voltage pability	PU OU O	10	o	V of I
1 _P		- 1 mir	1 1	150	Q	% of I_{PN} % of I_{PN}
Per	formance	data				
Х	Accuracv @	I T. = 25 °C (e)	(cluding offset)	< ±1.5	5 0	% of I
£	Linearity erro	pn [,] A	5 ,	< +0.5	5 9	% of I
t	Sten respon	se time to 90 % of	f <i>T</i>	< 300		ms
	Eroquonovih	se time to 50 70 of	PN	<u> </u>		ш ,
DW	Frequency b	andwidth		50/60		ΠΖ
Ger	eral data					
Τ.	Ambient ope	erating temperatur	e	-20	. +60	°C
A T	Ambient stor	age temperature		-20	+85	°C
¹ S	Mace	ago temperature		20	00	2
/// IPxx	Protection de	egree		90 IP 40		g
		-				

Note: Deviation of the output during test IEC 61000-4-3 @ 10 V/m between 280 to 500 MHz.





Features

- RMS (average) output
- 0-10 V DC voltage output
- Split-core type
- Ø 16 mm sensing aperture for non-contact measurement
- Terminal output
- Insulating plastic case recognized according to UL 94-V0.

Advantages

- High insulation between primary and secondary circuits
- Compact case
- Cost-effective solution
- Easy installation.

Applications

- Automation and Supervision Current measurement for process regulation by distributed PLCs or remote control (e.g. SCADA software)
- Safety and Condition
 Monitoring

Load monitoring for protection systems and predictive maintenance (e.g. conveyers, pumps or HVAC motors).

Application domain

• Energy and Automation.

N° U2.05.08.200.0; U2.05.13.200.0; U2.05.17.200.0; U2.05.25.200.0; U2.05.34.200.0; U2.05.39.200.0



Current Transducer AT-B10

Insulation coordination

$U_{\rm b}$	Rated insulation RMS voltage ¹⁾ , reinforced or basic insulation with IEC 61010-1 standards and following conditions - Reinforced insulation - Over voltage category CAT III - Pollution degree PD2	300 s:	V
	- Heterogeneous field		
$U_{\rm d}$	RMS voltage for AC insulation test ²⁾ , 50 Hz, 1 min	3.5 Min	kV
$d_{\rm Cp}$	Creepage distance	6	mm
d _{CI}	Clearance	6	mm
CTI	Comparative tracking index (group I)	600	

<u>Notes:</u> ¹⁾ If insulated cable is used for the primary circuit, the voltage category could be improved according to the insulation coordination given by the cable manufacturer

²⁾Between primary (completely filling the hole) and secondary.



Safety and warning notes

In order to guarantee safe operation of the transducer and to be able to make proper use of all features and functions, please read these instructions thoroughly! Safe operation can only be guaranteed if the transducer is used for the purpose it has been designed for and within the limits of the technical specifications. Ensure you get up-to-date technical information that can be found in the latest associated datasheet under www.lem.com.



Caution! Risk of danger

Ignoring the warnings can lead to serious injury and/or cause damage! The electric measuring transducer may only be installed and put into operation by qualified personnel that have received an appropriate training.

The corresponding national regulations shall be observed during installation and operation of the transducer and any electrical conductor. The transducer shall be used in electric/electronic equipment with respect to applicable standards and safety requirements and in accordance with all the related systems and components manufacturer' operating instructions.



Caution, Risk of electrical shock

When operating the transducer, certain parts of the module may carry hazardous live voltage (eg. primary conductor, power supply). The user shall ensure to take all measures necessary to protect against electrical shock. The transducer is a build-in device containing conducting parts that shall not be accessible after installation. A protective enclosure or additional insulation barrier may be necessary. The transducer shall not be put into operation if the jaw opening is open

(split core version) or the installation is not completed. Installation and maintenance shall be done with the main power supply disconnected except if there are no hazardous live parts in or in close proximity to the system and if the applicable national regulations are fully observed.

Safe and trouble-free operation of this transducer can only be guaranteed if transport, storage and installation are carried out correctly and operation and maintenance are carried out with care.



Dimensions AT-B10 (in mm)



Mechanical characteristics

- General tolerance
- Primary aperture
- Fastening

Connections

• Wires up to 2 mm Ø



(+)

±1 mm

Ø 16 mm

Cable tie

(-)

Load (Controller, meter etc)

Remarks

• Attention: contact areas (air gap) must be kept clean (particle free) to ensure proper performance.



LEM reserves the right to carry out modifications on its transducers, in order to improve them, without prior notice