

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



# Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China









STRUCTURE Silicon Monolithic Integrated Circuit

NAME OF PRODUCT DC-AC Inverter Control IC

TYPE BD9885FV

FUNCTION • 2ch control with Half-bridge

- · Lamp current and voltage sense feed back control
- Sequencing easily achieved with Soft Start Control
- Short circuit protection with Timer Latch
- · Under Voltage Lock Out
- · Short circuit protection with over voltage
- Mode-selectable the operating or stand-by mode by stand-by pin
- Synchronous operating the other BD9885FV IC's
- BURST mode controlled by PWM and DC input
- · Variable to standard Voltage for Lamp current Feed back

#### OAbsolute Maximum Ratings ( $Ta = 25^{\circ}C$ )

Parameter	Symbol	Limits	Unit
Supply Voltage	Vcc	15	V
Operating Temperature Range	Topr	<b>-40∼+90</b>	°C
Storage Temperature Range	Tstg	-55 <b>~</b> +125	°C
Power Dissipation	Pd	850*	mW
Maximum Junction Temperature	Tjmax	+125	°C

<sup>\*</sup>Pd derated at 8.5mW/°C for temperature above Ta = 25°C (When mounted on a PCB 70.0mm×70.0mm×1.6mm)

#### ORecommended operating condition

Parameter	Symbol	Limits	Unit
Supply voltage	Vcc	5. 0~14. 0	٧
CT oscillation frequency	fст	20~150	kHz
BCT oscillation frequency	fBCT	0.05~0.50	kHz




○電気的特性 (Ta=25°C, VCC=7V)

気的特性(Ta=25℃,VCC=7V)	T	1	Limite			
Parameter	Symbol	MIN.	Limits TYP.	MAX.	Unit	Conditions
((WHOLE DEVICE))	1	mill.	111.	max.		
Operating current	Icc1	_	11.0	17. 0	mA	CT=0. 5V
Stand-by current	Icc2	_	2	10	μA	
((OVER VOLTAGE DETECT))						
FB over voltage detect voltage	Vovf	2. 20	2. 40	2. 60	V	
((STAND BY CONTROL))	T	1		1		T -
Stand-by voltage H	VstH	1.4	_	VCC	V	System ON
Stand-by voltage L	VstL	-0.3	-	0.5	V	System OFF
Stand-by hysteresis	⊿Vst	0. 10	0. 25	0. 40	٧	
((TIMER LATCH)) Timer Latch voltage	Vcp	1.8	2. 0	2. 2	V	1
Timer Latch current	Icp	0.5	1. 0	1.5	μΑ	
((OSC BLOCK))	ТОР	0.0	1.0	1.0	μп	
		1 05 /DT	4.5/57	4 05 /57		1
OSC constant current	Іст	1. 35/RT	1. 5/RT	1. 65/RT	A	6 00111
OSC Max voltage	VoscH	1.8	2. 0	2. 2	٧	fct=60kHz
OSC Min voltage	VoscL	0. 3	0. 5	0.7	V	fct=60kHz
MAX DUTY	MAXDUTY	44	46. 5	49	%	fct=60kHz
Soft start current	Iss	1.0	2. 0	3. 0	μΑ	
IS COMP detect Voltage	Visc	0. 45	0. 50	0. 55	٧	
SS COMP detect voltage	Vss	2. 0	2. 2	2. 4	٧	
SRT ON resistance	RSRT	_	200	400	Ω	
((UVLO BLOCK))	1 ,, ,			4.50-		
Operating voltage	VuvloH	4. 100	4. 300	4. 500	V	
Lock out voltage Operating voltage (External UVLO)	VuvloL Vuvlo1	3. 900 1. 900	4. 100 2. 000	4. 300 2. 100	V	
Lock out voltage (External UVLO)	Vuv101 Vuv102	2. 100	2. 200	2. 100	V	
((FEED BACK BLOCK))	VUVTOZ	2. 100	2. 200	2. 300	V	
IS threshold voltage1	Vis1	1. 220	1. 250	1. 280	٧	VREF=0pen
13 till eshoru vortager		1.220		1. 200		VREF=Applying
IS threshold voltage2	Vis2	-	Vref2	-	٧	Voltage
VS threshold voltage	Vvs	1. 220	1. 250	1. 280	V	
IS source current 1	lis1	_	-	1.5	μA	DUTY=2. OV
IS source current 2	lis2	13. 0	20. 0	27. 0	μA	DUTY=OV、IS=0.5V
VS source current	Ivs	_	_	1.0	μA	
((OUTPUT BLOCK))	<u>l</u>	I		l		
Pch output voltage H	VoutPH	VCC-0. 3	VCC-0. 1	_	٧	
Nch output voltage H	VoutNH	VCC-0. 3	VCC-0. 1	_	٧	
Pch output voltage L	VoutPL	_	0. 1	0. 3	V	
Nch output voltage L	VoutNL	_	0. 1	0. 3	V	
Pch output sink resistance	RsinkP	_	8	16	Ω	Isink = 10mA
Pch output source resistance	RsourceP	_	10	20	Ω	Isource = 10mA
Nch output sink resistance	RsinkN	_	8	16	Ω	Isink = 10mA
Nch output source resistance	RsourceN	_	10	20	Ω	Isource = 10mA
((BURST MODE BLOCK))	1	1		T		T
BOSC Max voltage	VburH	1. 94	2. 0	2.06	٧	fBCT=0. 2kHz
BOSC Min Voltage	VburL	0. 4	0. 5	0.6	٧	fBCT=0. 2kHz
BOSC constant current	Івст	1. 35/BRT	1. 5/BRT	1. 65/BRT	Α	
((REG BLOCK))						
REG output voltage	VREG	3. 038	3. 100	3. 162	٧	
REG source current	IREG	5. 0			mA	
			1. 250	1. 280	٧	VREF=0pen
VREF voltage	Vref1	1. 220				
VREF voltage VREF input voltage range		1. 220 0. 60	-	1. 60	٧	VREF=Applying
VREF input voltage range	Vref1			1.60	٧	VREF=Applying Voltage
VREF input voltage range ((COMP BLOCK))	Vref1 Vref2	0. 60	-		V	
VREF input voltage range ((COMP BLOCK)) Over voltage detect	Vref1 Vref2 VCOMPH	0. 60 2. 20	2. 5	2. 80	<u> </u>	
VREF input voltage range ((COMP BLOCK)) Over voltage detect Under voltage detect	Vref1 Vref2	0. 60	-		V	
VREF input voltage range  ((COMP BLOCK))  Over voltage detect	Vref1 Vref2 VCOMPH	0. 60 2. 20	2. 5	2. 80	V	


(This product is not designed for normal operation with in a radio active environment.)



#### OPackage Dimensions



## OBlock Diagram



## OPin Description

1 DUTY Control PWM mode and BURST mode 2 BRT External resistor from BRT to GND for adjusting the BURST triangle oscillator 3 BCT External capacitor from BCT to GND for adjusting the BURST triangle oscillator 4 RT External resistor from SRT to RT for adjusting the triangle oscillator 5 SRT External resistor from SRT to RT for adjusting the triangle oscillator 6 CT External capacitor from CT to GND for adjusting the triangle oscillator 7 GND GROUND 8 FB1 Error amplifier output① 9 IS1 Error amplifier input① 10 VS1 Error amplifier input② 11 FB2 Error amplifier input② 12 IS2 Error amplifier input② 13 VS2 Error amplifier input④ 14 VREF Reference voltage for ISNECE error amplifier 15 FAIL Protect clock output 16 STB Stand-by switch 17 COMP1 Under, over voltage detect for 1ch 18 COMP2 Under, over voltage detect for 2ch 19 UVLO External Under Voltage Lock OUT 20 REG Internal regulator output 21 SS External capacitor from SS to GND for Soft Start Control 22 SCP External capacitor from SCP to GND for Timer Latch 23 P2 FET driver for 2ch 24 N2 FET driver for 2ch 25 PGND Ground for FET drivers 26 N1 FET driver for 1ch 27 P1 FET driver for 1ch 28 VCC Supply voltage input	Pin No.	Pin Name	Function		
adjusting the BURST triangle oscillator  External capacitor from BCT to GND for adjusting the BURST triangle oscillator  External resistor from SRT to RT for adjusting the triangle oscillator  SRT External resistor from SRT to RT for adjusting the triangle oscillator  External resistor from SRT to RT for adjusting the triangle oscillator  External capacitor from CT to GND for adjusting the triangle oscillator  GND GROUND  FB1 Error amplifier output①  VS1 Error amplifier input②  10 VS1 Error amplifier input②  11 FB2 Error amplifier output②  12 IS2 Error amplifier input④  13 VS2 Error amplifier input④  VREF Reference voltage for ISNECE error amplifier  15 FAIL Protect clock output  16 STB Stand-by switch  17 COMP1 Under, over voltage detect for 1ch  18 COMP2 Under, over voltage detect for 2ch  19 UVLO External Under Voltage Lock OUT  20 REG Internal regulator output  21 SS External capacitor from SS to GND for Soft Start Control  22 SCP External capacitor from SCP to GND for Timer Latch  23 P2 FET driver for 2ch  24 N2 FET driver for 2ch  PGND Ground for FET drivers  26 N1 FET driver for 1ch	1	DUTY	Control PWM mode and BURST mode		
adjusting the BURST triangle oscillator  RT External resistor from SRT to RT for adjusting the triangle oscillator  SRT External resistor from SRT to RT for adjusting the triangle oscillator  External capacitor from CT to GND for adjusting the triangle oscillator  REST External capacitor from CT to GND for adjusting the triangle oscillator  REST GROUND  REST Error amplifier output①  SET Error amplifier input②  SET Error amplifier input②  SET Error amplifier input②  REST Error amplifier input④  REFE Under, over voltage detect for 1ch  Under, over voltage detect for 2ch  REFE Internal regulator output  SEX External Under Voltage Lock OUT  REFE Internal regulator output  External capacitor from SCP to GND for Soft Start Control  External capacitor from SCP to GND for Timer Latch  REFE Error and internal regulator output  External capacitor from SCP to GND for Timer Latch  REFE Error adjuster for 2ch  REFE Error amplifier input①  REFE Error amplifier input②  REFE Error amplifier input③  REFE	2	BRT			
adjusting the triangle oscillator  External resistor from SRT to RT for adjusting the triangle oscillator  External capacitor from CT to GND for adjusting the triangle oscillator  RND GROUND  B FB1 Error amplifier output①  10 VS1 Error amplifier input②  11 FB2 Error amplifier input②  12 IS2 Error amplifier input③  13 VS2 Error amplifier input④  14 VREF Reference voltage for ISNECE error amplifier  15 FAIL Protect clock output  16 STB Stand-by switch  17 COMP1 Under, over voltage detect for 1ch  18 COMP2 Under, over voltage detect for 2ch  19 UVLO External Under Voltage Lock OUT  20 REG Internal regulator output  21 SS External capacitor from SCP to GND for Timer Latch  22 SCP External capacitor from SCP to GND for Timer Latch  23 P2 FET driver for 2ch  24 N2 FET driver for 2ch  25 PGND Ground for FET drivers  26 N1 FET driver for 1ch	3	BCT			
adjusting the triangle oscillator  External capacitor from CT to GND for adjusting the triangle oscillator  GND GROUND  Error amplifier output①  SET Error amplifier input②  SET Error amplifier input②  SET Error amplifier input②  SET Error amplifier input③  SET Error amplifier input④  SET Error amplifier input④  VREF Reference voltage for ISNECE error amplifier  FAIL Protect clock output  STB Stand-by switch  COMP1 Under, over voltage detect for 1ch  STB COMP2 Under, over voltage detect for 2ch  SET External Under Voltage Lock OUT  REG Internal regulator output  External capacitor from SCP to GND for Soft Start Control  External capacitor from SCP to GND for Timer Latch  PET driver for 2ch  FET driver for 2ch  PI FET driver for 1ch	4	RT			
adjusting the triangle oscillator  GND GROUND  B FB1 Error amplifier output①  SIST Error amplifier input②  SIST Error amplifier input②  SIST Error amplifier input②  SIST Error amplifier output②  SIST Error amplifier input③  SIST Error amplifier input④  SIST Error amplifier output④  SIST Error amplifier output④  SIST Error amplifier output  SIST Error amplifier input②  SIST Error amplifier output④  SIST Error amplifier input②  SIST Error amplifier  SIST Error amplifier input②  SIST Error amplifier input③	5	SRT			
8 FBI Error amplifier output(1) 9 IS1 Error amplifier input(1) 10 VS1 Error amplifier input(2) 11 FB2 Error amplifier output(2) 12 IS2 Error amplifier input(3) 13 VS2 Error amplifier input(4) 14 VREF Reference voltage for ISNECE error amplifier 15 FAIL Protect clock output 16 STB Stand-by switch 17 COMP1 Under, over voltage detect for 1ch 18 COMP2 Under, over voltage detect for 2ch 19 UVLO External Under Voltage Lock OUT 20 REG Internal regulator output 21 SS External capacitor from SS to GND for Soft Start Control 22 SCP External capacitor from SCP to GND for Timer Latch 23 P2 FET driver for 2ch 24 N2 FET driver for 2ch 25 PGND Ground for FET drivers 26 N1 FET driver for 1ch	-	СТ	·		
9 ISI Error amplifier input① 10 VS1 Error amplifier input② 11 FB2 Error amplifier output② 12 IS2 Error amplifier input③ 13 VS2 Error amplifier input④ 14 VREF Reference voltage for ISNECE error amplifier 15 FAIL Protect clock output 16 STB Stand-by switch 17 COMP1 Under, over voltage detect for 1ch 18 COMP2 Under, over voltage detect for 2ch 19 UVLO External Under Voltage Lock OUT 20 REG Internal regulator output 21 SS External capacitor from SS to GND for Soft Start Control 22 SCP External capacitor from SCP to GND for Timer Latch 23 P2 FET driver for 2ch 24 N2 FET driver for 2ch 25 PGND Ground for FET drivers 26 N1 FET driver for 1ch	7	GND	GROUND		
10 VS1 Error amplifier input② 11 FB2 Error amplifier output② 12 IS2 Error amplifier input③ 13 VS2 Error amplifier input④ 14 VREF Reference voltage for ISNECE error amplifier 15 FAIL Protect clock output 16 STB Stand-by switch 17 COMP1 Under, over voltage detect for 1ch 18 COMP2 Under, over voltage detect for 2ch 19 UVLO External Under Voltage Lock OUT 20 REG Internal regulator output 21 SS External capacitor from SS to GND for Soft Start Control 22 SCP External capacitor from SCP to GND for Timer Latch 23 P2 FET driver for 2ch 24 N2 FET driver for 2ch 25 PGND Ground for FET drivers 26 N1 FET driver for 1ch 27 P1 FET driver for 1ch	8	FB1	Error amplifier output①		
11 FB2 Error amplifier output2  12 IS2 Error amplifier input3  13 VS2 Error amplifier input4  14 VREF Reference voltage for ISNECE error amplifier  15 FAIL Protect clock output  16 STB Stand-by switch  17 COMP1 Under, over voltage detect for 1ch  18 COMP2 Under, over voltage detect for 2ch  19 UVLO External Under Voltage Lock OUT  20 REG Internal regulator output  21 SS External capacitor from SS to GND for Soft Start Control  22 SCP External capacitor from SCP to GND for Timer Latch  23 P2 FET driver for 2ch  24 N2 FET driver for 2ch  25 PGND Ground for FET drivers  26 N1 FET driver for 1ch	9	IS1	Error amplifier input①		
12 IS2 Error amplifier input③ 13 VS2 Error amplifier input④ 14 VREF Reference voltage for ISNECE error amplifier 15 FAIL Protect clock output 16 STB Stand-by switch 17 COMP1 Under, over voltage detect for 1ch 18 COMP2 Under, over voltage detect for 2ch 19 UVLO External Under Voltage Lock OUT 20 REG Internal regulator output 21 SS External capacitor from SS to GND for Soft Start Control 22 SCP External capacitor from SCP to GND for Timer Latch 23 P2 FET driver for 2ch 24 N2 FET driver for 2ch 25 PGND Ground for FET drivers 26 N1 FET driver for 1ch 27 P1 FET driver for 1ch	10	VS1	Error amplifier input②		
13 VS2 Error amplifier input@  14 VREF Reference voltage for ISNECE error amplifier  15 FAIL Protect clock output  16 STB Stand-by switch  17 COMP1 Under, over voltage detect for 1ch  18 COMP2 Under, over voltage detect for 2ch  19 UVLO External Under Voltage Lock OUT  20 REG Internal regulator output  21 SS External capacitor from SS to GND for Soft Start Control  22 SCP External capacitor from SCP to GND for Timer Latch  23 P2 FET driver for 2ch  24 N2 FET driver for 2ch  25 PGND Ground for FET drivers  26 N1 FET driver for 1ch	11	FB2	Error amplifier output②		
14 VREF Reference voltage for ISNECE error amplifier  15 FAIL Protect clock output  16 STB Stand-by switch  17 COMP1 Under, over voltage detect for 1ch  18 COMP2 Under, over voltage detect for 2ch  19 UVLO External Under Voltage Lock OUT  20 REG Internal regulator output  21 SS External capacitor from SS to GND for Soft Start Control  22 SCP External capacitor from SCP to GND for Timer Latch  23 P2 FET driver for 2ch  24 N2 FET driver for 2ch  25 PGND Ground for FET drivers  26 N1 FET driver for 1ch	12	182	Error amplifier input③		
WKEF	13	VS2	Error amplifier input④		
16 STB Stand-by switch 17 COMP1 Under, over voltage detect for 1ch 18 COMP2 Under, over voltage detect for 2ch 19 UVLO External Under Voltage Lock OUT 20 REG Internal regulator output 21 SS External capacitor from SS to GND for Soft Start Control 22 SCP External capacitor from SCP to GND for Timer Latch 23 P2 FET driver for 2ch 24 N2 FET driver for 2ch 25 PGND Ground for FET drivers 26 N1 FET driver for 1ch 27 P1 FET driver for 1ch	14	VREF	_		
17 COMP1 Under, over voltage detect for 1ch 18 COMP2 Under, over voltage detect for 2ch 19 UVLO External Under Voltage Lock OUT 20 REG Internal regulator output 21 SS External capacitor from SS to GND for Soft Start Control 22 SCP External capacitor from SCP to GND for Timer Latch 23 P2 FET driver for 2ch 24 N2 FET driver for 2ch 25 PGND Ground for FET drivers 26 N1 FET driver for 1ch 27 P1 FET driver for 1ch	15	FAIL	Protect clock output		
18         COMP2         Under, over voltage detect for 2ch           19         UVLO         External Under Voltage Lock OUT           20         REG         Internal regulator output           21         SS         External capacitor from SS to GND for Soft Start Control           22         SCP         External capacitor from SCP to GND for Timer Latch           23         P2         FET driver for 2ch           24         N2         FET driver for 2ch           25         PGND         Ground for FET drivers           26         N1         FET driver for 1ch           27         P1         FET driver for 1ch	16	STB			
19         UVLO         External Under Voltage Lock OUT           20         REG         Internal regulator output           21         SS         External capacitor from SS to GND for Soft Start Control           22         SCP         External capacitor from SCP to GND for Timer Latch           23         P2         FET driver for 2ch           24         N2         FET driver for 2ch           25         PGND         Ground for FET drivers           26         N1         FET driver for 1ch           27         P1         FET driver for 1ch	17	COMP1			
20 REG Internal regulator output 21 SS External capacitor from SS to GND for Soft Start Control 22 SCP External capacitor from SCP to GND for Timer Latch 23 P2 FET driver for 2ch 24 N2 FET driver for 2ch 25 PGND Ground for FET drivers 26 N1 FET driver for 1ch 27 P1 FET driver for 1ch			Under, over voltage detect for 2ch		
21 SS External capacitor from SS to GND for Soft Start Control  22 SCP External capacitor from SCP to GND for Timer Latch  23 P2 FET driver for 2ch  24 N2 FET driver for 2ch  25 PGND Ground for FET drivers  26 N1 FET driver for 1ch  27 P1 FET driver for 1ch	19	UVL0	External Under Voltage Lock OUT		
SS   Start Control	20	REG	Internal regulator output		
22         SGP         Latch           23         P2         FET driver for 2ch           24         N2         FET driver for 2ch           25         PGND         Ground for FET drivers           26         N1         FET driver for 1ch           27         P1         FET driver for 1ch	21	SS	I		
24         N2         FET driver for 2ch           25         PGND         Ground for FET drivers           26         N1         FET driver for 1ch           27         P1         FET driver for 1ch	22	SCP	·		
25 PGND Ground for FET drivers 26 N1 FET driver for 1ch 27 P1 FET driver for 1ch	23	P2	FET driver for 2ch		
26 N1 FET driver for 1ch 27 P1 FET driver for 1ch	24	N2	FET driver for 2ch		
27 P1 FET driver for 1ch	25	PGND	Ground for FET drivers		
	26	N1	FET driver for 1ch		
28 VCC Supply voltage input	27	P1	FET driver for 1ch		
20 outpit for cago tilpac	28	VCC	Supply voltage input		



#### ONOTE FOR USE

- 1. When designing the external circuit, including adequate margins for variation between external devices and the IC. Use adequate margins for steady state and transient characteristics.
- 2. Recommended Operating Range

The circuit functionality is guaranteed within of ambient temperature operation range as long as it is within recommended operating range. The standard electrical characteristic values cannot be guaranteed at other voltages in the operating ranges, however, the variation will be small.

3. Mounting Failures

Mounting failures, such as misdirection or miscounts, may harm the device.

4. Electromagnetic Fields

A strong electromagnetic field may cause the IC to malfunction.

- 5. The GND pin should be the location within  $\pm 0.3V$  compared with the PGND pin
- 6. BD9885FV has the short circuit protection with Thermal Shut Down System. When STB or Vcc pin re-supplied, They enables to cancel the latch. If It rise the temperature of the chip more than 170°C(TYP), It make the external FET OFF
- 7. Absolute maximum ratings are those values that, if exceeded, may cause the life of a device to become significantly shortened.
  Moreover, the exact failure mode caused by short or open is not defined. Physical countermeasures, such as a fuse, need to be considered when using a device beyond its maximum ratings.
- 8. About the external FET, the parasitic Capacitor may cause the gate voltage to change, when the drain voltage is switching.

  Make sure to leave adequate margin for this IC variation.
- 9. On operating Slow Start Control (SS is less than 2.2V), It does not operate Timer Latch.
- 1 O. By STB voltage, BD9885FV is changed to 2 states. Therefore, do not input STB pin voltage between one state and the other state  $(0.5 \sim 1.4 \text{V})$ .
- 1 1. The pin connected a connector need to connect to the resistor for electrical surge destruction.
- 1 2. This IC is a monolithic IC which (as shown is Fig-1)has P<sup>+</sup> substrate and between the various pins. A P-N junction is formed from this P layer of each pin. For example, the relation between each potential is as follows,
  - O (When GND > PinB and GND > PinA, the P-N junction operates as a parasitic diode.)
  - O(When PinB > GND > PinA, the P-N junction operates as a parasitic transistor.)

Parasitic diodes can occur inevitably in the structure of the IC. The operation of parasitic diodes can result in mutual interference among circuits as well as operation faults and physical damage. Accordingly you must not use methods by which parasitic diodes operate, such as applying a voltage that is lower than the GND(P substrate) voltage to an input pin.




Fig-1 Simplified structure of a Bipolar IC

#### Notes

No copying or reproduction of this document, in part or in whole, is permitted without the consent of ROHM Co.,Ltd.

The content specified herein is subject to change for improvement without notice.

The content specified herein is for the purpose of introducing ROHM's products (hereinafter "Products"). If you wish to use any such Product, please be sure to refer to the specifications, which can be obtained from ROHM upon request.

Examples of application circuits, circuit constants and any other information contained herein illustrate the standard usage and operations of the Products. The peripheral conditions must be taken into account when designing circuits for mass production.

Great care was taken in ensuring the accuracy of the information specified in this document. However, should you incur any damage arising from any inaccuracy or misprint of such information, ROHM shall bear no responsibility for such damage.

The technical information specified herein is intended only to show the typical functions of and examples of application circuits for the Products. ROHM does not grant you, explicitly or implicitly, any license to use or exercise intellectual property or other rights held by ROHM and other parties. ROHM shall bear no responsibility whatsoever for any dispute arising from the use of such technical information.

The Products specified in this document are intended to be used with general-use electronic equipment or devices (such as audio visual equipment, office-automation equipment, communication devices, electronic appliances and amusement devices).

The Products specified in this document are not designed to be radiation tolerant.

While ROHM always makes efforts to enhance the quality and reliability of its Products, a Product may fail or malfunction for a variety of reasons.

Please be sure to implement in your equipment using the Products safety measures to guard against the possibility of physical injury, fire or any other damage caused in the event of the failure of any Product, such as derating, redundancy, fire control and fail-safe designs. ROHM shall bear no responsibility whatsoever for your use of any Product outside of the prescribed scope or not in accordance with the instruction manual.

The Products are not designed or manufactured to be used with any equipment, device or system which requires an extremely high level of reliability the failure or malfunction of which may result in a direct threat to human life or create a risk of human injury (such as a medical instrument, transportation equipment, aerospace machinery, nuclear-reactor controller, fuel-controller or other safety device). ROHM shall bear no responsibility in any way for use of any of the Products for the above special purposes. If a Product is intended to be used for any such special purpose, please contact a ROHM sales representative before purchasing.

If you intend to export or ship overseas any Product or technology specified herein that may be controlled under the Foreign Exchange and the Foreign Trade Law, you will be required to obtain a license or permit under the Law.



Thank you for your accessing to ROHM product informations.

More detail product informations and catalogs are available, please contact us.

## **ROHM Customer Support System**

http://www.rohm.com/contact/