imall

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832 Email & Skype: info@chipsmall.com Web: www.chipsmall.com Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China





BP130 Ni-MH Rechargeable Battery Pack

Instruction Sheet

This Rechargeable Battery Pack is designed for use with the Fluke ScopeMeter Model 124 and with Model 123 if the installed software is of version V2.00 or higher.

Chapter 2 of the Users Manual of the ScopeMeter explains how to display the software version. This Chapter also explains how to exchange the Battery Pack.

After installation, charge the Battery Pack for at least 7 Hrs. with the ScopeMeter switched off.

- Nominal Voltage: 4.8 V
- Capacity: 3.0 Ah

.

- Lifetime: minimum 500 cycles at nominal charge of 500 mA
- Temperature Ranges: Operating: 0 °C to 50°C Quick Charging: 10°C to 40°C Trickle Charging: 10°C to 45°C Storage: -40°C to 60°C

Performing a Refresh Cycles every 3 months, will contribute to the lifetime of the Battery Pack.

To prevent damage to Equipment or Battery:

Fully charge before use. Keep the battery cool Do not dispose in open fire Observe polarity Do not solder directly to the cells Do not short circuit Store Batteries outside the Instrument



BP130 Ni-MH Rechargeable Battery Pack

Instruction Sheet

This Rechargeable Battery Pack is designed for use with the Fluke ScopeMeter Model 124 and with Model 123 if the installed software is of version V2.00 or higher.

Chapter 2 of the Users Manual of the ScopeMeter explains how to display the software version. This Chapter also explains how to exchange the Battery Pack.

After installation, charge the Battery Pack for at least 7 Hrs. with the ScopeMeter switched off.

- Nominal Voltage: 4.8 V
- Capacity: 3.0 Ah
- Lifetime: minimum 500 cycles at nominal charge of 500 mA
- Temperature Ranges: Operating: 0 °C to 50°C Quick Charging: 10°C to 40°C Trickle Charging: 10°C to 45°C Storage: -40°C to 60°C

Performing a Refresh Cycles every 3 months, will contribute to the lifetime of the Battery Pack.

To prevent damage to Equipment or Battery: Fully charge before use. Keep the battery cool Do not dispose in open fire Observe polarity Do not solder directly to the cells Do not short circuit Store Batteries outside the Instrument

FLUKE

BP130 Ni-MH Rechargeable Battery Pack

Instruction Sheet

This Rechargeable Battery Pack is designed for use with the Fluke ScopeMeter Model 124 and with Model 123 if the installed software is of version V2.00 or higher.

Chapter 2 of the Users Manual of the ScopeMeter explains how to display the software version. This Chapter also explains how to exchange the Battery Pack.

After installation, charge the Battery Pack for at least 7 Hrs. with the ScopeMeter switched off.

- Nominal Voltage: 4.8 V
- Capacity: 3.0 Ah
- Lifetime: minimum 500 cycles at nominal charge of 500 mA
- Temperature Ranges: Operating: 0 °C to 50°C Quick Charging: 10°C to 40°C Trickle Charging: 10°C to 45°C Storage: -40°C to 60°C

Performing a Refresh Cycles every 3 months, will contribute to the lifetime of the Battery Pack.

To prevent damage to Equipment or Battery: Fully charge before use. Keep the battery cool Do not dispose in open fire Observe polarity Do not solder directly to the cells Do not short circuit Store Batteries outside the Instrument



Do not dispose the Battery Pack with other solid waste. Used batteries should be disposed of by a qualified recycler or hazardous materials handler. Contact your authorized FLUKE Service Center for recycling information.

To locate a Fluke Service Center, visit Fluke on the World Wide Web:

www.fluke.com

or call Fluke using any of the phone numbers listed below:

+1-888-993-5853 in U.S.A. and Canada +31-40-2675200 in Europe +1-425-446-5500

4822 872 30730

Sept 2002 © 2002, Fluke Corporation, All rights reserved. Printed in the Netherlands All product names are trademarks of their respective companies.



Do not dispose the Battery Pack with other solid waste. Used batteries should be disposed of by a qualified recycler or hazardous materials handler. Contact your authorized FLUKE Service Center for recycling information.

To locate a Fluke Service Center, visit Fluke on the World Wide Web:

www.fluke.com

or call Fluke using any of the phone numbers listed below:

+1-888-993-5853 in U.S.A. and Canada +31-40-2675200 in Europe +1-425-446-5500

4822 872 30730

Sept 2002 © 2002, Fluke Corporation, All rights reserved. Printed in the Netherlands All product names are trademarks of their respective companies.



Do not dispose the Battery Pack with other solid waste. Used batteries should be disposed of by a qualified recycler or hazardous materials handler. Contact your authorized FLUKE Service Center for recycling information.

To locate a Fluke Service Center, visit Fluke on the World Wide Web:

www.fluke.com

or call Fluke using any of the phone numbers listed below: +1-888-993-5853 in U.S.A. and Canada +31-40-2675200 in Europe +1-425-446-5500

4822 872 30730

Sept 2002 © 2002, Fluke Corporation, All rights reserved. Printed in the Netherlands All product names are trademarks of their respective companies.





