



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts,Customers Priority,Honest Operation,and Considerate Service",our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



## Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China





# Digital IR Receiver Module (SKU:DFR0094)



## Contents

- [1 Introduction](#)
- [2 Specification](#)
- [3 Wiring Diagram](#)
- [4 Sample Code](#)

## Introduction

Digital IR Receiver Module (SKU:DFR0094)

IR is widely used in remoter control. With this IR receiver, the Arduino project is able to receive command from any IR remoter controller if you have the right decoder. Well, it will be also easy to make your own IR controller using IR transmitter.


## Specification

- Power Supply:5V
- Interface:Digital
- Modulate Frequency:38Khz
- Module interface socket:**JST PH2.0**

## Wiring Diagram

The following image shows a suggested connection method. You may use any Digital I/O pin that is not in use by another device.

NOTE: In the sample code below Digital pin 11 is in use, you may either change your wiring or change the sample code to match.



## Sample Code

IR Receiver test code:

```
/*
 * IRremote: IRrecvDemo - demonstrates receiving IR codes with IRrecv
 * An IR detector/demodulator must be connected to the input RECV_PIN.
 * Version 0.1 July, 2009
 * Copyright 2009 Ken Shirriff
 * http://arcfn.com
 */
```

```
*/  
  
#include <IRremote.h>  
  
int RECV_PIN = 11;  
  
IRrecv irrecv(RECV_PIN);  
  
decode_results results;  
  
void setup()  
{  
  Serial.begin(9600);  
  irrecv.enableIRIn(); // Start the receiver  
}  
  
void loop() {  
  if (irrecv.decode(&results)) {  
    Serial.println(results.value, HEX);  
    irrecv.resume(); // Receive the next value  
  }  
}
```