

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China







DP2 SERIES

High-performance Digital Pressure Sensor







DP2

Complete functionality! Selection from a wide lineup

* Passed the UL 991 Environment Test





UL 61010C-1 compatible, Passed the UL 991 Environment Test based on SEMI S2-0200 (Category applicable for semiconductor manufacturing: TWW2, Process Equipment)
[Applicable standards: UL 61010C-1]
[Additional test / evaluation standards as per intended use: UL991, SEMI S2-0200]

High accuracy · high resolution · high speed

It achieves a 2.5 ms, or less, response time at a high resolution of 1/1,000. It enables highly accurate sensing with its excellent repeatability and temperature characteristics.

Response time






Clearly visible LED display with 3¹/₂ digits

Bright red LED 7-segment display having 31/2 digits, 10 mm 0.394 in high. The displayed figures are remarkably noticeable not only in a dark area, but also in a well-lit place.




Four output modes enable versatile pressure level control

1 Hysteresis mode




The common hysteresis of the comparative outputs can be set, as desired, with the set values.

3 Dual output mode




The outputs can be put to different use, such as, detection of different kinds of objects, control function, alarm function etc.

2 Window comparator mode



The comparative outputs can be turned ON or OFF by a pressure which is within the pressure range set by Set Value 1 and Set Value 2.

4 Automatic sensitivity setting mode



Using actual objects, if the pressure values for OK objects and NG objects are input, then the sensor is automatically set to the optimum pressure value (mid-value)


Initialization and threshold value settings are easily done by key operation while seeing the values on the display.

Setting with easy key operation

Selection from six pressure units

The pressure unit can be selected from six different systems to suit your requirement.

The selectable pressure units differ with the sensor type. When the pressure unit is changed, the measured pressure value and the set values are automatically converted.




Note: 'MPa' in case of DP2-22□, DP2-42□ and DP2-62□.

APPLICATIONS


Confirmation of chip component suction

The light weight type does not disturb the movement of the suction head, even if it is mounted close to the head.




Verifying placement of frame

High pressure is attained when the frame is exactly seated. Hence, the pressure change when the frame is exactly placed is detected.




Controlling clamping force

The clamping force can be changed to suit the workpiece by controlling the supplied air pressure.




Detecting tap breakage

Two opposed nozzles are supplied air at different pressures. If the tap breaks, the pressure at the lower pressure side nozzle is affected by the air of the higher pressure side nozzle. This change in pressure is detected.




Inspecting orientation of glass sheet

The orientation of the glass sheet can be recognized by detecting the change in vacuum due to presence / absence of indentation.



Controlling edge of winding film

With bifurcated nozzles placed on both sides of the film, the position of the winding film is recognized as right-shifted (high pressure), OK (middle pressure), or left-shifted (low pressure).



Analog voltage output incorporated as a standard

Since a linear analog voltage output (1 to 5 V) is incorporated, the sensor is ideally suited for real time monitoring or for remote control in combination with an analog controller (ultra-compact digital panel controller CA2 series, or digital panel controller CA series).


Peak hold / bottom hold display

The peak value or the bottom value of the varying pressure can be displayed. This function is convenient for finding the pressure variation range or for determining a reference for pressure settings.

Analog bar display


Pressure changes can also be displayed in an analog fashion using LED bars. Hence, sudden pressure changes can be recognized at a glance.


LED bars indicate the pressure level in steps of 10 % F.S., regardless of the pressure unit.




A Wide Variety of Models

Models are selectable according to mounting style, environmental resistance, and manner of use.







Direct mounting on a wall

The **DP2** series covers world-wide usage with the Asian type, the North American type and the European type. Each type provides the customary pressure unit, suitable transistor output, and pressure port.

	Pres	sure unit		Pressure port	
	The interna- tional system of unit (SI)		Output		
Asian		kgf/cm² (Positive pressure type) mmHg (Vacuum pressure type)	NPN and	Rc (PT) ^{1/8} or M5 female thread	
North American	Pa	psi (Positive pressure type) inHg (Vacuum pressure type)	NPN and	NPT ¹ / ₈ or NPTF ¹ / ₈ female thread	
European		bar	PNP and analog voltage	G (PF) ¹ / ₈ female thread	

DP2

ORDER GUIDE

PRESS		_			_										
	_		/pe		Appearance	Rated pressure range	Model No.	Pressure port	Comparative output						
DP5/DPH ead-separated		Vacuum pressure	type	Asian			DP2-20	Rc (PT) ¹ / ₈ female thread	NPN open-collector						
DP5/DPH		um pre	101 kPa type	North American		0 to - 101.3 kPa	DP2-20F	NPTF 1/8	transistor						
DE Head		Vacu	1 1				DP2-20F-P	female thread	PNP open-collector transistor						
	_		ed	Asian	Section Control		DP2-21	Rc (PT) ¹ / ₈ female thread	NPN open-collector						
DP4	Standard	KPa t	100 kPa type		<u>-1000</u>	0 to 100.0 kPa	DP2-21F	NPTF ¹ /8	transistor						
	Ş	Positive pressure	100	North American	090		DP2-21F-P	female thread	PNP open-collector transistor						
		sitive p	90	Asian	•		DP2-22	Rc (PT) ¹ / ₈ female thread	NPN open-collector						
DP2 av	ļ	 ਕੁ	MPa type	North American		0 to 1.000 MPa	DP2-22F	NPTF ¹ /8	transistor						
l slgsi			2 :				DP2-22F-P	female thread	PNP open-collector transistor						
DP3 DF Digital Display	Light weight	Vacuum pressure	- 101 kPa type	Asian	-1000	0 to — 101.3 kPa	DP2-80	M5 female thread	NPN open-collector transistor						
DP-M		Va	'	North American			DP2-40N	NPT ¹ /8 female thread							
ᆸ	#			European 1			DP2-40E	G (PF) ¹ / ₈ female thread	PNP open-collector transistor						
av	Flat		e d	Asian	District the proof		DP2-41	Rc (PT) ¹ / ₈ female thread	NPN open-collector						
PE ar Disp		Φ	100 kPa type	KPa ty	North American	1000	0 to 100.0 kPa	DP2-41N	NPT ¹ / ₈ female thread	transistor					
PE ED Bar Dis		oressur	100	European	000		DP2-41E	G (PF) ¹ / ₈ female thread	PNP open-collector transistor						
	1	Positive pressure	96	Asian			DP2-42	Rc (PT) ¹ / ₈ female thread	NPN open-collector						
		PC	Po	- A	- A	a a	ď	MPa type	North American		0 to 1.000 MPa	DP2-42N	NPT ¹ /8 female thread	transistor	
			=	European			DP2-42E	G (PF) ¹ / ₈ female thread	PNP open-collector transistor						
		sarre	hype	Asian			DP2-60	Rc (PT) ¹ / ₈ female thread	NPN open-collector						
		Vacuum pressure	101 kPa type	North American		0 to - 101.3 kPa	DP2-60N	NPT ¹ / ₈ female thread	transistor						
		Vacuur 101	Vacuu — 10 — 10 — European			DP2-60E	G (PF) ¹ / ₈ female thread	PNP open-collector transistor							
			100 kPa type	Asian	1,000		DP2-61	Rc (PT) ¹ / ₈ female thread	NPN open-collector						
	1P67	IP67		North American		0 to 100.0 kPa	DP2-61N	NPT ¹ / ₈ female thread	transistor						
		ressur	100	European			DP2-61E	G (PF) ¹ / ₈ female thread	PNP open-collector transistor						
		Positive pressure	ø	Asian			DP2-62	Rc (PT) ^{1/8} female thread	NPN open-collector						
		Po	MPa type	North American	ı	0 to 1.000 MPa	DP2-62N	NPT ¹ / ₈ female thread	transistor						
			-	European			DP2-62E	G (PF) ¹ / ₈ female thread	PNP open-collector transistor						

ORDER GUIDE


5 m 16.404 ft cable length type

5 m 16.404 ft cable length type is also available. (Standard: 2 m 6.562 ft)

		Туре		Standard	5 m 16.404 ft cable length type		
				DP2-20	DP2-20-C5		
	Þ	Vacuum pressure	— 101 kPa type	DP2-20F			
				DP2-20F-P			
7				DP2-21	DP2-21-C5		
9	Standard		100 kPa type	DP2-21F			
đ	N N	Docitivo proceuro		DP2-21F-P			
		Positive pressure		DP2-22	DP2-22-C5		
			1 MPa type	DP2-22F			
				DP2-22F-P			
	ight			DP2-80	DP2-80-C5		
	Light weight	Vacuum pressure	- 101 kPa type	DP2-40N			
	Ligh			DP2-40E			
				DP2-41	DP2-41-C5		
Ė	I	Positive pressure	100 kPa type	DP2-41N			
				DP2-41E			
				DP2-42	DP2-42-C5		
			1 MPa type	DP2-42N			
				DP2-42E			
				DP2-60			
		Vacuum pressure	- 101 kPa type	DP2-60N			
				DP2-60E			
	IP67			DP2-61	The IDOZ have in the other dead		
ID67			100 kPa type	DP2-61N	The IP67 type is the standard type with a 5 m 16.404 ft cable.		
		Positive pressure		DP2-61E			
		. contro procedure		DP2-62			
			1 MPa type	DP2-62N			
				DP2-62E			

Accessories

- DPX-01 [Pressure port attachment (Standard type only)]
 DPX-02 [Hexagon-socket-head plug for pressure port (Standard type only)]



OPTIONS

	Designation	Model No.	Description					
-	Sensor mounting	MS-DPX	Mounting bracket for standard type [Two M4 (length 6 mm 0.236 in) pan head screws and two spring washers are attached.					
	bracket (For standard type)	MS-DPX-4	Back angled mounting bracket for standard type [Two M4 (length 6 mm 0.236 in) pan head screws and two spring washers are attached.					
;	Straight bush	DPX-03	Changes the pressure port from female thread [Rc (P male thread [R (PT) 1/8]					
- 1	Panel mounting bracket (For standard type)	MS-DPX-2	It can be used for mounting on a panel (1 to 3.2 mm 0.039 to 0.126 in thick).					
(Front protection cover (For standard type)	DPX-04	It protects the sensor's adjustment panel. (It can be fitted when the panel mounting bracket is used.)					
	Digital panel controller (Note)	CA2-T2	NPN open-collector transistor	This is a very small controller which allows two independent threshold level settings. * Supply voltage: 24 V DC ± 10 % * No. of inputs: 1 No. (sensor input) * Input range: 1 to 5 V DC * Main functions: Threshold level setting function, zero-adjust function, scale setting function, hysteresis setting function, start / hold function, autoreference function, power supply ON-delay function, etc.				
		CA-R2	Relay contact	This is a multi-functional controller havin mathematical functions, hold function, etc. • Supply voltage: 100 to 240 V AC ± 10 % • No. of inputs: 2 Nos. (sensor inputs)				
		CA-T2	NPN open-collector transistor	Input range: 1 to 5 V DC Power supply for sensor: 12 V DC, 150 mA Main functions: Mathematical functions, process number				
		CA-B2	NPN open-collector transistor With BCD output	selection function, hold function, scaling function, auto-reference function, power supply ON-delay function, measurement start delay function, hysteresis setting function, etc.				

Note: For further details, refer to p.864 \sim for the ultra-compact digital panel controller **CA2** series, and to p.854 \sim for the digital panel controller **CA** series.

Sensor mounting bracket

· MS-DPX

· MS-DPX-4








Two M4 (length 6 mm 0.236 in) pan head screws and two spring washers are attached.

Straight bush

• DPX-03



Panel mounting bracket, Front protection cover • MS-DPX-2 • DPX-04



Digital panel controller

• CA2 series



• CA series



SPECIFICATIONS

	_			pressure					pressure		
Туре				Pa type			100kPa typ			1MPa type	1
		Standard	Light weight	Flat	IP67	Standard	Flat	IP67	Standard	Flat	IP67
Model No.	Asian	DP2-20	DP2-80		DP2-60	DP2-21	DP2-41	DP2-61	DP2-22	DP2-42	DP2-62
\ <u>\</u>	North American (Note)	DP2-20F(-P)		DP2-40N	DP2-60N	DP2-21F(-P)	DP2-41N	DP2-61N	DP2-22F(-P)	DP2-42N	DP2-62N
Item\ ≥	European			DP2-40E	DP2-60E		DP2-41E	DP2-61E		DP2-42E	DP2-62E
Type of pr	essure					Gauge	pressure				
Rated pre	ssure range		0 to — 1	01.3 kPa		(0 to 100.0 kP	a	0	to 1.000 MF	Pa
Set pressure range		5.1 to - 101.3 kPa 0.052 to - 1.033 kgf/cm², 0.051 to - 1.013 bar 0.74 to - 14.70 psi, 38 to - 760 mmHg 1.5 to - 29.9 inHg -5.0 to 100.0 kPa -0.051 to 1.020 kgf/cm² -0.050 to 1.000 bar -0.72 to 14.50 psi -0.50 to 100.0 kPa -0.51 to 10.20 kgf/cm² -0.50 to 10.00 bar -7.2 to 145.0 psi						gf/cm ² ar			
Pressure v	withstandability				490	kPa				1.47 MPa	
Applicable	e fluid					Non-corr	osive gas				
Selectable	e units	kPa,	kgf/cm ² , bar	, psi, mmHg,	inHg	kPa	, kgf/cm ² , ba	r, psi	MPa	, kgf/cm², ba	ır, psi
Supply vo	Itage				12 to 24 V	DC + 10 %	Ripple P-P 10) % or less			
	onsumption						or less				
(Compara Compara	ive outputs ative Output 1 ative Output 2	NPN open-c • Maximu • Applied vo	collector tran im sink curre oltage: 30 V DC al voltage: 1		en comparative o	utput and 0 V) current) current)	PNP open- • Maxim • Applied • Residu	collector tran um source c voltage: 30 V D	dard PNP out sistor urrent: 100 m C or less (betwee V or less (at	A en comparative	output and $\pm V$
Utiliza	ation category						or DC-13				
Outpu	ut modes	Equipped v		mo	de (selectab	le by key ope	eration)		ut mode, auto		ivity setting
Hyste				1 digit (howe					using psi unit)	
Repe	atability	Within ± 0.2 % F.S. ± 1 digit									
Resp	onse time	2.5 ms or less									
Short	-circuit protection					Incorp	orated				
Analog voltage output		Output voltage: 1 to 5 V (over rated pressure range) Zero-point: within 1 V ± 5 % F.S. Span: within 4 V ± 5 % F.S. Linearity: within ± 1 % F.S. Output impedance: 1 kΩ approx.									
Display				3 ¹ / ₂ 0	ligit red LED	display (Sam	pling rate: 4	times/sec. ap	prox.)		
Displa	ayable pressure range	$ \left\{ \begin{array}{c} 5.1 \text{ to} - 101.3 \text{ kPa} \\ 0.052 \text{ to} - 1.033 \text{ kgf/cm}^2, 0.051 \text{ to} - 1.013 \text{ bar} \\ 0.74 \text{ to} - 14.70 \text{ psi, } 38 \text{ to} - 760 \text{ mmHg} \\ 1.5 \text{ to} - 29.9 \text{ inHg} \end{array} \right\} \left\{ \begin{array}{c} -5.0 \text{ to} 100.0 \text{ kPa} \\ -0.051 \text{ to} 1.020 \text{ kgf/cm}^2 \\ -0.050 \text{ to} 1.000 \text{ bar} \\ -0.72 \text{ to} 14.50 \text{ psi} \end{array} \right\} \left\{ \begin{array}{c} -0.51 \text{ to} 10.20 \text{ kgf/cm}^2 \\ -0.50 \text{ to} 1.000 \text{ bar} \\ -7.2 \text{ to} 145.0 \text{ psi} \end{array} \right\} \right. $									
Analog ba	ır display	LED bar display in steps of 10 % F.S. approx.									
Operation		Orange LED (lights up when Comparative Output 1 is ON)									
indicators	Comparative Output 2	Green LED (lights up when Comparative Output 2 is ON)									
	tion degree	3 (Industrial environment)									
Prote	ction	Standard, Flat and Light weight types: IP40 (IEC), IP67 type: IP67 (IEC)									
SidmA Ambie	ent temperature	- 10 to $+$ 50 °C $+$ 14 to $+$ 122 °F (No dew condensation or icing allowed), Storage: $-$ 10 to $+$ 60 °C $+$ 14 to $+$ 140 °F									
Ambie EMC Voltage Vibrati	ent humidity				35 to 8	5 % RH, Sto	rage: 35 to 8	5 % RH			
EMC		EN 50081-2, EN 50082-2, EN 61000-6-2									
E Voltag	ge withstandability		1,000	V AC for on	e min. betwe	en all supply	terminals co	nnected toge	ther and encl	osure	
2 Insula	ation resistance	5	50 MΩ, or m	ore, with 500	V DC megge	er between al	supply term	inals connec	ted together a	and enclosure	e
∐ Vibrat	tion resistance	10 to 150 Hz frequency, 0.75 mm 0.030 in amplitude in X, Y and Z directions for two hours each									
Shock	k resistance	100 m/s ² acceleration (10 G approx.) in X, Y and Z directions for three times each									
Temperatu	ure characteristics	Over amb	ient tempera	ure range —	10 to + 50 °C	+ 14 to + 12	2°F : within ∃	1 % F.S. of	detected press	sure at +20	°C + 68 °F
D	Asian		Standar	d, Flat and IF	P67 types: Ro	(PT) ¹ /8 fem	ale thread, L	ight weight ty	pe: M5 fema	le thread	
Pressure port	North American		Sta	andard type:	NPTF 1/8 fen	nale thread, F	lat and IP67	types: NPT	1/8 female thre	ead	
port	European				Flat and	P67 types: G	(PF) ¹ / ₈ fem	ale thread			
Material		Pressure por	t attachment		alloy [Light v		lay surface: A OM (glass fibe		, pressure por	t is brass (nic	kel plated)]
Cable			0.15 m	m ² 5-core oil	resistant cab	tyre cable, 2	m 6.562 ft lo	ng (IP67 type	e: 5 m 16.404	ft long)	
Cable exte	ension	Extension up	to total 100 r	n 328.084 ft (le	ess than 10 m	32.808 ft wher	n conforming t	o CE marking	is possible wi	th 0.3 mm ² , or	more, cable.
Weight		Stan	idard type: 9	5 g approx.,	Flat type: 120	g approx., I	P67 type: 370	g approx.,	_ight weight t	ype: 70 g app	orox.
Accessori	es		Hexagon-	socket-head	plug for pres	sure port: 1 p	c. (Standard	type only), F	ressure unit l	abel: 1 pc.	
		Hexagon-socket-head plug for pressure port: 1 pc. (Standard type only), Pressure unit label: 1 pc.									


Note: Model Nos. of North American standard type having the suffix '-P' are PNP output type.

DP2

I/O CIRCUIT AND WIRING DIAGRAMS

NPN output type

I/O circuit diagram




Notes:1) When using the analog voltage output, take care to connect external device of proper input impedance. Also, when a cable extension is used, voltage drop due to cable resistance should be taken into account.

 The analog voltage output does not incorporate a shortcircuit protection circuit.
 Do not connect it directly to a power supply or a capacitive load.


Symbols ... D: Reverse supply polarity protection diode Z_{D1}, Z_{D2}, Z_{D3}: Surge absorption zener diode Tr₁, Tr₂: NPN output transistor

Wiring diagram



PNP output type

I/O circuit diagram



Notes:1) When using the analog voltage output, take care to connect external device of proper input impedance. Also, when a cable extension is used, voltage drop due to cable resistance should be taken into account.


The analog voltage output does not incorporate a short-circuit protection circuit.

Do not connect it directly to a power supply or a

Do not connect it directly to a power supply or a capacitive load.

Symbols ... D: Reverse supply polarity protection diode ZD1, ZD2, ZD3: Surge absorption zener diode Tr1, Tr2: PNP output transistor

Wiring diagram



All models




 This product is not a safety sensor. Its use is not intended or designed to protect life and prevent body injury or property damage from dangerous parts of machinery. It is a normal pressure detection sensor.

 The DP2 series is designed for use with noncorrosive gas. It cannot be used with liquid or corrosive gas.

Operation

- If setting is impossible even with pressing the MODE key, verify whether the key-protect function is enabled. Please note that pressing down on the MODE key for an extended moment will enable the key-protect function as soon as the key is released.
- If using the window comparator mode, set the pressure value so that there is a difference of 3 digits, or more, between Set Value 1 (P-1) and Set Value 2 (P-2). No output will be possible with a 0 to 2 digit difference.

Functional description



		<u> </u>					
	Description	Function					
1	31/2 digit LED Displays measured pressure, settings, error messages and key-protect status.						
2	Comparative Output 1 operation indicator (Orange) Lights up when Comparative Output 1 is ON.						
3	Comparative Output 2 operation indicator (Green) Lights up when Comparative Output 2 is O						
4	Increment key (()	In the initial setting mode, pressing the key changes the settable digit. In the Set Value 1, 2 modes, pressing the key changes the set value to the high pressure side in case of positive pressure type sensor and to the high vacuum side in case of vacuum pressure type sensor. In the sensing mode, if the key is pressed continuously for 4 sec. or more, the display shows peak hold value. In the initial setting mode, pressing the key changes the set conditions. In the Set Value 1, 2 modes, pressing the key changes the set value to the low pressure side in case of positive pressure type sensor and to the low vacuum side in case of vacuum pressure type sensor. In the sensing mode, if the key is					
(5)	Decrement key ((▽)	In the initial setting mode, pressing the key changes the set conditions. In the Set Value 1, 2 modes, pressing the key changes the set value to the low pressure side in case of positive pressure type sensor and to the low vacuum side in case of vacuum pressure type sensor. In the sensing mode, if the key is pressed continuously for 4 sec. or more, the display shows bottom hold value.					
6	Mode selection key	Each press of the key changes the selected mode to sensing mode, Set Value 1 (P-1) set mode and Set Value 2 (P-2) set mode. In the sensing mode, if the key is pressed continuously for about 3 sec., key-protect can be set / released. In the sensing mode, if the mode selection key is pressed while pressing the increment					

key ((), the initial setting mode is obtained.

Error messages

• When an error occurs, take the following corrective action.

Error message		Cause	Corrective action
<u>E-1</u>	Overcur circuit.	rrent due to short-	Switch off the power supply and check the load.
[-3		e is being applied zero-point adjust-	Applied pressure at the pressure port should be brought to atmospheric pressure and zero-point adjustment should be done again.
	Positive pressure type	Applied pressure exceeds the upper limit of displayable pressure range.	
	Vacuum pressure type	Applied pressure exceeds the lower limit of displayable pressure range.	Applied pressure should be
	Positive pressure type	Applied pressure exceeds the lower limit of displayable pressure range.	brought within the rated pressure range.
	Vacuum pressure type	Applied pressure exceeds the upper limit of displayable pressure range.	

Wiring

The analog voltage output does not incorporate a short-circuit protection circuit. Do not directly connect a power supply or a capacitive load.

- · Make sure that the power supply is off while wiring.
- · Verify that the supply voltage variation is within the rating.
- If power is supplied from a commercial switching regulator, ensure that the frame ground (F.G.) terminal of the power supply is connected to an actual ground.
- In case noise generating equipment (switching regulator, inverter motor, etc.) is used in the vicinity of this sensor, connect the frame ground (F.G.) terminal of the equipment to an actual ground.
- Do not run the wires together with high-voltage lines or power lines or put them in the same raceway. This can cause malfunction due to induction.

Conditions in use for CE conformity

 The DP2 series is a CE conformity product complying with EMC Directive. The harmonized standard with regard to immunity that applies to this product is EN 61000-6-2 (Note) and the following condition must be met to conform to that standard.

Condition

 The sensor should be connected <u>less than 10 m 32.808 ft</u> from the power supply.

Note: The EN 50082-2 that previously applied to the products for conforming to EMC Directive was replaced by EN 61000-6-2 starting April 1st, 2002.

All models

Setting

- If key-protect has been set, make sure to release key-protect before operating the keys. (Please refer to '**Key-protect function**' on p.801 for the procedure.)
- Set Value 1 (P-1) and Set Value 2 (P-2) can be made common for all the output modes.
- The setting of Set Value 2 (P-2) with respect to Set Value 1 (P-1) can only be towards the high pressure side in case of the positive pressure type sensor and only towards the high vacuum side in case of the vacuum pressure type sensor.
- Set Value 3 (P-3) is automatically set to the mid-value of Set Value 1 (P-1) and Set Value 2 (P-2).
 (When setting the pressure value for the automatic sensitivity mode)
- The conditions which are set are stored in an EEPROM. Kindly note that the EEPROM has a life span and its guaranteed life is 100,000 write operation cycles.

Setting procedure

① Zero-point adjustment Adjust zero-point

② Initial setting Set 'Display', 'Output mode', and 'Unit'

1 Zero-point adjustment

 The displayed pressure when the pressure port is left open is adjusted to zero.




- The sensor will automatically enter the sensing mode when power is supplied.
- Let the pressure port be at atmospheric pressure (i.e., no applied pressure condition), and press, simultaneously, the increment and decrement keys continuously.
- Is displayed and, when the fingers are released, zero-point adjustment is completed and the sensor returns to the sensing mode.

2 Initial setting

 Pressure 'Unit', 'Display' and 'Output mode' of the comparative outputs are set.



- (Initial setting is displayed.
- If sensor is being used for the first time, FHG is displayed.
- The settable digit blinks.
- The settable digit changes when $\ \ \ \,$ key is pressed and the setting is changed when $\ \ \,$ key is pressed.



③ Pressure value setting

Enter Set Value 1 (P-1), Set Value 2 (P-2), Set Value 3 (P-3)

Measurement

Commence measurement on completion of setting

3 Pressure value setting

For the case when output mode is set to either hysteresis mode ($\mathcal H$), window comparator mode ($\mathcal L$) or dual output mode ($\mathcal L$).

• 'Set Value 1 (P-1)' and Set Value 2 (P-2)' of the comparative outputs are set.



- Press es key in the sensing mode to set to Set Value 1 (P-1) set mode.
- Enter Set Value 1 (P-1) using

 key and

 key.
- •Then, press ee key to set to Set Value 2 (P-2) set mode.
- Enter Set Value 2 (P-2) using △ key and ¬ key.
- Then, press week key to set to sensing mode.

For the case when output mode is set to automatic sensitivity setting mode ($\ensuremath{\mathcal{R}}$).

• 'Set Value 1 (P-1)', 'Set Value 2 (P-2)' and 'Set Value 3 (P-3)' of the comparative outputs are set.



- Press weekey in the sensing mode to set to Set Value 1 (P-1) set mode.
- Within the required permissible pressure range, having created a pressure state which is nearest to the atmospheric pressure, press (\$\overline{\text{T}}\$ key to enter Set Value 1 (P-1).
- Then, press we key to set to Set Value 2 (P-2) set mode.
- Within the required permissible pressure range, having created a pressure state which is nearest to the high pressure end (for a positive pressure type sensor) or the high vacuum end (for a vacuum pressure type sensor), press (a) key to enter Set Value 2 (P-2).
- Then, press es key to set to Set Value 3 (P-3) set mode.
- After checking and setting, press well key to set to sensing mode.
- The automatically set Set Value 3 (P-3) can be manually changed to a value between Set Value 1 (P-1) and Set Value 2 (P-2).
- If using the window comparator mode, set the pressure value so that there is a difference of 3 digits, or more, between Set Value 1 (P-1) and Set Value 2 (P-2). No output will be possible with a 0 to 2 digit difference.

All models

Conversion of pressure units

• In the **DP2** series, the conversion to different units is automatically done on changing the setting of the pressure unit. However, this conversion can also be obtained by multiplying the values by the coefficients given in the table on the right.

Conversion procedure

• For example, if 2 kPa is to be expressed in kgf/cm²,

since 1 kPa = 1.01972×10^{-2} kgf/cm², 2 kPa becomes

 $2 \times 1.01972 \times 10^{-2} \rightleftharpoons 0.020 \text{ kgf/cm}^2$.

Conversion table for pressure units

	kPa	MPa	kgf/cm ²			mmHg (Torr)	inHg	atm
1 kPa	1	1 × 10 ⁻³	1.01972×10 ⁻²	1 × 10 ⁻²	1.45038 × 10 ⁻¹	7.50062	0.2953	9.86923 × 10 ⁻³
1 MPa	1×10 ³	1	1.01972×10	1×10	1.45038 × 10 ²	7.50062×10^{3}	0.2953×10^{3}	9.86923
1 kgf/cm ²	9.80665×10	9.80665 × 10 ⁻²	1	9.80665×10 ⁻¹	1.42234×10	7.35559 × 10 ²	2.8959×10	9.67841 × 10 ⁻¹
1 bar	1×10 ²	1 × 10 ⁻¹	1.01972	1	1.45038 × 10	7.50062 × 10 ²	2.953×10	9.86923 × 10 ⁻¹
1 psi	6.89473		7.03065×10^{-2}	6.89473×10 ⁻²	1	5.17147×10	2.036	6.80457 × 10 ⁻²
1 mmHg (1 Torr)	1.33322×10 ⁻¹	1.33322×10 ⁻⁴	1.35951 × 10⁻³	1.33322 × 10⁻³	1.93368 × 10 ⁻²	1	3.9370×10 ⁻²	1.31579 × 10 ⁻³
1 inHg	3.3864	3.3864 × 10 ⁻³	3.4531 × 10 ⁻²	3.3864 × 10 ⁻²	0.4912	2.5400×10	1	3.342×10^{-2}
1 atm	1.01325×10 ²	1.01325 × 10 ⁻¹	1.03323	1.01325	1.46960×10	7.60000 × 10 ²	2.9921 × 10	1

Key-protect function

 Key-protect is a function which prevents any unintentional change in the conditions which have been entered in each setting mode by making the sensor not to respond to the key operations.

Setting of key-protect



- In the sensing mode, press expected key continuously for about 3 sec. and release it immediately when a is displayed.
- (• Key-protect is set and the sensor returns to the sensing mode.

Release of key-protect



- Key-protect is released and the sensor returns to the sensing mode.

Others


- Use within the rated pressure range.
- Do not apply pressure exceeding the pressure withstandability value. The diaphragm will get damaged and correct operation shall not be maintained.
- Do not use during the initial transient time (0.5 sec.) after the power supply is switched on.
- Avoid use of standard type, flat type and light weight type of sensors in places where steam and dust is excessive.
- Take care that the sensor does not come in direct contact with water, oil, grease, or organic solvents, such as, thinner, etc.
- Do not insert wires, etc., into the pressure port. The diaphragm will get damaged and correct operation shall not be maintained.
- Do not operate the keys with pointed or sharp objects.

Standard type

Setting of pressure lead direction

•The pressure lead direction can be changed by dismantling the pressure port attachment and changing the mounting direction. The tightening torque of the hexagon-socket-head bolt (length: 9 mm 0.354 in or less) should be 0.29 N·m or less.

Note: Make sure to close any unused pressure port with the hexagonsocket-head plug supplied as accessory.



Piping


· When connecting a hexagon-socket-head plug or coupling to the pressure port, hold the hexagonal part of the pressure port with a 12 mm 0.472 in spanner and make sure that the tightening torque is 9.8 N·m or less. Also, in order to prevent any leakage, wind a sealing tape on the coupling when connecting.

However, sealing tape is not required for North American type (DP2-□F□) using NPTF 1/8 coupling. (Sealing tape is required if NPT 1/8 coupling is used.)



Mounting


• When mounting the sensor with the sensor mounting bracket, etc., the tightening torque should be 1.2 N·m or



Flat type Light weight type


Setting of pressure lead direction

•The pressure lead direction can be changed by dismantling the pressure port attachment and changing the mounting direction. The tightening torque of the hexagon-socket-head bolt (length: 9 mm 0.354 in or less) should be 0.29 N·m or less.



Piping

• When connecting a coupling to the pressure port, hold the pressure port attachment with a 16 mm 0.630 in (light weight type: 10 mm 0.394 in) spanner and make sure that the tightening torque is 9.8 N·m or less (light weight type: 1.47 N·m or less). Also, in order to prevent any leakage, wind a sealing tape on the coupling when connecting.




IP67 type

Piping for pressure measurement inlet port

• When connecting a coupling to the pressure measurement inlet port, hold the pressure port attachment with a spanner and make sure that the tightening torque is 9.8 N·m or less. Also, in order to prevent any leakage, wind a sealing tape on the coupling when connecting.

Piping for atmospheric pressure inlet port


• If there is a possibility of water entering into the sensor enclosure through the atmospheric pressure inlet port, connect a tube to the atmospheric pressure inlet port through a M5 coupling and extend the other end of the tube to a safe place. In this case, ensure that this end of the tube does not get clogged.



Fitting of front cover


• Insert the bosses on the front cover into the guide holes at the bottom of the pressure port attachment, and push in the direction of the arrow to fit the hook.

When removing the front cover, release the hook first.





DP2

DIMENSIONS (Unit: mm in) The CAD data in the dimensions can be downloaded from the SUNX website: http://www.sunx.co.jp/




Note: NPTF 1/8 female thread for North American type.





Note: NPT 1/8 female thread for North American type, and G (PF) 1/8 female thread for European type.


DIMENSIONS (Unit: mm in) The CAD data in the dimensions can be downloaded from the SUNX website: http://www.sunx.co.jp/



Note: NPT $^{1}/_{8}$ for North American type, and G (PF) $^{1}/_{8}$ for European type.

MS-DPX


Sensor mounting bracket for standard type (Optional)



Material: Cold rolled carbon steel (SPCC) (Uni-chrome plated)

(Uni-chrome plated)
Two M4 (length 6 mm 0.236 in) pan head screws and two spring washers are attached.

Assembly dimensions




DIMENSIONS (Unit: mm in) The CAD data in the dimensions can be downloaded from the SUNX website: http://www.sunx.co.jp/


MS-DPX-4

DP2

Back angled mounting bracket for standard type (Optional)



Assembly dimensions




Material: Cold rolled carbon steel (SPCC) (Uni-chrome plated)

Two M4 (length 6 mm 0.236 in) pan head screws and two spring washers are attached.

MS-DPX-2 DPX-04


Panel mounting bracket, front protection cover for standard type (Optional)

Assembly dimensions



portion shows the front protection cover. Material: Polycarbonate (Front protection cover) Nylon 6, Stainless steel (SUS304)(Panel mounting bracket)

Panel cut-out dimensions



Note: The panel thickness should be 1 to 3.2 mm 0.039 to 0126 in.