



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of “Quality Parts,Customers Priority,Honest Operation,and Considerate Service”,our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832


Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China





How to use F6 tool...



If you have ever run wiring through split tubing you know that it can be frustrating. Without this tool, the more wires you have, the harder it is. When you have to add a wire, it can really slow you down.

With this premium wire loom tool, you can add and remove wires quickly and easily. Simply gather the wires you want into the installation tool and then insert the tool and wires into any split tubing or semi-rigid sleeving like Flexo F6. Run the tool through the tubing, smooth it out with your hand and you are finished.



Step 1
Rotate the barrel to line up the slot and insert your wire bundle



Step 2
Rotate the barrel to hide the slot and prevent the bundle from slipping out of the tool



Step 3
Insert the bulge of the tool into your tubing. Make sure that the end of the bundle is properly seated in the tubing

Step 4
Gently slide the tool along the length of the tubing, inserting the wire bundle as you move down the sleeving



Step 5
Run your hand over the length of the installation to smooth out any imperfections.



INN0.25OR
Split Tubing Installation Tool
for bundles up to 1/4"



INN1.00OR
Split Tubing Installation Tool
for bundles up to 1"



INN0.50OR
Split Tubing Installation Tool
for bundles up to 1/2"



INN1.50OR
Split Tubing Installation Tool
for bundles up to 1 1/2"



INN0.75OR
Split Tubing Installation Tool
for bundles up to 3/4"