

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China









General Description

The MAX3746 evaluation kit (EV kit) simplifies evaluation of the MAX3746 limiting amplifier. The EV kit allows for quick threshold level selections, provides a RSSI output signal (when used with the MAX3744) and includes a calibration circuit. The MAX3746 EV kit is fully assembled and tested.

Component List

DESIGNATION	QTY	DESCRIPTION
C1 C2 C7 C10	_	1000pF 10% 10V min
C1, C2, C7, C10	4	ceramic capacitor (0201)
C3, C4, C6, C8,	12	0. 1 μF, 10% 10V min
C9, C11, C14-C18		ceramic capacitor (0402)
C20	1	2.2μF, 10%, 10V min
C21	1	ceramic capacitor (0805)
	1	33μF 10V min 5% tantalum 30.1k Ω, 1% resistor (0402)
R1	'	` ,
R3		2k Ω, 1% resistor (0402)
R4	1	14k Ω, 1% resistor (0402)
R5	1	24.9k Ω, 1% resistor (0402)
R6	1	4.75k Ω, 1% resistor (0402)
R7	1	10k Ω, 1% resistor (0402)
R8	1	3.01k Ω, 1% resistor (0402)
L1	1	1.2μH, 5% Chip inductor
JU2-JU5, JU9,	5	Jumper blocks, 2 Pins 0.1" spacing
JU6, JU7	3	Jumper blocks, 3 Pins 0.1"
JU8	1	Jumper block, 3 Pins +1 Pin 0.1"
TP2, TP3, TP9, TP10	4	Test point Digikey 5000K- ND
JU2-JU9	8	Shunts
J1-J8	8	SMA edge mount tab Johnson 142-0701-851
U1		MAX3746EGE
	1	MAX3746 Rev A Evaluation Circuit Board

Features

- ♦ Fully Assembled and Tested
- Test Point for Easy Monitoring of LOS
- ♦ Polarity Reversal Control
- Jumpers Allow Quick Selection for Loss of Signal Threshold Level

Ordering Information

PART	TEMP. RANGE	IC PACKAGE
MAX3746EVKIT	-40°C to +85°C	16 QFN

Component Suppliers

SUPPLIER	PHONE	FAX
AVX	843-444-2863	843-626-3123
Coilcraft	847-639-6400	847-639-1469
Murata	415-964-6321	415-964-8165

Note: Please indicate that you are using the MAX3746 when ordering from these suppliers.

Quick Start

- 1) Connect OUT+ and OUT- to a 50Ω terminated oscilloscope.
- Connect IN+ and IN- to a 500mV_{P-P}, 3.2Gbps differential data stream.
- 3) Remove all shunts.
- Shunt JU8 to V_{CC} so that there is no inversion of signal polarity. (OUTPOL, V_{CC}). Figure 2 shows the jumper diagram for the board.
- 5) Shunt JU4 connecting R3 = 13k Ω (R_{TH}).
- 6) Shunt JU6 connecting R7 = $10k \Omega$ (R_{LOS}).
- 7) Shunt JU5 connecting pin LOS to DISABLE.

- 8) Connect TP2 to V_{CC} .
- 9) Connect the power-supply ground to the GND pad and then connect a +3.3V power supply to the V_{CC}.
- Observe a limited signal at the output, roughly 0.8V_{0.0}.
- 11) Lower the amplitude of the input signal from $500 mV_{p-p}$ to $15 mV_{p-p}$ or less. The output signal is squelched.

Adjustment and Control Descriptions (see Quick Start first)

NAME	FUNCTION
JU2, JU3, JU4	Selects loss of signal assert/deassert level.
JU5	Shunt to connect the LOS pin to the DISABLE pin (Squelch)
JU6	Shunt to connect series resistor from LOS to test point TP2. Make sure TP2 is connected to a positive supply.
JU7	Disable. Shunting to V _{CC} holds the outputs static.
JU8	Shunt center pin (OUTPOL) to V_{CC} for full-swing non-inverted output signal. Shunt to GND to have an inverted full-swing output. Leave open for reduced-amplitude non-inverted output. Connect to $30 \text{k}\Omega$ for reduced-amplitude inverted output signal.
JU9	Shunt to connect RSSI output to RSSI resistor R8.

2______M/XI/M




Figure 1. MAX3746 electrical schematic.

/U/IXI/W




Figure 2. Jumper Diagram.




Figure 3. MAX3746 EV Kit Component Placement Guide - Component Side (2X)




Figure 4. MAX3746 EV Kit PC Board Layout – Component Side (2X)




Figure 5. MAX3748A EV Kit PC Board Layout – Ground Plane (2X)




Figure 6. MAX3746 EV Kit PC Board Layout – Power Plane (2X)




Figure 7. MAX3746 EV Kit PC Board Layout – Solder Side (2X)

Maxim makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Maxim assume any liability arising out of the application or use of any product or circuit and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters can and do vary in different applications. All operation parameters, including "typicals" must be validated for each customer application by customer's technical experts. Maxim products are not designed, intended or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Maxim product could create a situation where personal injury or death may occur.

Maxim cannot assume responsibility for use of any circuitry other than circuitry entirely embodied in a Maxim product. No circuit patent licenses are implied. Maxim reserves the right to change the circuitry and specifications without notice at any time.