



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of “Quality Parts,Customers Priority,Honest Operation,and Considerate Service”,our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China



Test Procedure for the NCP1236 Demoboard NCP1236B65NBGEVB



05/31/2011

Required Equipment:

Current limited 90 ÷ 265 Vrms AC source (current limited to avoid board destruction in case of defective part) (e.g. AGILENT 6811)	1pc
AC Volt-Meter able to measure up to 300 V AC (e.g. KEITHLEY 2000)	1pc
AC Amp-Meter able to measure up to 3 A AC (e.g. KEITHLEY 2000)	1pc
DC Amp-Meter able to measure up to 5 A DC (e.g. FLUKE 89 IV).....	1pc
DC Volt-Meter able to measure up to 30 V DC (e.g. KEITHLEY 2000)	1pc
DC Electronic Load (e.g. AGILENT 6060B)	1pc



Figure 1: Test Setup

The following steps describe the test procedure for all these boards:

Test Procedure:

1. Connect the test setup as shown in Figure 1.
2. Apply an input voltage, $V_{IN} = 90 \div 265 \text{ Vac}$
3. Apply $I_{OUT}(\text{load}) = 0 \text{ A}$
4. Check that $V_{OUT} = 19 \text{ Vdc}$
5. Set I_{OUT} to 3.5 A
6. Check that $V_{OUT} = 19 \text{ Vdc}$
7. Turn off the load
8. Turn off V_{IN}
9. End of the test

Be careful when manipulating the boards in operation, lethal voltages up to 425V are present on the primary side. An isolation transformer is also recommended for safer manipulations.