



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of “Quality Parts,Customers Priority,Honest Operation,and Considerate Service”,our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China





Test Procedure for the NCP2809A Evaluation Board

Equipment Needed:

- DC Power Supply
- Function Generator
- Oscilloscope
- Digital Multimeter

The procedure described below can be used for each schematic.

- Set $V_p = 5\text{ V}$ to power supply connector.
- Set two 16 Ohm loads (resistance) on the 3 points of output connector J3 and J9.
- With your Function Generator, set a sinewave signal at 1kHz and 1Vrms for the input signal. Connect it to the input connector (J2 & J8): between IN_R and GND for the right output and once measured, between IN_L and GND for the left one.
- In case of the big output capacitors schematic, place 1 oscilloscope probe on each output (Right & Left) and you should get a 1Vrms output signal with a "perfect sinewave". That is to say no clipping at the minimum and maximum of the sinewave.
- In case of the capless schematic, place 2 oscilloscope probes on each output (Right & Left) and the virtual ground and you should get a 1 Vrms differential output signal with a "perfect sinewave". That is to say no clipping at the minimum and maximum of the sinewave.
- **During the test with the capless schematic, be careful not to connect the ground to the virtual ground on the output! If you do so, you'll need to solder another NCP2809A.**

This is the only test performed. You could also check the quiescent current. Place two 16 Ohm loads, no input signal, V_p set to 5V and you should measure around 1.9 mA.