## imall

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



### Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832 Email & Skype: info@chipsmall.com Web: www.chipsmall.com Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China



# PA52-P(Z)P Data Sheet 52 pin PLCC socket/52 pin PLCC plug


#### Supported Device/Footprints

These adapters accepts 52 pin PLCC devices and plugs into 52 pin PLCC production sockets. Test points are provided near the edges of the circuit board.

Socket			Plug		
Mfgr	Device	Package	Device	Package	
Many	52 pin	PLCC	52 pin	PLCC	

#### Adapter Dimensions

0.216



Press' device to close, press rim to open

## 

2.075

#### PA52-PP

#### Adapter Construction

The adapter is made up of 2 sub-assemblies. They assemble via connectors making the adapter modular. This way the sub-assemblies can be replaced when they wear out.

When disassembling the adapter take care not to bend the pins. When reassembling the adapter note the pin 1 indicators to align the parts correctly.

The adapters described by this datasheet and their subassemblies are:

Adapter	Test Socket	Board
PA52-PP	52-307	52-PP
PA52-PZP	52-411	52-PZP

#### Test Socket

LSC #	Style	Mfgr/Pn
52-307	Auto-Eject	Yamaichi IC120-0524-307
52-411	Lidded ZIF	Yamaichi IC51-0524-411

#### **Test Points**

These adapters offer Test Points. The Test Points are rows of plated-thru-holes (PTH) along the 4 edges of the adapter.

Grabbers may be used to hook onto the holes.

Alternately, 0.050" pitch 13 pin strips can be soldered into the holes and connections made to the strip's pins. Right angle strips should be considered for easier access to the pins.

#### Adapter Wiring

This adapter is wired 1 to 1. Pin 1 of the socket is connected to pin 1 of the plug. Pin 2 to pin 2 and so on around the adapter.

PA52-PZP

1.54