

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of “Quality Parts,Customers Priority,Honest Operation,and Considerate Service”,our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



## Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China

[Home](#) > [Products](#) > [Dev Kits & Hardware](#) > [Mixed Signal Boards](#) > [ispClock 5620A Development Kit](#)

## ispClock 5620A Development Kit

---

The ispClock 5620 Development Kit includes everything the designer needs to quickly configure and evaluate the ispClock5620A on a fully assembled printed-circuit board. The four-layer board supports a 100-pin TQFP package, a header for user I/O and a JTAG programming cable connector. SMA connectors are installed to provide high-signal integrity access to selected high-speed I/O signals. JTAG programming signals can be generated by using an ispDOWNLOAD® programming cable connected between the evaluation board and a PC. All user-programmable features of the ispPAC-CLK5620A can be easily configured using Lattice Semiconductor's PAC-Designer® software.

### Product Contents

The ispClock5620A Development Kit includes:

- ispClock5620A Evaluation Board
- ispDOWNLOAD Cable
- AC Adapter
- User Documentation



[click for enlarged view](#)

### Device Support

You will need the [PAC-Designer software](#) to use this board. PAC-Designer can be [downloaded from the Lattice web site](#).

### Ordering Information

#### Purchase Now

Part Number: PAC-SYSCLK5620AV

To purchase, visit our [online store](#).