



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of “Quality Parts,Customers Priority,Honest Operation,and Considerate Service”,our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China



SAFETY INFORMATION

The probe is designed to be safe under the following conditions:

- Indoor use
- Altitude to 2000 m
- Temperature range from 0 °C to 50 °C
- Maximum relative humidity 80 % for temperatures up to 31 °C, decreasing linearly to 40 % relative humidity at 50 °C

WARNING

Do not disassemble or disconnect probes while they are connected to a voltage source. Use only grounded oscilloscopes.



Attention: Refer to this manual before using the probe.



Danger. High Voltage.

CLEANING

The exterior of the probe only should be cleaned with a soft cloth moistened with either water or isopropyl alcohol.

USING AND MAINTENANCE

The probe user should note that the protection provided by the equipment may be impaired, if the equipment is used in a manner not specified by the manufacturer.

To guarantee accurate performance characteristics, mechanical shocks should be avoided, as well as damage to the cable through excessive bending. Handle with care, especially when the extra thin spring-tip is fitted. All maintenance should be referred to qualified personnel.

SALES & SERVICE LECROY

Corporate Headquarters

U.S.A.: Chestnut Ridge
Phone (1) 914 578 6020
Fax (1) 914 578 5985

European Headquarters

Germany: Heidelberg
Phone (49) 6221 827 00
Fax (49) 6221 834 655

ELECTRICAL CHARACTERISTICS

System attenuation: 1000:1

System input resistance: 100 M Ω

Input capacitance: < 3 pF

Compensation range: 10 pF to 65 pF

System BW (-3 dB): 100 MHz typical

Input voltage:

1. Max. voltage: ≤ 20 kV DC incl. peak AC
2. AC: ≤ 14 kV AC rms 50/60 Hz Sinus
3. HF-Sinus-AC: See derating chart
4. Pulse peak: ≤ 40 kV (see peak pulse derating chart)

HIGH VOLTAGE

PPE 20 kV



GENERAL CHARACTERISTICS

Operating temperature: 0 °C to 50 °C

Cable length: 3 m

Weight of probe + accessories: 495 gr

Coupling: 1 M Ω DC/AC

Warranty: One year


Overvoltage category: CAT I

Pollution degree: 1


LeCroy

LF PROBE ADJUSTMENT (1000:1)


Connect the probe to a 1 kHz square wave signal. Adjust compensation trimmer in the BNC-box for optimum square wave response.



Undershoot




Correct




Overshoot

HF PROBE ADJUSTMENT


If necessary the probe can be adjusted for high frequency. Connect the probe to a 1 MHz square wave signal and adjust the trimmer in order to receive an optimum square wave response.




Undershoot



Correct



Overshoot



STANDARD ACCESSORIES SUPPLIED WITH THE PROBE

Accessories

1. Trimming tool
2. Ground lead with a crocodile clip
3. Hook

Quantities

- 1
- 1
- 1

HIGH VOLTAGE PROBE KIT PK104

Accessories

1. Trimming tool
2. Ground lead with a crocodile clip
3. Hook
4. BNC Adapter

Quantities

- 1
- 1
- 1
- 1

