# imall

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



## Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832 Email & Skype: info@chipsmall.com Web: www.chipsmall.com Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China



## **RTE Series** – Analog Timers

Switches & Pilot Lights

Signaling Lights

## **Key features:**

- 20 time ranges and 10 timing functions
- Time delays up to 600 hours
- Space-saving package
- High repeat accuracy of ± 0.2%
- ON and timing OUT LED indicators
- Standard 8- or 11-pin and 11-blade termination

Cert. No. E9950913332316 (EMC, RTE)

Cert. No. BL960813332355 (LVD, RTE)

- 2 form C delayed output contacts
- 10A Contact Rating








D12 Dimensions

RTE-B1, B2





40Hx 36W x 74.9D mm

RTE-P2

89q

RTE-P1

87g



## **Contact Ratings**

CE

| Contact | Configuration                 | 2 Form C, DPDT<br>(Delay output) |
|---------|-------------------------------|----------------------------------|
|         | le Voltage /<br>le Current    | 240V AC, 30V DC / 10A            |
|         | m Permissible<br>ng Frequency | 1800 cycles per hour             |
|         | Resistive                     | 10A 240V AC, 30V DC              |
| Rated   | Inductive                     | 7A 240V AC, 30V DC               |
| Load    | Horse Power<br>Rating         | 1/6 HP 120V AC, 1/3 HP 240V AC   |
| Life    | Electrical                    | 500,000 op. minimum (Resistive)  |
| Lite    | Mechanical                    | 50,000,000 op. minimum           |


\*For the value of the error against a preset time, whichever the largest, applies.

Weight (Approx.) IDEC RTE-B1, -B2

85g

## Part Numbering Guide

RTE series part numbers are composed of 4 part number codes. When ordering a RTE series part, select one code from each category. Example: **RTE-P1AF20** 



#### **Part Numbers: RTE Series**

|                             | Description                                                                 | Part Number Code | Remarks                                             |
|-----------------------------|-----------------------------------------------------------------------------|------------------|-----------------------------------------------------|
| ① Series                    | RTE series                                                                  | RTE              | For internal circuits, see next page.               |
| Terminal Style              | Pin                                                                         | Р                | Calactions only                                     |
| <sup>©</sup> Terminal Style | Blade                                                                       | В                | Select one only.                                    |
|                             | ON-delay, interval, cycle OFF, cycle ON                                     | 1                | Each function group has different timing functions. |
| ③ Function Group            | ON-delay, cycle OFF, cycle ON, signal ON/<br>OFF delay, OFF-delay, one-shot | 2                | See page 940.                                       |
|                             | 100 to 240V AC(50/60Hz)                                                     | AF20             |                                                     |
| ⊕ Input Voltage             | 24V AC(50/60Hz)/24V DC                                                      | AD24             |                                                     |
|                             | 12V DC                                                                      | D12              |                                                     |

## **Part Numbers**

| Voltage     | Power T    | riggered   | Start Input | t Triggered |
|-------------|------------|------------|-------------|-------------|
| voltage     | 8-Pin      | Blade      | 11-Pin      | Blade       |
| 12V DC      | RTE-P1D12  | RTE-B1D12  | RTE-P2D12   | RTE-B2D12   |
| 24V AC/DC   | RTE-P1AD24 | RTE-B1AD24 | RTE-P2AD24  | RTE-B2AD24  |
| 100-240V AC | RTE-P1AF20 | RTE-B1AF20 | RTE-P2AF20  | RTE-B2AF20  |


## Time Range Determined by Time Range Selector and Dial Selector

|       | Dial     | 0 - 1           | 0 - 3           | 0 - 10           | 0 - 30           | 0 - 60           |
|-------|----------|-----------------|-----------------|------------------|------------------|------------------|
|       | Second   | 0.1 sec - 1 sec | 0.1 sec - 3 sec | 0.2 sec - 10 sec | 0.6 sec - 30 sec | 1.2 sec - 60 sec |
| Range | Minute   | 1.2 sec - 1 min | 3.6 sec - 3 min | 12 sec - 10 min  | 36 sec - 30 min  | 1.2 min - 60 min |
| Rar   | Hour     | 1.2 min - 1 hr  | 3.6 min - 3 hr  | 12 min - 10 hr   | 36 min - 30 hr   | 1.2 hr - 60 hr   |
|       | 10 Hours | 12 min - 10 hr  | 36 min - 30 hr  | 2 hr - 100 hr    | 6 hr - 300 hr    | 12 hr - 600 hr   |

IDEC 945

## **Timing Diagrams**

#### RTE-P1, -B1



1. RTE-B1: Do not apply voltage to terminals #2, #5 & #8. 2. IDEC sockets are as follows: RTE-P1: SR2P-06\* pin type socket,

DEL sockets are as follows: HTE-P1: SH2P-U6\* pin type socket, RTE-B1: SR3B-05\* blade type socket, (\*-may be followed by suffix letter A,B,C or U).

#### A: ON-Delay 1 (power start)

Set timer for desired delay, apply power to coil. Contacts transfer after preset time has elapsed, and remain in transferred position until timer is reset. Reset occurs with removal of power.

| Item      | Terminal Nur                         | nber |   | Operat | ion |  |
|-----------|--------------------------------------|------|---|--------|-----|--|
| Power     | (1) 2 - 7<br>(2) A - B               |      |   |        |     |  |
| Delayed   | (1) 1 - 4, 5 - 8<br>(2) 1 - 7, 3 - 9 | (NC) |   |        |     |  |
| Contact   | (1) 1 - 3, 6 - 8<br>(2) 4 - 7, 6 - 9 | (NO) |   |        |     |  |
| Indicator | PWR                                  |      |   |        |     |  |
| Indicator | OUT                                  |      |   |        |     |  |
| Set Time  |                                      |      | • | T      |     |  |

#### C: Cycle 1 (power start, OFF first)

Set timer for desired delay, apply power to coil. First transfer of contacts occurs after preset delay has elapsed, after the next elapse of preset delay contacts return to original position. The timer now cycles between on and off as long as power is applied (duty ratio 1:1).

| ltem      | Terminal Nur                         | nber |        |         | Op | eration |  |  |  |
|-----------|--------------------------------------|------|--------|---------|----|---------|--|--|--|
| Power     | (1) 2 - 7<br>(2) A - B               |      |        |         |    |         |  |  |  |
| Delayed   | (1) 1 - 4, 5 - 8<br>(2) 1 - 7, 3 - 9 | (NC) |        |         |    |         |  |  |  |
| Contact   | (1) 1 - 3, 6 - 8<br>(2) 4 - 7, 6 - 9 | (NO) |        |         |    |         |  |  |  |
| Indianta  | PWR                                  |      |        |         |    |         |  |  |  |
| Indicator | OUT                                  |      |        |         |    |         |  |  |  |
| Set Time  |                                      |      | ι<br>τ | ←→<br>T |    |         |  |  |  |

#### B: Interval (power start)

Set timer for desired delay, apply power to coil. Contacts transfer immediately, and return to original position after preset time has elapsed. Reset occurs with removal of power.

| Item      | Terminal Nur                         | nber |   | Opera | tion |  |
|-----------|--------------------------------------|------|---|-------|------|--|
| Power     | (1) 2 - 7<br>(2) A - B               |      |   |       |      |  |
| Delayed   | (1) 1 - 4, 5 - 8<br>(2) 1 - 7, 3 - 9 | (NC) |   |       |      |  |
| Contact   | (1) 1 - 3, 6 - 8<br>(2) 4 - 7, 6 - 9 | (NO) |   |       |      |  |
| Indicator | PWR                                  |      |   |       |      |  |
| Indicator | OUT                                  |      |   |       |      |  |
| Set Time  |                                      |      | 4 | т     | •    |  |


#### D: Cycle 3 (power start, ON first)

Functions in same manner as Mode C, with the exception that first transfer of contacts occurs as soon as power is applies. The ratio is 1:1. Time On = Time Off

| ltem      | Terminal Nu                          | nber |  |    | Op | eration |  |  |
|-----------|--------------------------------------|------|--|----|----|---------|--|--|
| Power     | (1) 2 - 7<br>(2) A - B               |      |  |    |    |         |  |  |
| Delayed   | (1) 1 - 4, 5 - 8<br>(2) 1 - 7, 3 - 9 | (NC) |  |    |    |         |  |  |
| Contact   | (1) 1 - 3, 6 - 8<br>(2) 4 - 7, 6 - 9 | (NO) |  |    |    |         |  |  |
| Indiantas | PWR                                  |      |  |    |    |         |  |  |
| Indicator | OUT                                  |      |  |    |    |         |  |  |
| Set Time  |                                      |      |  | <> |    |         |  |  |

**Circuit Breakers** 

RTE-P2, -B2





A: ON-Delay 2 (signal start)

When a preset time has elapsed after the start input turned on while power is on, the NO output contact goes on.

| Item      | Terminal Nur                          | nber |   | Operat | ion |  |  |
|-----------|---------------------------------------|------|---|--------|-----|--|--|
| Power     | (A) 2 - 10<br>(B) A - B               |      |   |        |     |  |  |
| Start     | (A) 5 - 6<br>(B) 2 - 5                |      |   |        |     |  |  |
| Delayed   | (A) 1 - 4, 8 - 11<br>(B) 1 - 7, 3 - 9 | (NC) |   |        |     |  |  |
| Contact   | (A) 1 - 3, 9 - 11<br>(B) 4 - 7, 6 - 9 | (NO) |   |        |     |  |  |
| Indicator | PWR                                   |      |   |        |     |  |  |
| Indicator | OUT                                   |      |   |        |     |  |  |
| Set Time  |                                       |      | - | r      | •   |  |  |

C: Cycle 4 (signal start, ON first)

When the start input turns on while power is on, the NO contact goes on. The output oscillates at a preset cycle (duty ratio 1:1).

| Item      | Terminal Nur                          | nber |  |  | Operat | tion                 |     |       |            |   |
|-----------|---------------------------------------|------|--|--|--------|----------------------|-----|-------|------------|---|
| Power     | (A) 2 - 10<br>(B) A - B               |      |  |  |        |                      |     |       |            |   |
| Start     | (A) 5 - 6<br>(B) 2 - 5                |      |  |  |        |                      |     |       |            |   |
| Delayed   | (A) 1 - 4, 8 - 11<br>(B) 1 - 7, 3 - 9 | (NC) |  |  |        |                      |     |       |            |   |
| Contact   | (A) 1 - 3, 9 - 11<br>(B) 4 - 7, 6 - 9 | (NO) |  |  |        |                      |     |       |            |   |
| Indicator | PWR                                   |      |  |  |        |                      |     |       |            |   |
| indicator | OUT                                   |      |  |  |        |                      |     |       |            |   |
| Set Time  |                                       |      |  |  |        | ∮ <del></del> •<br>T | T T | <br>T | <b>T</b> a | • |

#### E: Signal OFF-Delay

When power is turned on while the start input is on, the NO output contact goes on. When a preset time has elapsed after the start input turned off, the NO output contact goes off.

| ltem      | Terminal Nur                          | nber |  |        |   | Op | eration          |   |        |          |                |   |
|-----------|---------------------------------------|------|--|--------|---|----|------------------|---|--------|----------|----------------|---|
| Power     | (A) 2 - 10<br>(B) A - B               |      |  |        |   |    |                  |   |        |          |                |   |
| Start     | (A) 5 - 6<br>(B) 2 - 5                |      |  |        |   |    |                  |   |        |          |                |   |
| Delayed   | (A) 1 - 4, 8 - 11<br>(B) 1 - 7, 3 - 9 | (NC) |  |        |   |    |                  |   |        |          |                |   |
| Contact   | (A) 1 - 3, 9 - 11<br>(B) 4 - 7, 6 - 9 | (NO) |  |        |   |    |                  |   |        |          |                |   |
| Indicator | PWR                                   |      |  |        |   |    |                  |   |        |          |                |   |
| Indicator | OUT                                   |      |  |        |   |    |                  |   |        |          |                |   |
| Set Time  |                                       |      |  | ₹<br>T | - |    | <b>∢</b> →<br>Ta | - | ₹<br>T | <b>•</b> | <b>≺</b><br>Ta | > |

1. RTE-P2: Do not apply voltage to terminals #5, #6 & #7.

2. RTE-B2: Do not apply voltage to terminals #2, #5 & #8.

3. IDEC sockets are as follows: RTE-P2: SR3P-05\* pin type socket, RTE-B2: SR3B-05\* blade type socket, (\*-may be followed by suffix letter A,B,C or U).

#### B: Cycle 2 (signal start, OFF first)

When the start input turns on while power is on, the output oscillates at a preset cycle (duty ratio 1:1), starting while the NO contact off.

| ltem      | Terminal Nur                          | nber |  |        |                         |            | Operat | tion |     |   |    |  |
|-----------|---------------------------------------|------|--|--------|-------------------------|------------|--------|------|-----|---|----|--|
| Power     | (A) 2 - 10<br>(B) A - B               |      |  |        |                         |            |        |      |     |   |    |  |
| Start     | (A) 5 - 6<br>(B) 2 - 5                |      |  |        |                         |            |        |      |     |   |    |  |
| Delayed   | (A) 1 - 4, 8 - 11<br>(B) 1 - 7, 3 - 9 | (NC) |  |        |                         |            |        |      |     |   |    |  |
| Contact   | (A) 1 - 3, 9 - 11<br>(B) 4 - 7, 6 - 9 | (NO) |  |        |                         |            |        |      |     |   |    |  |
| Indicator | PWR                                   |      |  |        |                         |            |        |      |     |   |    |  |
| muicator  | OUT                                   |      |  |        |                         |            |        |      |     |   |    |  |
| Set Time  |                                       |      |  | ×<br>T | ∳ <del>- − −</del><br>T | - <b>T</b> |        |      | T T | T | Ta |  |

#### D: Signal ON/OFF-Delay

When the start input turns on while power is on, the NO output contact goes on. When a preset time has elapsed while the start input remains on, the output contact goes off. When the start input turns off, the NO contact goes on again. When a preset time has elapsed after the start input turned off, the NO contact goes off.

| Item               | Terminal Number                       |      | Operation |        |   |          |   |                |            |   |        |   |          |   |
|--------------------|---------------------------------------|------|-----------|--------|---|----------|---|----------------|------------|---|--------|---|----------|---|
| Power              | (A) 2 - 10<br>(B) A - B               |      |           |        |   |          |   |                |            |   |        |   |          |   |
| Start              | (A) 5 - 6<br>(B) 2 - 5                |      |           |        |   |          |   |                |            |   |        |   |          |   |
| Delayed<br>Contact | (A) 1 - 4, 8 - 11<br>(B) 1 - 7, 3 - 9 | (NC) |           |        |   |          |   |                |            |   |        |   |          |   |
|                    | (A) 1 - 3, 9 - 11<br>(B) 4 - 7, 6 - 9 | (NO) |           |        |   |          |   |                |            |   |        |   |          |   |
| Indicator          | PWR                                   |      |           |        |   |          |   |                |            |   |        |   |          |   |
|                    | OUT                                   |      |           |        |   |          |   |                |            |   |        |   |          |   |
| Set Time           |                                       |      |           | τ<br>T | + | <b>∢</b> | • | <b>→</b><br>Ta | - <b>-</b> | - | ₹<br>T | Þ | ←→<br>Ta | - |

#### F: One-Shot (signal start)

When the start input turns on while power is on, the NO output contact goes on. When a preset time has elapsed, the NO output contact goes off.

| ltem     | Terminal Number                       |      | Operation |  |
|----------|---------------------------------------|------|-----------|--|
| Power    | (A) 2 - 10<br>(B) A - B               |      |           |  |
| Start    | (A) 5 - 6<br>(B) 2 - 5                |      |           |  |
| Delayed  | (A) 1 - 4, 8 - 11<br>(B) 1 - 7, 3 - 9 | (NC) |           |  |
| Contact  | (A) 1 - 3, 9 - 11<br>(B) 4 - 7, 6 - 9 | (NO) |           |  |
| PWR      |                                       |      |           |  |
| muicdlur | OUT                                   |      |           |  |
| Set Time |                                       |      |           |  |

Contactors


Signaling Lights

Relays & Sockets


Timers


RTE

## **Temperature Derating Curves**



#### Installation of Hold-Down Springs DIN Rail Mount Socket





Hold-down Spring (sold separately) SFA-203 (use two springs) **Switch Settings** 



①Operator Mode Selector
②Scale Selector
③Time Range Selector

- Turn the selectors securely using a flat screwdriver 4mm wide (maximum). Note that incorrect setting may cause malfunction. Do not turn the selectors beyond their limits.
- Since changing the setting during timer operation may cause malfunction, turn power off before changing.

## **Safety Precautions**

Special expertise is required to use Electronic Timers.

- All Electronic Timers are manufactured under IDEC's rigorous quality control system, but users must add a backup or fail safe provision to the control system when using the Electronic Timer in applications where heavy damage or personal injury may occur should the Electronic Timer fail.
- Install the Electronic Timer according to instructions described in this catalog.
- Make sure that the operating conditions are as described in the specifications. If you are uncertain about the specifications, contact IDEC in advance.
- In these directions, safety precautions are categorized in order of importance under Warning and Caution.

## Warnings

Warning notices are used to emphasize that improper operation may cause severe personal injury or death.

- Turn power off to the Electronic timer before starting installation, removal, wiring, maintenance, and inspection on the Electronic Timer.
- Failure to turn power off may cause electrical shocks or fire hazard.

 Do not use the Electronic Timer for an emergency stop circuit or interlocking circuit. If the Electronic Timer should fail, a machine malfunction, breakdown, or accident may occur.

#### Caution

Caution notices are used where inattention might cause personal injury or damage to equipment.

- The Electronic Timer is designed for installation in equipment. Do not install the Electronic Timer outside equipment.
- Install the Electronic Timer in environments described in the specifications. If the Electronic Timer is used in places where it will be subjected to high-temperature, high-humidity, condensation, corrosive gases, excessive vibrations, or excessive shocks, then electrical shocks, fire hazard, or malfunction could result.
- Use an IEC60127-approved fuse and circuit breaker on the power and output line outside the Electronic Timer.
- Do not disassemble, repair, or modify the Electronic Timer.
- When disposing of the Electronic Timer, do so as industrial waste.

Switches & Pilot Lights

Signaling Lights

Relays & Sockets

Terminal Blocks

Contactors



## Accessories

**DIN Rail Mounting Accessories** 

#### **DIN Rail/Surface Mount Sockets and Hold-Down Springs**

|                                      | DIN Rail Mount Socket   | Applicable Hold-Down Springs |             |               |             |
|--------------------------------------|-------------------------|------------------------------|-------------|---------------|-------------|
| Style                                | Appearance              | Use with Timers              | Part Number | Appearance    | Part Number |
| 11-Pin Screw Terminal<br>(dual tier) |                         | DIE DO                       | SR3P-05     |               | 054.000     |
| 11-Pin FingerSafe Socket             |                         | RTE-P2                       | SR3P-05C    |               | SFA-203     |
| 8-Pin Screw Terminal                 | XXXXX                   | DTE D4                       | SR2P-06     |               |             |
| 8-Pin Fingersafe Socket              |                         | RTE-P1                       | SR2P-05C    | CLUD R CLUD R | SFA-202     |
| 11-Blade Screw Terminal              |                         | RTE-B1<br>RTE-B2             | SR3B-05     |               |             |
| DIN Mounting Rail<br>Length 1000mm   | No. of Concession, Name | _                            | BNDN1000    |               |             |


#### **Panel Mounting Accessories**


## Flush Panel Mount Adapter and Sockets that use an Adapter

| Accessory                                   | Description                                 | Appearance                               | Use with       | Part No.  |
|---------------------------------------------|---------------------------------------------|------------------------------------------|----------------|-----------|
| Panel Mount Adapter                         | Adaptor for flush panel mounting RTE timers |                                          | All RTE timers | RTB-G01   |
|                                             | 8-pin screw terminal                        |                                          | RTE-P1         | SR6P-M08G |
|                                             | 11-pin screw terminal                       | (Shown: SR6P-M08G Wiring Socket Adapter) | RTE-P2         | SR6P-M11G |
| Sockets for use with<br>Panel Mount Adapter | 8-pin solder terminal                       |                                          | RTE-P1         | SR6P-S08  |
|                                             | 11-pin solder terminal                      |                                          | RTE-P2         | SR6P-S11  |



## Dimensions





RTE-P1 (8 pin) Terminal Style




RTE-P2 (11 pin)Terminal Style




**Panel Mount Adapter** 


RTE Timer, 8-Pin and 11-Pin with SR6P-S08 or SR6P-S11



#### RTE Timer, 8-Pin with SR6P-M08G



#### RTE Timer, 11-Pin with SR6P-M11G



Signaling Lights

Terminal Blocks

**Circuit Breakers** 

950