



Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from,Europe,America and south Asia,supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of “Quality Parts,Customers Priority,Honest Operation,and Considerate Service”,our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip,ALPS,ROHM,Xilinx,Pulse,ON,Everlight and Freescale. Main products comprise IC,Modules,Potentiometer,IC Socket,Relay,Connector.Our parts cover such applications as commercial,industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832

Email & Skype: info@chipsmall.com Web: www.chipsmall.com

Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China



CMOS 16-BIT SINGLE CHIP MICROCONTROLLER
S5U1C17F57T Manual
(Software Evaluation Tool for S1C17F57)

Evaluation board/kit and Development tool important notice

1. This evaluation board/kit or development tool is designed for use for engineering evaluation, demonstration, or development purposes only. Do not use it for other purpose. It is not intended to meet the requirement of design for finished product.
2. This evaluation board/kit or development tool is intended for use by an electronics engineer, and it is not the product for consumer. The user should use this goods properly and safely. Seiko Epson dose not assume any responsibility and liability of any kind of damage and/or fire coursed by usage of it. User should cease to use it when any abnormal issue occurs even during proper and safe use.
3. The part used for this evaluation board/kit or development tool is changed without any notice.


NOTICE

No part of this material may be reproduced or duplicated in any form or by any means without the written permission of Seiko Epson. Seiko Epson reserves the right to make changes to this material without notice. Seiko Epson does not assume any liability of any kind arising out of any inaccuracies contained in this material or due to its application or use in any product or circuit and, further, there is no representation that this material is applicable to products requiring high level reliability, such as, medical products. Moreover, no license to any intellectual property rights is granted by implication or otherwise, and there is no representation or warranty that anything made in accordance with this material will be free from any patent or copyright infringement of a third party. When exporting the products or technology described in this material, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You are requested not to use, to resell, to export and/or to otherwise dispose of the products (and any technical information furnished, if any) for the development and/or manufacture of weapon of mass destruction or for other military purposes.

All brands or product names mentioned herein are trademarks and/or registered trademarks of their respective companies.

Configuration of product number

● Devices



● Development tools




Table of Contents

1. Overview	1
1.1 Usage Method	2
2. Name and Functions of Each Part	4
2.1 Name of Each Part	4
2.2 Functions of Each Part	9
2.2.1 Jumper Switch Functions	9
2.2.2 Functions of Each Component	10
3. Block Diagram	12
4. Connectors	13
4.1 CPU Board Connectors	13
4.1.1 CPU board interface connector (CN1-1 to CN1-4)	13
4.1.2 Debug Interface Connectors (CN2-1 to CN2-2)	15
4.1.3 Power Supply Connector (CN3)	15
4.1.4 USB Connector (CN4)	15
4.2 Peripheral Board Connectors	16
4.2.1 Power supply Connector (CN5)	16
4.2.2 General Purpose CPU Interface (CN6)	16
4.2.3 EPD Panel Interface Connector (CN7-1)	17
4.2.4 EPD Panel Interface Connector (CN7-2)	18
4.2.5 EPD Panel Interface Connector Pads (CN8-1 to 3)	19
4.2.6 EPD Panel Interface Connector Pads (CN9-1)	20
4.2.7 EPD Panel Interface Connector Pads (CN9-2)	21
4.2.8 EPD module interface connector pad (CN10)	22
5. Sample Software Manipulation	23
5.1 Jumper Switch Settings	23
5.2 Basic Function Manipulation Method	23
5.2.1 Function Overview	23
5.2.2 Software Startup	23
5.2.3 EPD Drive Waveform Selection	24
5.2.4 RTC Demonstration	24
5.2.5 Temperature Measurement Demonstration	24
5.2.6 Current Consumption Measurement Demonstration	25
Appendix A Sample Software File Configuration	26
Appendix B Circuit Diagram and Component List	27
Revision History	40

1. Overview

The S5U1C17F57T1 (SVT17F57: Software eValuation Tool for S1C17F57) and the S5U1C17F57T2(SVTmini 17F57: Software eValuation Tool for S1C17F57) ^{*1} are evaluation and development support boards for the Seiko Epson single-chip microcontroller S1C17F57.

The S5U1C17F57T1 is composed of a CPU board and a peripheral board. In the CPU board, an IC socket for the S1C17F57, extension connectors, debug connectors for the S1C17F57 and others are built-in. In the peripheral board, an EPD (Electrophoretic Display) panel, EPD panel connectors, EPD panel connector pads, a buzzer, a tact switch and others are built-in. These make it possible to perform the functions such as the EPD drive display, buzzer rumbling and switch input.

The S5U1C17F57T2 is composed only of the CPU board that is used in the S5U1C17F57T1, and can be applicable for various applications using the extension connectors.

- | | |
|--------------------------------|--|
| 1) CPU | S1C17F57 (QFP15-128) |
| 2) Power supply voltage | External power supply (DC3.0V)
Coin battery (CR2032: 3.0 V) (inserted in the battery folder) |
| 3) CPU clock | OSC1 : 32.768kHz crystal oscillator
OSC3 : 4.000MHz crystal oscillator |
| 4) Built-in devices | |
| CPU board: | IC socket for S1C17F57 (S1C17F57 is inserted)
Crystal oscillator
Reset switch
Extension connector
LED
USB interface and connector
Jumper switches for various settings |
| Peripheral board: | EPD panel connectors and connector pads
EPD panel (DM-EPS2)
Tact switches
Buzzer
Power supply switch
Jumper switches for various settings |
| 5) Accessories | Jumper switch × 3
Power supply cable |
| 6) Operating temperature range | 5 °C to 35 °C |
| 7) Operating voltage range | 2.0 V to 5.5 V |

*1: The S5U1C17F57T1 is a package of the CPU board and the peripheral board, and the S5U1C17F57T2 is a package only of the CPU board.

1. Overview

1.1 Usage Method

The S1C17F57 software debugging and evaluation environment can be set up with the following procedures.

<For Software Debugging>

- (1) Connect the 4-pin connector for the target and the 4-pin connector for the Flash programming power supply of the ICDminiVer.2 to the connectors (CN2-1 (J5) and CN2-2 (J6)) of the CPU board, respectively, using the dedicated cables that are included in the S5U1C17001H2 (ICDminiVer.2).
- (2) Place the VDD power supply selection jumper switch (JP14) of the CPU board on the “EXT” side.
- (3) Place the VPP power supply selection jumper switch (JP12) of the CPU board on the “ICD” side.
- (4) Set the jumper switches of the CPU board as follows.
JP1, JP2, JP3, JP17: Short
JP13, JP18, JP19: Open
If the peripheral board is connected, set JP23 of the peripheral board to open.
- (5) Supply the power output from a stabilized power supply or the power output from the ICDminiVer.2 to the power supply connector (CN3 (J8)) of the CPU board. The power supply voltage should be within the S1C17F57 operating power supply voltage range.
- (6) Connect the ICDminiVer.2 to the PC using the USB cable included in the ICDminiVer.2.

In addition, set DIP switches of the ICDminiVer.2 as follows

“Selecting the DSIO signal level” (SW4, SW5) “Voltage input from the target”

“Selecting the Flash programming voltage output” (SW8) ON

<For Free-run with External Power Supply>

- (1) Place the VDD power supply selection jumper switch (JP14) of the CPU board on the “EXT” side.
- (2) Set the jumper switches of the CPU board as follows.
JP1, JP2, JP3, JP17: Short
JP13, JP18, JP19: Open
If the peripheral board is connected, set JP23 of the peripheral board to open.
- (3) Supply the power output from a stabilized power supply to the power supply connector (CN3 (J8)) of the CPU board. The power supply voltage should be within the S1C17F57 operating power supply voltage range.

<For Free-run with Coin Battery (when the CPU board and the peripheral board are used as a set)>

- (1) Place the VDD power supply selection jumper switch (JP14) of the CPU board on the “EXT” side.
- (2) Set the jumper switches of the CPU board as follows.
JP1, JP2, JP3 Short
JP13, JP17, JP18, JP19 Open
Place JP23 of the peripheral board on the “BATT” side.
- (3) Insert the coin battery to the battery folder mounted on the peripheral board.
- (4) Set the power supply switch (SW2) of the peripheral board to the “ON” side.

The factory default settings are the above.

Table 1.1 Jumper setting list in each mode

Board	Jumper switch number	Software debugging	Free-run with external power supply	Free-run with coin battery
CPU	JP1-JP3	ON	ON	ON
	JP4-JP11	—	—	—
	JP12	ICD	—	—
	JP13	OPEN	OPEN	OPEN
	JP14	EXT	EXT	EXT
	JP15-16	—	—	—
	JP17	ON	ON	OPEN
	JP18-19	OPEN	OPEN	OPEN
Peripheral	JP1-22	—	—	—
	JP23	OPEN	OPEN	BATT
	JP24-29	—	—	—

ON: Place the jumper switch

OPEN: Remove the jumper switch

—: Arbitrary

Other: Place the jumper switch to the side of this name

2. Name and Functions of Each Part

2. Name and Functions of Each Part

2.1 Name of Each Part

The followings show the name of each part.




Figure 2.1 Name of each part for S5U1C17F57T1 CPU board (front side)

2. Name and Functions of Each Part




Figure 2.2 Name of each part for S5U1C17F57T1 CPU board (reverse side)

Note: The No.1 pin position of the CN2-1 (J5) connector is shown above. When connecting the ICDminiVer.2 to this board, confirm the direction of the connector carefully.

2. Name and Functions of Each Part




Figure 2.3 Name of each part for S5U1C17F57T1 peripheral board (front side)

2. Name and Functions of Each Part




Figure 2.4 Name of each part for S5U1C17F57T1 peripheral board (reverse side)

2. Name and Functions of Each Part




Figure 2.5 Connection diagram of EPD module (DM-EPS2)

2.2 Functions of Each Part

2.2.1 Jumper Switch Functions

Table 2.2.1 Jumper function list for CPU board

Name	Type	Function	Factory default setting	Selectable setting
JP1 (VD1_F-VD1)	Pin	Connects the S1C17F57 VD1_F terminal to the VD1 terminal.	Short	Open
JP2 (S1C17F57-VDD)	Pin	Connects the S1C17F57 VDD terminal to the VDD power supply.	Short	Open
JP3 (S1C17F57-VPP)	Pin	Connects the S1C17F57 VPP terminal to the VPP power supply.	Short	Open
JP4 to JP7	Solder bridge	Selects the usage of the S1C17F57 P20 to P23 terminals. Short: General purpose I/O Open: RF converter component connection	Short	Open
JP8 to JP11	Solder bridge	Selects the usage of the S1C17F57 P24 to P27 terminals. Short: General purpose I/O Open: RF converter component connection	Short	Open
JP12(VPP)	Pin	Selects the S1C17F57 Flash programming power supply. 1(ICD): External power supply connector CN2-2(J6) 3(USB): USB VBUS boost power supply	1(ICD)	3(USB)
JP13 (VPP_CNT-P05)	Pin	Enables the USB power supply boost circuit. Short: Enables the USB power supply boost control Open: Disables the USB power supply boost control	Open	Short
JP14(VDD)	Pin	Selects the S1C17F57 VDD power supply. 1(EXT): External power supply connector CN3(J8) 3(USB): USB VBUS power supply When using the coin battery in the peripheral board, set to "1 (EXT)" and set JP17 to open. Or remove this jumper switch.	1(EXT)	3(USB) Open
JP15	Solder bridge	Connects the signal line (SIN) between the CP2102 and the S1C17F57.	Open	Short
JP16	Solder bridge	Connects the signal line (SOUT) between the CP2102 and the S1C17F57.	Open	Short
JP17 (VDD_EXT)	Pin	Supplies the power from the external VDD power supply connector CN3 (J8). Short: Supplies Open: Does no supply.	Open	Short
JP18	Pin	Connects the S1C17F57 VE1 terminal to the VE2 terminal.	Open	Short
JP19	Pin	Connects the S1C17F57 VE2 terminal to the VDD terminal.	Open	Short

2. Name and Functions of Each Part

Table 2.2.2 Jumper function list for peripheral board

Name	Type	Function	Factory default setting	Selectable setting
JP1(VOUT2-VEPD)	Pin		Short	Open
JP2(VOUT2-C)	Pin		Short	Open
JP3(VD1-C)	Pin		Short	Open
JP4(EPDTRG)	Pin		Short	Open
JP5(EPDCLK)	Pin		Short	Open
JP6(SDO)	Pin		Short	Open
JP7(SDA)	Pin		Short	Open
JP8(SPICLK)	Pin		Short	Open
JP9(I2C_AD0_SCS)	Pin		Short	Open
JP10(OS)	Pin		Open	Short
JP11(XRES)	Pin		Short	Open
JP12(VDD)	Pin		Short	Open
JP13(VPP)	Pin		Open	Short
JP14(MFS)	Pin		Open	Short
JP15(VD1-VDD)	Pin		Open	Short
JP16(MFS)	Pin	Connects the external EPD module connector pad CN10 (J12) to the MFS terminal.	Open	Short
JP17(I2C_AD0_SCS)	Pin		Open	1(Vss) 3(VDD)
JP18(I2C_AD1)	Pin		Open	1(Vss) 3(VDD)
JP19(IFSEL)	Pin		3(VDD)	1(Vss) Open
JP20(SLVSEL)	Pin		3(VDD)	1(Vss) Open
JP21(VD1SEL)	Pin		3(VDD)	1(Vss) Open
JP22(VPP)	Pin	Connect the external EPD module connector pad CN10 (J12) to the VPP terminal.	Open	Short
JP23(VDD)	Pin	Selects the VDD power supply. 3(BATT): Coin battery 1(EXT): Power supply connector CN5(J14)	3(BATT)	1(EXT) Open
JP24-27	Solder bridge	Connects tact switches to the P00 – P03 port.	Short	Open
JP28	Pin		Open	Short
JP29	Pin		Short	Open

2.2.2 Functions of Each Component

Table 2.2.3 Component and function list for CPU board

Name	Location	Function
IC socket	U1	For the S1C17F57
Connector	CN1-1 to 4 (J4,J3,J1,J2)	Interface with the peripheral board (external)
Connector	CN2-1 to 2(J5,J6)	Debug interface (for the S5U1C17001H2)
Connector	CN3(J8)	External power supply connector
Connector	CN4(J7)	USB connector
LED	D2	Lit when using the external VDD power supply
Switch	SW1	System reset
Monitor pin	TP1(VPP)	VPP (USB VBUS boost) power supply monitor pin
Monitor terminal	TP2(VDD)	VDD power supply monitor through-hole
Monitor terminal	TP3,TP4	Serial interface signal monitor through-hole
Capacitor	C35	Reference capacitor (DC/AC bias, channel 0)

2. Name and Functions of Each Part

Resistor	R4	Reference resistor (DC bias, channel 0)
Sensor	SENR1	Resistive sensor 1 (DC bias, channel 0)
Sensor	SENR2	Resistive sensor 2 (DC bias, channel 0)
Resistor	R5	Reference resistor (AC bias, channel 0)
Resistive sensor	SENR3	Resistive sensor (AC bias, channel 0)
Capacitor	C37	Reference capacitor (DC/AC bias, channel 1)
Resistor	R6	Reference resistor (DC bias, channel 1)
Sensor	SENR4	Resistive sensor 1 (DC bias, channel 1)
Sensor	SENR5	Resistive sensor 2 (DC bias, channel 1)
Resistor	R7	Reference resistor (AC bias, channel 1)
Resistive sensor	SENR6	Resistive sensor (AC bias, channel 1)

Table 2.2.4 Component and function list for peripheral board

Name	Location	Function
IC	U1	
Connector	CN1-1 to 4 (J5, J3, J15, J4)	Interface with the CPU board
Connector	CN5 (J14)	Dedicated external power supply connector for the peripheral board with stand-alone operation (When the CPU board is connected, the external power supply connector CN3 is used.)
Connector	CN6 (J13)	Interface with the external CPU
Connector	CN7-1 to 2 (J2, J1)	EPD panel connector (0.3 mm pitch, staggered arrangement)
Connector pad	CN8-1 to 3 (J8, J9, J11)	EPD panel connector pad (0.3, 0.4 and 0.5 mm pitch, straight alignment)
Connector pad	CN9-1 to 2 (J7, J6)	EPD panel connector pad (0.2 and 0.4 mm pitch, staggered arrangement)
Connector pad	CN10 (J12)	Connector pad for the external EPD module (0.5 mm pitch)
Through-holes	CN11 (J10)	Through-holes for the EPD panel connection (2.54 mm pitch)
Switch	SW1	System reset
Switch	SW2	Battery power supply switch
Switch	SW3 to SW6	P00 - P03 port input switch
Monitor terminal	TP1	V _{DD} power supply (battery)
Monitor terminal	TP2	V _{DD} power supply (selected power supply)
Monitor terminal	TP3	GND terminal
Monitor terminal	TP4	V _{DD} (external power supply)
Monitor pin	TP5	P00 (REGMON) monitor pin
Buzzer	BZ1	Piezo buzzer
Battery folder	BT1	For the coin battery (When the coin battery is inserted, do not supply a power from the CN3 (external power supply connector) of the CPU board.)

3. Block Diagram

3. Block Diagram

The S5U1C17F57T1 block diagram is shown below.




Figure 3.1 S5U1C17F57T1 block diagram

4. Connectors

4.1 CPU Board Connectors

4.1.1 CPU board interface connector (CN1-1 to CN1-4)

Table 4.1 Pin assignment table for CPU board interface connector (CN1-1)

No.	Terminal name	I/O	Function	No.	Terminal name	I/O	Function
1	Vss	—	Power supply (-)	21	ESEG23	O	EPD segment output
2	Vss	—	Power supply (-)	22	ESEG22	O	EPD segment output
3	ESEG39	O	EPD segment output	23	ESEG21	O	EPD segment output
4	ESEG38	O	EPD segment output	24	ESEG20	O	EPD segment output
5	ESEG37	O	EPD segment output	25	ESEG19	O	EPD segment output
6	ESEG36	O	EPD segment output	26	Vdd	—	Power supply (+)
7	ESEG35	O	EPD segment output	27	Vdd	—	Power supply (+)
8	ESEG34	O	EPD segment output	28	ESEG18	O	EPD segment output
9	ESEG33	O	EPD segment output	29	ESEG17	O	EPD segment output
10	ESEG32	O	EPD segment output	30	ESEG16	O	EPD segment output
11	ESEG31	O	EPD segment output	31	ESEG15	O	EPD segment output
12	ESEG30	O	EPD segment output	32	ESEG14	O	EPD segment output
13	Vdd	—	Power supply (+)	33	ESEG13	O	EPD segment output
14	Vdd	—	Power supply (+)	34	ESEG12	O	EPD segment output
15	ESEG29	O	EPD segment output	35	ESEG11	O	EPD segment output
16	ESEG28	O	EPD segment output	36	ESEG10	O	EPD segment output
17	ESEG27	O	EPD segment output	37	ESEG9	O	EPD segment output
18	ESEG26	O	EPD segment output	38	ESEG8	O	EPD segment output
19	ESEG25	O	EPD segment output	39	Vss	—	Power supply (-)
20	ESEG24	O	EPD segment output	40	Vss	—	Power supply (-)

Table 4.2 Pin assignment table for CPU board interface connector (CN1-2)

No.	Terminal name	I/O	Function	No.	Terminal name	I/O	Function
1	Vss	—	Power supply (-)	21	ESEG55	O	EPD segment output
2	Vss	—	Power supply (-)	22	ESEG54	O	EPD segment output
3	#RESET_PER	I	Initial reset input	23	ESEG53	O	EPD segment output
4	NC	—	Unconnected	24	ESEG52	O	EPD segment output
5	NC	—	Unconnected	25	ESEG51	O	EPD segment output
6	VE2	—	EPD system power supply circuit output	26	Vdd	—	Power supply (+)
7	VEPD	—	EPD system power supply circuit output	27	Vdd	—	Power supply (+)
8	ETP1	O	EPD top plane	28	ESEG50	O	EPD segment output
9	EBP1	O	EPD back plane	29	ESEG49	O	EPD segment output
10	NC	—	Unconnected	30	ESEG48	O	EPD segment output
11	ESEG63	O	EPD segment output	31	ESEG47	O	EPD segment output
12	ESEG62	O	EPD segment output	32	ESEG46	O	EPD segment output
13	Vdd	—	Power supply (+)	33	ESEG45	O	EPD segment output
14	Vdd	—	Power supply (+)	34	ESEG44	O	EPD segment output
15	ESEG61	O	EPD segment output	35	ESEG43	O	EPD segment output
16	ESEG60	O	EPD segment output	36	ESEG42	O	EPD segment output
17	ESEG59	O	EPD segment output	37	ESEG41	O	EPD segment output
18	ESEG58	O	EPD segment output	38	ESEG40	O	EPD segment output
19	ESEG57	O	EPD segment output	39	Vss	—	Power supply (-)
20	ESEG56	O	EPD segment output	40	Vss	—	Power supply (-)

4. Connectors

Table 4.3 Pin assignment table for CPU board interface connector (CN1-3)


No.	Terminal name	I/O	Function	No.	Terminal name	I/O	Function
1	Vss	—	Power supply (-)	21	P10	I/O	P10/SPICLK
2	Vss	—	Power supply (-)	22	Vss	—	Power supply (-)
3	NC	—	Unconnected	23	P07	I/O	P07/BZ
4	P20	I/O	P20/SDAS/SEN0/BZ	24	Vss	—	Power supply (-)
5	Vss	—	Power supply (-)	25	P06	I/O	P06/TOUTB1/CAPB1/#BZ
6	P17	I/O	P17/#BFR/EPDCLK	26	VDD	—	Power supply (+)
7	Vss	—	Power supply (-)	27	VDD	—	Power supply (+)
8	P16	I/O	P16/SOUT/SCLM	28	P05	I/O	P05/TOUTA1/CAPA1
9	Vss	—	Power supply (-)	29	Vss	—	Power supply (-)
10	P15	I/O	P15/SIN/SDAM	30	P04	I/O	P04/EXCL1
11	Vss	—	Power supply (-)	31	Vss	—	Power supply (-)
12	P14	I/O	P14/SCLK/EPDTRG	32	P03	I/O	P03/TOUTB0/CAPB0
13	VDD	—	Power supply (+)	33	Vss	—	Power supply (-)
14	VDD	—	Power supply (+)	34	P02	I/O	P02/TOUTA0/CAPA0
15	P13	I/O	P13/#SPISS/FOUTA	35	Vss	—	Power supply (-)
16	Vss	—	Power supply (-)	36	P01	I/O	P01/EXCL0
17	P12	I/O	P12/SDI/SCLS	37	Vss	—	Power supply (-)
18	Vss	—	Power supply (-)	38	P00	I/O	P00/RFCLKO/REGMON
19	P11	I/O	P11/SDO/SDAS	39	Vss	—	Power supply (-)
20	Vss	—	Power supply (-)	40	Vss	—	Power supply (-)

Table 4.4 Pin assignment table for CPU board interface connector (CN1-4)

No.	Terminal name	I/O	Function	No.	Terminal name	I/O	Function
1	Vss	—	Power supply (-)	21	DST2	I/O	DST2/P33
2	Vss	—	Power supply (-)	22	Vss	—	Power supply (-)
3	ESEG7	O	EPD segment output	23	DSIO	I/O	DSIO/P32
4	ESEG6	O	EPD segment output	24	Vss	—	Power supply (-)
5	ESEG5	O	EPD segment output	25	P31	I/O	P31/EPDCLK
6	ESEG4	O	EPD segment output	26	VDD	—	Power supply (+)
7	ESEG3	O	EPD segment output	27	VDD	—	Power supply (+)
8	ESEG2	O	EPD segment output	28	P30	I/O	P30/FOUTB/#SPISS
9	ESEG1	O	EPD segment output	29	P27	I/O	P27/SEN1
10	ESEG0	O	EPD segment output	30	P26	I/O	P26/SENA1
11	EBP0	O	EPD back plane output	31	P25	I/O	P25/REF1
12	ETP0	O	EPD top plane output	32	P24	I/O	P24/RFIN1
13	VPP	—	Flash memory programming power supply	33	Vss	—	Power supply (-)
14	VPP	—	Flash memory programming power supply	34	P23	I/O	P23/SCLM/RFIN0
15	NC	—	Unconnected	35	Vss	—	Power supply (-)
16	TEST0	I	Input for testing	36	P22	I/O	P22/SDAM/REF0
17	#RESET	O	Initial reset output	37	Vss	—	Power supply (-)
18	Vss	—	Power supply (-)	38	P21	I/O	P21/SCLS/SENA0/#BZ
19	DCLK	I/O	DCLK/P34	39	Vss	—	Power supply (-)
20	Vss	—	Power supply (-)	40	Vss	—	Power supply (-)


4.1.2 Debug Interface Connectors (CN2-1 to CN2-2)

Table 4.5 Pin assignment table for CPU board debug interface connector (CN2-1)

	No.	Terminal name	I/O	Function
	1	DCLK	O	Clock signal for debugging
2	GND	—	Power supply (GND)	
3	DSIO	I/O	Serial communication I/O signal for debugging	
4	DST2	O	Debug status signal	

Note: The No.1 pin position of the CN2-1 (J5) connector is shown above. When connecting the ICDminiVer.2 to this board, confirm the direction of the connector carefully.

Table 4.6 Pin assignment table for CPU board interface connector (CN2-2)

	No.	Terminal name	I/O	Function
	1	VPP	I	Flash memory programming power supply input
2	GND	—	Power supply (GND)	
3	RESET	I	Reset signal input for the target	
4	VCCIN	O	Target voltage output	

4.1.3 Power Supply Connector (CN3)

Table 4.7 Pin assignment table for CPU board power supply connector (CN3)

No.	Terminal name	I/O	Function
1	VDD	—	Power supply (+)
2	GND	—	Power supply (GND)

4.1.4 USB Connector (CN4)

Table 4.8 Pin assignment table for CPU board USB connector (CN4)

No.	Terminal name	I/O	Function
1	VBUS	—	Power supply (+5V)
2	D-	I/O	D-
3	D+	I/O	D+
4	ID	—	Unconnected
5	USBGND	—	Power supply (GND)

4. Connectors

4.2 Peripheral Board Connectors

4.2.1 Power supply Connector (CN5)

Table 4.9 Pin assignment table for peripheral board power supply connector (CN5)

No.	Terminal name	I/O	Function
1	VDD	—	Power supply (+)
2	GND	—	Power supply (GND)
3	VPP	—	Flash memory programming power supply input

4.2.2 General Purpose CPU Interface (CN6)

Table 4.10 Pin assignment table for general purpose CPU interface connector (CN6)

No.	Terminal name	I/O	Function	No.	Terminal name	I/O	Function
1	SDO	O	SPI interface control data output	6	XRES	-	Unconnected
2	SDI	I	SPI interface control data output	7	VDD	—	Power supply (+)
3	Vss	—	Power supply (-)	8	NC	—	Unconnected
4	SCL	I	SPI interface control clock input	9	NC	—	Unconnected
5	SCS	I	SPI interface control chip select	10	NC	—	Unconnected

4.2.3 EPD Panel Interface Connector (CN7-1)

Table 4.11 Pin assignment table for EPD interface connector (CN7-1)

No.	Terminal name	I/O	Function	No.	Terminal name	I/O	Function
1	CN92	O	ETP0(MCU)	47	CN46	O	ESEG20(MCU)
2	CN91	O	EBP0(MCU)	48	CN45	O	ESEG21(MCU)
3	CN90	—	NC	49	CN44	O	ESEG22(MCU)
4	CN89	—	NC	50	CN43	O	ESEG23(MCU)
5	CN88	—	NC	51	CN42	O	ESEG24(MCU)
6	CN87	—	NC	52	CN41	O	ESEG25(MCU)
7	CN86	—	NC	53	CN40	O	ESEG26(MCU)
8	CN85	—	NC	54	CN39	O	ESEG27(MCU)
9	CN84	—	NC	55	CN38	O	ESEG28(MCU)
10	CN83	—	NC	56	CN37	O	ESEG29(MCU)
11	CN82	—	NC	57	CN36	O	ESEG30(MCU)
12	CN81	—	NC	58	CN35	O	ESEG31(MCU)
13	CN80	—	NC	59	CN34	O	ESEG32(MCU)
14	CN79	—	NC	60	CN33	O	ESEG33(MCU)
15	CN78	—	NC	61	CN32	O	ESEG34(MCU)
16	CN77	—	NC	62	CN31	O	ESEG35(MCU)
17	CN76	—	NC	63	CN30	O	ESEG36(MCU)
18	CN75	—	NC	64	CN29	O	ESEG37(MCU)
19	CN74	—	NC	65	CN28	O	ESEG38(MCU)
20	CN73	—	NC	66	CN27	O	ESEG39(MCU)
21	CN72	—	NC	67	CN26	O	ESEG40(MCU)
22	CN71	—	NC	68	CN25	O	ESEG41(MCU)
23	CN70	—	NC	69	CN24	O	ESEG42(MCU)
24	CN69	—	NC	70	CN23	O	ESEG43(MCU)
25	CN68	—	NC	71	CN22	O	ESEG44(MCU)
26	CN67	—	NC	72	CN21	O	ESEG45(MCU)
27	CN66	O	ESEG0(MCU)	73	CN20	O	ESEG46(MCU)
28	CN65	O	ESEG1(MCU)	74	CN19	O	ESEG47(MCU)
29	CN64	O	ESEG2(MCU)	75	CN18	O	ESEG48(MCU)
30	CN63	O	ESEG3(MCU)	76	CN17	O	ESEG49(MCU)
31	CN62	O	ESEG4(MCU)	77	CN16	O	ESEG50(MCU)
32	CN61	O	ESEG5(MCU)	78	CN15	O	ESEG51(MCU)
33	CN60	O	ESEG6(MCU)	79	CN14	O	ESEG52(MCU)
34	CN59	O	ESEG7(MCU)	80	CN13	O	ESEG53(MCU)
35	CN58	O	ESEG8(MCU)	81	CN12	O	ESEG54(MCU)
36	CN57	O	ESEG9(MCU)	82	CN11	O	ESEG55(MCU)
37	CN56	O	ESEG10(MCU)	83	CN10	O	ESEG56(MCU)
38	CN55	O	ESEG11(MCU)	84	CN9	O	ESEG57(MCU)
39	CN54	O	ESEG12(MCU)	85	CN8	O	ESEG58(MCU)
40	CN53	O	ESEG13(MCU)	86	CN7	O	ESEG59(MCU)
41	CN52	O	ESEG14(MCU)	87	CN6	O	ESEG60(MCU)
42	CN51	O	ESEG15(MCU)	88	CN5	O	ESEG61(MCU)
43	CN50	O	ESEG16(MCU)	89	CN4	O	ESEG62(MCU)
44	CN49	O	ESEG17(MCU)	90	CN3	O	ESEG63(MCU)
45	CN48	O	ESEG18(MCU)	91	CN2	O	EBP1(MCU)
46	CN47	O	ESEG19(MCU)	92	CN1	O	ETP1(MCU)

4. Connectors

4.2.4 EPD Panel Interface Connector (CN7-2)

Table 4.12 Pin assignment table for EPD interface connector (CN7-2)

No.	Terminal name	I/O	Function	No.	Terminal name	I/O	Function
1	CN92			47	CN46	O	ESEG44(MCU)
2	CN91			48	CN45	O	ESEG45(MCU)
3	CN90	O	ESEG0(MCU)	49	CN44	O	ESEG46(MCU)
4	CN89	O	ESEG1(MCU)	50	CN43	O	ESEG47(MCU)
5	CN88	O	ESEG2(MCU)	51	CN42	O	ESEG48(MCU)
6	CN87	O	ESEG3(MCU)	52	CN41	O	ESEG49(MCU)
7	CN86	O	ESEG4(MCU)	53	CN40	O	ESEG50(MCU)
8	CN85	O	ESEG5(MCU)	54	CN39	O	ESEG51(MCU)
9	CN84	O	ESEG6(MCU)	55	CN38	O	ESEG52(MCU)
10	CN83	O	ESEG7(MCU)	56	CN37	O	ESEG53(MCU)
11	CN82	O	ESEG8(MCU)	57	CN36	O	ESEG54(MCU)
12	CN81	O	ESEG9(MCU)	58	CN35	O	ESEG55(MCU)
13	CN80	O	ESEG10(MCU)	59	CN34	O	ESEG56(MCU)
14	CN79	O	ESEG11(MCU)	60	CN33	O	ESEG57(MCU)
15	CN78	O	ESEG12(MCU)	61	CN32	O	ESEG58(MCU)
16	CN77	O	ESEG13(MCU)	62	CN31	O	ESEG59(MCU)
17	CN76	O	ESEG14(MCU)	63	CN30	O	ESEG60(MCU)
18	CN75	O	ESEG15(MCU)	64	CN29	O	ESEG61(MCU)
19	CN74	O	ESEG16(MCU)	65	CN28	O	ESEG62(MCU)
20	CN73	O	ESEG17(MCU)	66	CN27	O	ESEG63(MCU)
21	CN72	O	ESEG18(MCU)	67	CN26		
22	CN71	O	ESEG19(MCU)	68	CN25		
23	CN70	O	ESEG20(MCU)	69	CN24		
24	CN69	O	ESEG21(MCU)	70	CN23		
25	CN68	O	ESEG22(MCU)	71	CN22		
26	CN67	O	ESEG23(MCU)	72	CN21		
27	CN66	O	ESEG24(MCU)	73	CN20		
28	CN65	O	ESEG25(MCU)	74	CN19		
29	CN64	O	ESEG26(MCU)	75	CN18		
30	CN63	O	ESEG27(MCU)	76	CN17		
31	CN62	O	ESEG28(MCU)	77	CN16		
32	CN61	O	ESEG29(MCU)	78	CN15		
33	CN60	O	ESEG30(MCU)	79	CN14		
34	CN59	O	ESEG31(MCU)	80	CN13		
35	CN58	O	ESEG32(MCU)	81	CN12		
36	CN57	O	ESEG33(MCU)	82	CN11		
37	CN56	O	ESEG34(MCU)	83	CN10		
38	CN55	O	ESEG35(MCU)	84	CN9		
39	CN54	O	ESEG36(MCU)	85	CN8		
40	CN53	O	ESEG37(MCU)	86	CN7		
41	CN52	O	ESEG38(MCU)	87	CN6		
42	CN51	O	ESEG39(MCU)	88	CN5		
43	CN50	O	ESEG40(MCU)	89	CN4		
44	CN49	O	ESEG41(MCU)	90	CN3		
45	CN48	O	ESEG42(MCU)	91	CN2		
46	CN47	O	ESEG43(MCU)	92	CN1		

4.2.5 EPD Panel Interface Connector Pads (CN8-1 to 3)

Table 4.13 Pin assignment table for EPD interface connector pads (CN8-1 to CN8-3)

No.	Terminal name	I/O	Function	No.	Terminal name	I/O	Function
1	CN96			49	CN48	O	ESEG18(MCU)
2	CN95			50	CN47	O	ESEG19(MCU)
3	CN94			51	CN46	O	ESEG20(MCU)
4	CN93			52	CN45	O	ESEG21(MCU)
5	CN92			53	CN44	O	ESEG22(MCU)
6	CN91			54	CN43	O	ESEG23(MCU)
7	CN90			55	CN42	O	ESEG24(MCU)
8	CN89			56	CN41	O	ESEG25(MCU)
9	CN88			57	CN40	O	ESEG26(MCU)
10	CN87			58	CN39	O	ESEG27(MCU)
11	CN86			59	CN38	O	ESEG28(MCU)
12	CN85			60	CN37	O	ESEG29(MCU)
13	CN84			61	CN36	O	ESEG30(MCU)
14	CN83			62	CN35	O	ESEG31(MCU)
15	CN82			63	CN34	O	ESEG32(MCU)
16	CN81			64	CN33	O	ESEG33(MCU)
17	CN80			65	CN32	O	ESEG34(MCU)
18	CN79			66	CN31	O	ESEG35(MCU)
19	CN78			67	CN30	O	ESEG36(MCU)
20	CN77			68	CN29	O	ESEG37(MCU)
21	CN76			69	CN28	O	ESEG38(MCU)
22	CN75			70	CN27	O	ESEG39(MCU)
23	CN74			71	CN26	O	ESEG40(MCU)
24	CN73			72	CN25	O	ESEG41(MCU)
25	CN72			73	CN24	O	ESEG42(MCU)
26	CN71			74	CN23	O	ESEG43(MCU)
27	CN70			75	CN22	O	ESEG44(MCU)
28	CN69			76	CN21	O	ESEG45(MCU)
29	CN68	O	ETP0(MCU)	77	CN20	O	ESEG46(MCU)
30	CN67	O	EBP0(MCU)	78	CN19	O	ESEG47(MCU)
31	CN66	O	ESEG0(MCU)	79	CN18	O	ESEG48(MCU)
32	CN65	O	ESEG1(MCU)	80	CN17	O	ESEG49(MCU)
33	CN64	O	ESEG2(MCU)	81	CN16	O	ESEG50(MCU)
34	CN63	O	ESEG3(MCU)	82	CN15	O	ESEG51(MCU)
35	CN62	O	ESEG4(MCU)	83	CN14	O	ESEG52(MCU)
36	CN61	O	ESEG5(MCU)	84	CN13	O	ESEG53(MCU)
37	CN60	O	ESEG6(MCU)	85	CN12	O	ESEG54(MCU)
38	CN59	O	ESEG7(MCU)	86	CN11	O	ESEG55(MCU)
39	CN58	O	ESEG8(MCU)	87	CN10	O	ESEG56(MCU)
40	CN57	O	ESEG9(MCU)	88	CN9	O	ESEG57(MCU)
41	CN56	O	ESEG10(MCU)	89	CN8	O	ESEG58(MCU)
42	CN55	O	ESEG11(MCU)	90	CN7	O	ESEG59(MCU)
43	CN54	O	ESEG12(MCU)	91	CN6	O	ESEG60(MCU)
44	CN53	O	ESEG13(MCU)	92	CN5	O	ESEG61(MCU)
45	CN52	O	ESEG14(MCU)	93	CN4	O	ESEG62(MCU)
46	CN51	O	ESEG15(MCU)	94	CN3	O	ESEG63(MCU)
47	CN50	O	ESEG16(MCU)	95	CN2	O	EBP1(MCU)
48	CN49	O	ESEG17(MCU)	96	CN1	O	ETP1(MCU)

4. Connectors

4.2.6 EPD Panel Interface Connector Pads (CN9-1)

Table 4.14 Pin assignment table for EPD interface connector pads (CN9-1)

No.	Terminal name	I/O	Function	No.	Terminal name	I/O	Function
1	NC	—		51	CN50	O	ESEG16(MCU)
2	NC	—		52	CN49	O	ESEG17(MCU)
3	NC	—		53	CN48	O	ESEG18(MCU)
4	NC	—		54	CN47	O	ESEG19(MCU)
5	CN96			55	CN46	O	ESEG20(MCU)
6	CN95			56	CN45	O	ESEG21(MCU)
7	CN94			57	CN44	O	ESEG22(MCU)
8	CN93			58	CN43	O	ESEG23(MCU)
9	CN92			59	CN42	O	ESEG24(MCU)
10	CN91			60	CN41	O	ESEG25(MCU)
11	CN90			61	CN40	O	ESEG26(MCU)
12	CN89			62	CN39	O	ESEG27(MCU)
13	CN88			63	CN38	O	ESEG28(MCU)
14	CN87			64	CN37	O	ESEG29(MCU)
15	CN86			65	CN36	O	ESEG30(MCU)
16	CN85			66	CN35	O	ESEG31(MCU)
17	CN84			67	CN34	O	ESEG32(MCU)
18	CN83			68	CN33	O	ESEG33(MCU)
19	CN82			69	CN32	O	ESEG34(MCU)
20	CN81			70	CN31	O	ESEG35(MCU)
21	CN80			71	CN30	O	ESEG36(MCU)
22	CN79			72	CN29	O	ESEG37(MCU)
23	CN78			73	CN28	O	ESEG38(MCU)
24	CN77			74	CN27	O	ESEG39(MCU)
25	CN76			75	CN26	O	ESEG40(MCU)
26	CN75			76	CN25	O	ESEG41(MCU)
27	CN74			77	CN24	O	ESEG42(MCU)
28	CN73			78	CN23	O	ESEG43(MCU)
29	CN72			79	CN22	O	ESEG44(MCU)
30	CN71			80	CN21	O	ESEG45(MCU)
31	CN70			81	CN20	O	ESEG46(MCU)
32	CN69			82	CN19	O	ESEG47(MCU)
33	CN68	O	ETP0(MCU)	83	CN18	O	ESEG48(MCU)
34	CN67	O	EBP0(MCU)	84	CN17	O	ESEG49(MCU)
35	CN66	O	ESEG0(MCU)	85	CN16	O	ESEG50(MCU)
36	CN65	O	ESEG1(MCU)	86	CN15	O	ESEG51(MCU)
37	CN64	O	ESEG2(MCU)	87	CN14	O	ESEG52(MCU)
38	CN63	O	ESEG3(MCU)	88	CN13	O	ESEG53(MCU)
39	CN62	O	ESEG4(MCU)	89	CN12	O	ESEG54(MCU)
40	CN61	O	ESEG5(MCU)	90	CN11	O	ESEG55(MCU)
41	CN60	O	ESEG6(MCU)	91	CN10	O	ESEG56(MCU)
42	CN59	O	ESEG7(MCU)	92	CN9	O	ESEG57(MCU)
43	CN58	O	ESEG8(MCU)	93	CN8	O	ESEG58(MCU)
44	CN57	O	ESEG9(MCU)	94	CN7	O	ESEG59(MCU)
45	CN56	O	ESEG10(MCU)	95	CN6	O	ESEG60(MCU)
46	CN55	O	ESEG11(MCU)	96	CN5	O	ESEG61(MCU)
47	CN54	O	ESEG12(MCU)	97	CN4	O	ESEG62(MCU)
48	CN53	O	ESEG13(MCU)	98	CN3	O	ESEG63(MCU)
49	CN52	O	ESEG14(MCU)	99	CN2	O	EBP1(MCU)
50	CN51	O	ESEG15(MCU)	100	CN1	O	ETP1(MCU)

4.2.7 EPD Panel Interface Connector Pads (CN9-2)

Table 4.15 Pin assignment table for EPD interface connector pads (CN9-2)

No.	Terminal name	I/O	Function	No.	Terminal name	I/O	Function
1	CN96			49	CN48	O	ESEG18(MCU)
2	CN95			50	CN47	O	ESEG19(MCU)
3	CN94			51	CN46	O	ESEG20(MCU)
4	CN93			52	CN45	O	ESEG21(MCU)
5	CN92			53	CN44	O	ESEG22(MCU)
6	CN91			54	CN43	O	ESEG23(MCU)
7	CN90			55	CN42	O	ESEG24(MCU)
8	CN89			56	CN41	O	ESEG25(MCU)
9	CN88			57	CN40	O	ESEG26(MCU)
10	CN87			58	CN39	O	ESEG27(MCU)
11	CN86			59	CN38	O	ESEG28(MCU)
12	CN85			60	CN37	O	ESEG29(MCU)
13	CN84			61	CN36	O	ESEG30(MCU)
14	CN83			62	CN35	O	ESEG31(MCU)
15	CN82			63	CN34	O	ESEG32(MCU)
16	CN81			64	CN33	O	ESEG33(MCU)
17	CN80			65	CN32	O	ESEG34(MCU)
18	CN79			66	CN31	O	ESEG35(MCU)
19	CN78			67	CN30	O	ESEG36(MCU)
20	CN77			68	CN29	O	ESEG37(MCU)
21	CN76			69	CN28	O	ESEG38(MCU)
22	CN75			70	CN27	O	ESEG39(MCU)
23	CN74			71	CN26	O	ESEG40(MCU)
24	CN73			72	CN25	O	ESEG41(MCU)
25	CN72			73	CN24	O	ESEG42(MCU)
26	CN71			74	CN23	O	ESEG43(MCU)
27	CN70			75	CN22	O	ESEG44(MCU)
28	CN69			76	CN21	O	ESEG45(MCU)
29	CN68	O	ETP0(MCU)	77	CN20	O	ESEG46(MCU)
30	CN67	O	EBP0(MCU)	78	CN19	O	ESEG47(MCU)
31	CN66	O	ESEG0(MCU)	79	CN18	O	ESEG48(MCU)
32	CN65	O	ESEG1(MCU)	80	CN17	O	ESEG49(MCU)
33	CN64	O	ESEG2(MCU)	81	CN16	O	ESEG50(MCU)
34	CN63	O	ESEG3(MCU)	82	CN15	O	ESEG51(MCU)
35	CN62	O	ESEG4(MCU)	83	CN14	O	ESEG52(MCU)
36	CN61	O	ESEG5(MCU)	84	CN13	O	ESEG53(MCU)
37	CN60	O	ESEG6(MCU)	85	CN12	O	ESEG54(MCU)
38	CN59	O	ESEG7(MCU)	86	CN11	O	ESEG55(MCU)
39	CN58	O	ESEG8(MCU)	87	CN10	O	ESEG56(MCU)
40	CN57	O	ESEG9(MCU)	88	CN9	O	ESEG57(MCU)
41	CN56	O	ESEG10(MCU)	89	CN8	O	ESEG58(MCU)
42	CN55	O	ESEG11(MCU)	90	CN7	O	ESEG59(MCU)
43	CN54	O	ESEG12(MCU)	91	CN6	O	ESEG60(MCU)
44	CN53	O	ESEG13(MCU)	92	CN5	O	ESEG61(MCU)
45	CN52	O	ESEG14(MCU)	93	CN4	O	ESEG62(MCU)
46	CN51	O	ESEG15(MCU)	94	CN3	O	ESEG63(MCU)
47	CN50	O	ESEG16(MCU)	95	CN2	O	EBP1(MCU)
48	CN49	O	ESEG17(MCU)	96	CN1	O	ETP1(MCU)