# mail

Chipsmall Limited consists of a professional team with an average of over 10 year of expertise in the distribution of electronic components. Based in Hongkong, we have already established firm and mutual-benefit business relationships with customers from, Europe, America and south Asia, supplying obsolete and hard-to-find components to meet their specific needs.

With the principle of "Quality Parts, Customers Priority, Honest Operation, and Considerate Service", our business mainly focus on the distribution of electronic components. Line cards we deal with include Microchip, ALPS, ROHM, Xilinx, Pulse, ON, Everlight and Freescale. Main products comprise IC, Modules, Potentiometer, IC Socket, Relay, Connector. Our parts cover such applications as commercial, industrial, and automotives areas.

We are looking forward to setting up business relationship with you and hope to provide you with the best service and solution. Let us make a better world for our industry!



## Contact us

Tel: +86-755-8981 8866 Fax: +86-755-8427 6832 Email & Skype: info@chipsmall.com Web: www.chipsmall.com Address: A1208, Overseas Decoration Building, #122 Zhenhua RD., Futian, Shenzhen, China



Rev 09 04 07

### TLP150CJ Enclosure

Installation Notes TLP150CJ • Cover Accessory Kit TLP150CJ will fit the TLP150 power supplies.

#### Materials

- 1 Base
- 1 Cover
- 4 M3X6mm Pan head screws with spring washer
- 4 M3X6mm countersunk screws
- 1 M4 nut
- 1 M4 star washer
- 1 M4 spring washer
- 1 Plastic insulator sheet



#### Installation Instructions and Notes

- 1. Place the insulator over the chassis as shown.
- 2. Place TLP150 power supply over the insulator as shown.
- 3. Align the 4x power supply to the chassis standoff.
- 4. Secure 4 pan head screws with washer provided with in kit as shown.
- 5. Place the cover over TLP150 power supply as shown.
- 6. Align the 4x cover to the U-bracket countersink holes.
- 7. Secure 4 countersink screws provided with in kit as shown.
- 8. Overall dimensions: 5.95 (151.13) x 3.4 (86.36) x 1.6 (40.64).
- 9. Base plate has two sets of customer mountings:
  a. Bottom mounting (4X) M3 inserts. Max. screw penetration 0.0787 (2mm)
  b. Side mounting (4X) M3 inserts. Max. screw penetration 0.236 (6mm)
- 10. Ensure insulator is correctly fitted in base under PCB to maintain safety creepage and clearances.
- 11. Ensure base is firmly connected to supply earth via the earth stud marked ④
- 12. When using this enclosure, ensure that relevant safety standards (e.g. EN60950) are complied with, in respect to creepage and clearance distances, and distances through insulation.
- 13. All dimensions are in inches (mm)







Rev. 09.04.07 TLP150CJ Enclosure 2 of 2

#### Americas

5810 Van Allen Way Carlsbad, CA 92008 USA Telephone: +1 760 930 4600 Facsimile: +1 760 930 0698

#### Europe (UK)

Waterfront Business Park Merry Hill, Dudley West Midlands, DY5 1LX United Kingdom Telephone: +44 (0) 1384 842 211 Facsimile: +44 (0) 1384 843 355

#### Asia (HK)

16th - 17th Floors, Lu Plaza 2 Wing Yip Street, Kwun Tong Kowloon, Hong Kong Telephone: +852 2176 3333 Facsimile: +852 2176 3888

For global contact, visit:

www.astecpower.com www.artesyn.com technicalsupport@astec.com technicalsupport@artesyn.com

While every precaution has been taken to ensure accuracy and completeness in this literature, Emerson Network Power assumes no responsibility, and disclaims all liability for damages resulting from use of this information or for any errors or omissions.

**Emerson Network Power.** The global leader in enabling business-critical continuity.



Emerson Network Power and the Emerson Network Power logo are trademarks and service marks of Emerson Electric Co. ©2007 Emerson Electric Co.